



Emulex Driver for FreeBSD

User Manual

Versions 11.0 and 11.1
March 1, 2016

pub-005374

Corporate Headquarters

San Jose, CA

Website

www.broadcom.com

Broadcom, the pulse logo, Connecting everything, the Connecting everything logo, Avago Technologies, and Emulex are among the trademarks of Broadcom Ltd. and/or its affiliates in the United States, certain other countries and/or the EU. Any other trademarks or trade names mentioned are the property of their respective owners.

Broadcom Ltd. reserves the right to make changes without further notice to any products or data herein to improve reliability, function, or design.

Information furnished by Broadcom Ltd. is believed to be accurate and reliable. However, Broadcom Ltd. does not assume any liability arising out of the application or use of this information, nor the application or use of any product or circuit described herein, neither does it convey any license under its patent rights nor the rights of others.

Copyright © 2012-2016 Broadcom Ltd. All Rights Reserved.

Table of Contents

Chapter 1: Introduction	4
1.1 Supported Versions and Adapters	4
1.2 Abbreviations	4
Chapter 2: Installing and Uninstalling	6
2.1 General Installation Requirements	6
2.2 Installing the FreeBSD Driver Kit	6
2.3 Uninstalling the FreeBSD Driver Kit	6
2.4 Updating the FreeBSD Driver Kit	7
2.5 Checking the FreeBSD Driver Version	7
2.6 Loading and Unloading the Driver	7
Chapter 3: Configuration	8
3.1 NIC Driver Configuration	8
3.1.1 Kernel Module Parameters	8
3.1.2 Configuring TSO	8
3.1.3 Configuring LSO	8
3.1.4 Configuring Jumbo Frame Transmit	9
3.1.5 Configuring AIC	9
3.1.6 Configuring CARP	9
3.2 Viewing Device Driver Statistics	10
3.3 Updating the Firmware	10
3.4 Extracting an SFP Module's VPD Information	11

Chapter 1: Introduction

This document provides procedures for installing, uninstalling, updating, and configuring Broadcom® Emulex® supported FreeBSD network interface card (NIC) drivers.

1.1 Supported Versions and Adapters

This manual is applicable to several versions of FreeBSD NIC drivers, operating systems, firmware, and adapters.

For a list of supported FreeBSD operating systems and their associated Broadcom Emulex firmware and drivers, refer to the Broadcom website for the specific adapter.

The FreeBSD operating system supports the Broadcom Emulex OneConnect OCe11102 universal converged network adapter (UCNA), the LightPulse LPe16202 converged fabric adapter (CFA), and the OneConnect OCe14000-series converged network adapters (CNA). The driver and adapters support:

- Peripheral Component Interconnect Express (PCIe) bus standard (Generation 2 or later)
- Statistics – Ethernet statistics provided for the number of packets received and sent, and errors encountered
- Jumbo packets (greater than 1500 bytes)
- Virtual local area network (VLAN)
- Multicast – packets sent from a source to a group of destinations
- Receive side scaling (RSS) – load balancing on Rx traffic across multiple Rx queues
- TSO/LSO (TCP segmentation offload/large segment offload) – offloads Tx traffic to hardware to improve performance
- CSO (Checksum Offload) to hardware
- Bonding – Ethernet bonding across multiple ports for load balancing and fail-over
- PXE – Preboot eXecution Environment for network boot
- MSI-x – Message signal interrupts–extended
- Promiscuous mode – configuring an Ethernet interface to accept traffic from any destination
- Debugging capability

1.2 Abbreviations

AIC	Adaptive Interrupt Coalescing
CARP	Common Address Redundancy Protocol
CFA	Converged Fabric Adapter
CNA	Converged Network Adapter
CSO	Checksum Offload
LSO	Large Segment Offload
MSI-X	Message Signaled Interrupts-Extended
NIC	Network Interface Card (or Controller)
PCIe	Peripheral Component Interconnect Express
PXE	Preboot eXecution Environment
RSS	Receive Side Scaling
SFP	Small Form-factor Pluggable

TCP	Transmission Control Protocol
TSO	TCP Segmentation Offload
UCNA	Universal Converged Network Adapter
VHID	Virtual Host ID
VLAN	Virtual Local Area Network
VPD	Vital Product Data

Chapter 2: Installing and Uninstalling

This chapter provides installation and uninstallation instructions for the FreeBSD driver kit.

NOTE FreeBSD driver kit is available for FreeBSD 8.x and FreeBSD 9.x operating system versions only. Starting from FreeBSD 10.x versions, the driver is inbox only.

2.1 General Installation Requirements

Prior to driver installation, you must:

- Use a supported operating system. Refer to the Broadcom website for a list of supported FreeBSD operating systems.
- Install a supported adapter in the system. Refer to the adapter's installation manual for specific hardware installation instructions.
- Install the FreeBSD NIC driver on a dual-core (or better) server with Intel x86 or AMD64 architecture and MSI-X support.

2.2 Installing the FreeBSD Driver Kit

To install the FreeBSD driver kit:

1. Download the appropriate driver kit from the Broadcom website.
2. Log on as *root* and type:

```
pkg_add oce-<VERSION>-<ARCH>.tbz
```

For example:

```
pkg_add oce-11.0.50.0-freebsd93-amd64.tbz
```
3. Type:

```
echo 'oce_load="YES"' >> /boot/loader.conf
```
4. Extract the tbz driver package and copy the *oce.ko* file to the */boot/kernel/* directory.
5. Reboot the system.

2.3 Uninstalling the FreeBSD Driver Kit

To uninstall the FreeBSD driver kit:

1. Log on as *root* and type:

```
pkg_delete oce-<VERSION>-<ARCH>
```

For example:

```
pkg_delete oce-11.0.50.0-freebsd93-amd64
```
2. Remove the *oce_load="YES"* entry from the */boot/loader.conf* file.
3. Reboot the system.

2.4 Updating the FreeBSD Driver Kit

To update the FreeBSD driver:

1. Type:

```
pkg_update oce-<VERSION>-<ARCH>.tbz
```

For example:

```
pkg_update oce-11.0.50.0-freebsd93-amd64.tbz
```

2. Reboot the system.

2.5 Checking the FreeBSD Driver Version

To check the currently installed FreeBSD driver version:

1. Log on as *root*.

2. Type:

```
pkg_info | grep -i 'oce driver'
```

For example:

```
pkg_info | grep -i 'oce driver'
```

Output:

```
oce-11.0.50.0 oce driver for freebsd
```

2.6 Loading and Unloading the Driver

To load the kernel module, type:

```
kldload oce.ko
```

To unload the kernel module, type:

```
kldunload oce.ko
```

To verify that the driver loaded properly, type:

```
kldstat | grep oce
```

Chapter 3: Configuration

This chapter provides information on configuring the FreeBSD NIC driver, updating the firmware, and extracting the VPD information from an SFP module.

3.1 NIC Driver Configuration

This section lists the kernel module parameters and how to configure the FreeBSD NIC driver.

3.1.1 Kernel Module Parameters

Table 1 Kernel Module Parameters

Parameter	Description
max_rsp_handled	Default: 64 Allowed values: 1 to 1024 kenv name: hw.oce.max_rsp_handled sysctl name: dev.oceX.max_rsp_handled max_rsp_handled indicates the maximum number of received frames that are processed during a single receive frame interrupt.

3.1.2 Configuring TSO

TSO can be configured globally (affects all controllers in the system) or individually for Broadcom Emulex adapters.

To enable TSO globally, type:

```
sysctl net.inet.tcp.tso=1
```

To disable TSO globally, type:

```
sysctl net.inet.tcp.tso=0
```

To enable TSO for NIC interfaces only, type:

```
ifconfig oce<if_id> tso
```

To disable TSO for NIC interfaces only, type:

```
ifconfig oce<if_id> -tso
```

NOTE <if_id> is the interface identification number.

3.1.3 Configuring LSO

To enable LSO, type:

```
ifconfig oce<if_id> lso
```

To disable LSO, type:

```
ifconfig oce<if_id> -lso
```

NOTE <if_id> is the interface identification number.

3.1.4 Configuring Jumbo Frame Transmit

To enable Jumbo frames transmission, type:

```
ifconfig oce<if_id> mtu <mtu>
```

NOTE <if_id> is the interface identification number and <mtu> should be less than or equal to 9000.

3.1.5 Configuring AIC

NOTE AIC configuration is available on OneConnect OCe11102 and OCe14000-series adapters only.

To enable AIC, type:

```
sysctl dev.oce.<if_id>.aic_enable = 1
```

To disable AIC, type:

```
sysctl dev.oce.<if_id>.aic_enable = 0
```

3.1.6 Configuring CARP

NOTE CARP is supported in FreeBSD 10.0 and later only.

CARP enables multiple hosts to share the same IP address and VHID to provide high availability for one or more services. If one or more host servers fail, the other host servers will transparently continue operations so a service failure is not observed.

In addition to the shared IP address, each host server has its own IP address for management and configuration. All of the systems that share an IP address have the same VHID. The VHID for each virtual IP address must be unique across the broadcast domain of the network interface.

To enable boot-time support for CARP, you must add an entry for the `carp.ko` kernel module in `/boot/loader.conf` by typing:

```
carp_load="YES"
```

To immediately load the module without rebooting, type:

```
# kldload carp
```

The host name, management IP address, subnet mask, shared IP address, and VHID are all set by adding entries to `/etc/rc.conf`. This example is for `hosta.example.org`:

```
hostname="hosta.example.org"
ifconfig_em0="inet 192.168.1.3 netmask 255.255.255.0"
ifconfig_em0_alias0="vhid 1 pass testpass alias 192.168.1.50/32"
```

The next set of entries are for `hostb.example.org`. Since it represents a second main host server, it uses a different shared IP address and VHID. However, the passwords specified with `pass` must be identical, as CARP only responds to systems with the correct password.

```
hostname="hostb.example.org"
ifconfig_em0="inet 192.168.1.4 netmask 255.255.255.0"
ifconfig_em0_alias0="vhid 2 pass testpass alias 192.168.1.51/32"
```

The third system, `hostc.example.org`, is configured to handle failover from either of the main host servers. This system is configured with two CARP VHIDs – one to handle the virtual IP address for each of the main host servers. The

CARP advertising skew, `advskew`, is set to ensure that the backup host advertises later than the main host server, because `advskew` controls the order of precedence when there are multiple backup servers.

```
hostname="hostc.example.org"
ifconfig_em0="inet 192.168.1.5 netmask 255.255.255.0"
ifconfig_em0_alias0="vhid 1 advskew 100 pass testpass alias 192.168.1.50/32"
ifconfig_em0_alias1="vhid 2 advskew 100 pass testpass alias 192.168.1.51/32"
```

Having two CARP VHIDs configured enables `hostc.example.org` to recognize if either of the main host servers becomes unavailable. If a main host server fails to respond before the backup server, the backup server will pick up the shared IP address until the main host server becomes available again.

3.2 Viewing Device Driver Statistics

To view device driver statistics, type:

```
sysctl -a | grep oce
```

To view statistics for a single interface, type:

```
sysctl dev.oce.<if_id>
```

NOTE `if_id` can be any of the interface values that correspond to the Broadcom Emulex interfaces in the `ifconfig` output.

3.3 Updating the Firmware

NOTE For information on using the `Elxflash` management utility to update firmware, see the *Elxflash and LpCfg Management Utilities User Manual*.

To update the firmware:

1. Copy the following code to the makefile.

```
KMOD=elxflash
FIRMWS=imagename.ufi:elxflash
.include <bsd.kmod.mk>
```
2. Replace `imagename` in the copied code with the actual firmware file name. The format is `<filename>.ufi`.
3. Copy this makefile and the firmware file to a temporary directory.
4. Run `make` command in the directory. This generates an `elxflash.ko` file.
5. Copy the `elxflash.ko` file to `/boot/modules`.
6. Run the command:

```
sysctl dev.oce.<if_id>.fw_upgrade=elxflash
```

NOTE `<if_id>` can be any of the interface values that correspond to the Broadcom Emulex interfaces in the `ifconfig` output. If multiple Broadcom Emulex NIC adapters exist in the same system, the firmware download procedure must be repeated on one `<if_id>` for each adapter.

7. Check if the `sysctl` command execution for the firmware update was successful.
If it was successful, reboot the system. Otherwise, you should see one of the following error codes:

-
- "Invalid BE3 firmware image"
 - "Invalid Cookie. Firmware image corrupted?"
 - "cmd to write to flash rom failed."

If one of the messages above appears, verify that you have the latest firmware update by checking the Broadcom website and then attempt to update the firmware again. If you continue to have issues, contact your Broadcom Technical Support representative.

3.4 Extracting an SFP Module's VPD Information

To dump an SFP module's VPD:

1. Trigger the dump by typing

```
sysctl dev.oce.<if_id>.sfp_vpd_dump=0
```
2. Choose one of the following dump options:
 - For a hexadecimal dump, type:

```
sysctl -x dev.oce.<if_id>.sfp_vpd_dump_buffer
```
 - For a binary dump, type:

```
sysctl -b dev.oce.<if_id>.sfp_vpd_dump_buffer > <filename>
```

where <filename> is the file into which the output should be redirected.

For example:

```
sysctl -b dev.oce.<if_id>.sfp_vpd_dump_buffer > sfp.bin
```

