



MegaRAID®
Advanced Software Options
Electronic License Activation
User Guide

48343-00, Rev. A
September 2010

Revision History

Version and Date	Description of Changes
48343-00 Rev. A, September 2010	Initial release of document.

LSI and the LSI logo are trademarks or registered trademarks of LSI Corporation or its subsidiaries. All other brand and product names may be trademarks of their respective companies.

This preliminary document describes a preproduction product and contains information that may change substantially for any final commercial release of the product. LSI Corporation makes no express or implied representation or warranty as to the accuracy, quality, or completeness of information contained in this document, and neither the release of this document nor any information included in it obligates LSI Corporation to make a commercial release of the product. LSI Corporation reserves the right to make changes to the product(s) or information disclosed herein at any time without notice. LSI Corporation does not assume any responsibility or liability arising out of the application or use of any product or service described herein, except as expressly agreed to in writing by LSI Corporation; nor does the purchase, lease, or use of a product or service from LSI Corporation convey a license under any patent rights, copyrights, trademark rights, or any other of the intellectual property rights of LSI Corporation or of third parties.

Corporate Headquarters
Milpitas, CA
800-372-2447

Website
www.lsi.com

Document Number: 48343-00 Rev. A
Copyright © 2010 LSI Corporation
All Rights Reserved

Table of Contents

Chapter 1: MegaRAID® Advanced Software Options Electronic License Activation	5
1.0 Getting Started	5
2.0 Purchase Order and LAC Letters/Certificates	5
3.0 Activating the LAC in the License Activation Portal for New Users	6
4.0 Activating the LAC in the License Activation Portal for Registered Users	10
5.0 Enabling Software Options in MegaRAID Storage Manager with Activation Key	13
Appendix A: Finding the Serial Number and the Safe ID for Your RAID Controller	19
Appendix B: Supported MegaRAID Controllers for Advanced Software Licenses	21

User Guide

MegaRAID Advanced Software Options Electronic License Activation

This guide is for users who need to install and activate the LSI Advanced Software options on MegaRAID controllers using the MegaRAID® Advanced Software License Portal. This process assumes that you have already purchased the Advanced Software options through your distributor or reseller and have received a License Authorization Code (LAC).

To install and activate the LSI Advanced Software options on your MegaRAID controller using the MegaRAID Advanced Software License Portal, you must have the following MegaRAID firmware version and MegaRAID Storage Manager® (MSM) version *or later* installed on your RAID controller:

- MegaRAID Firmware version:
 - 12.11.0-0010: For MegaRAID SAS 9260-4i, 9260-8i, 9261-8i, 9280-4i4e, 9280-8e
 - 12.11.0-0011: For MegaRAID SAS 9260-16i, 9280-16i4e, 9280-24i4e
- MegaRAID Storage Manager version 8.10-02:
 - For all supported controllers listed in Appendix B, [Supported MegaRAID Controllers for Advanced Software Licenses](#).

1.0 Getting Started

The LSI Advanced Software licensing process consists of the following procedures:

1. Purchase LSI Advanced Software Option(s) and receive a License Authorization Code letter or License Authorization Code certificate that entitles you to one or more advanced software options.
2. Use the License Activation Portal to activate the LAC and receive a License Activation Key to enable your software.

If you are a new user, use [Section 3.0, Activating the LAC in the License Activation Portal for New Users](#). If you are already a registered user, use [Section 4.0, Activating the LAC in the License Activation Portal for Registered Users](#).

3. Enable the software on your MegaRAID controller card by entering the Activation Key in MSM.

The following sections describe these procedures in more detail.

2.0 Purchase Order and LAC Letters/Certificates

After you purchase an LSI Advanced Software license, you receive your License Authorization Code (LAC) in an email from your distributor or your reseller in a LAC letter. The LAC letter contains the following items:

- A LAC
- A list of the products ordered
- The product part numbers
- Instructions on how to redeem the LAC for an activation key

3.0 Activating the LAC in the License Activation Portal for New Users

If you are already a registered user, and need to activate the LAC and create an Activation Confirmation Letter, follow these steps.

1. Go to the LSI Advanced Software License Management Portal at <http://softwarelicense.lsi.com>.

The portal login shown in the following figure appears.



Welcome to the LSI Advanced Software License Management Portal

Your license authorization code (LAC) is printed on the LAC letter or LAC certificate that you received. To convert this LAC into an Activation Key that can enable your Software, please log in or enter your LAC below.

Returning users: * Email Address <input type="text"/> * Password <input type="password"/> <input type="button" value="Log In"/> Forgot My Password	New users: * LAC <input type="text"/> <input type="button" value="Create Account"/>
---	---

Figure 1: Product Activation Login Screen

2. As a new user, enter your LAC in the **New users** section and click **Create Account**, as shown in the following figure.



Welcome to the LSI Advanced Software License Management Portal

Your license authorization code (LAC) is printed on the LAC letter or LAC certificate that you received. To convert this LAC into an Activation Key that can enable your Software, please log in or enter your LAC below.

Returning users: * Email Address <input type="text"/> * Password <input type="password"/> <input type="button" value="Log In"/> Forgot My Password	New users: * LAC <input type="text"/> LAC12345678901234567890 <input type="button" value="Create Account"/>
---	---

Figure 2: New User Login with LAC

The LAC you enter on the login screen appears on the **Product Activation** screen, shown in the following figure.




Figure 3: Product Activation Screen

3. Click **Activate**.

A login dialog box appears, as shown in the following figure.



Figure 4: Register as New User

4. Under the heading **Register as a new user**, fill out the fields **User Name** and **Email Address**.
5. Click **Submit**.

A new user registration dialog box appears, as shown in the following figure.




Figure 5: New User Registration Form


6. Fill out the **New User Registration** form and click **Save**.

The **Add RAID Controller** screen appears, as shown in the following figure.

**Figure 6: Add RAID Controller**


7. Enter the name of the RAID controller for which the Advanced Software Option(s) will be activated and enabled, and click **Save**.

The Activate LACs on RAID Controller screen appears, as shown in the following figure.

**Figure 7: Activate LACs on RAID Controller**

8. Enter the RAID controller **Serial Number** and **Safe ID**, as shown in the following figure, and click **Next**.

See Appendix A, [Finding the Serial Number and the Safe ID for Your RAID Controller](#), for instructions on how to find the controller serial number and the Safe ID.

**Figure 8: Enter Serial Number and Safe ID**

The Software License Agreement appears, as shown in the following figure.




Figure 9: Read and Accept Software License Agreement

9. Read and accept the Software License Agreement, and then click **Finish**.

The LAC activation is now complete. The Activation Confirmation Letter is automatically sent to the registered user. In addition, you can view the letter on the summary page, as shown in the following figure. You can now use the Activation Key to enable software on your RAID controller using MSM.




Figure 10: Activation Complete Summary Screen

4.0 Activating the LAC in the License Activation Portal for Registered Users

To activate the LAC and create an Activation Confirmation Letter, follow these steps.

1. Go to the LSI Advanced Software License Management Portal at <http://softwarelicense.lsi.com>.

The portal login shown in the following figure appears.



Welcome to the LSI Advanced Software License Management Portal

Your license authorization code (LAC) is printed on the LAC letter or LAC certificate that you received. To convert this LAC into an Activation Key that can enable your Software, please log in or enter your LAC below.

Returning users: * Email Address <input type="text"/> * Password <input type="password"/> <input type="button" value="Log In"/> Forgot My Password	New users: * LAC <input type="text"/> <input type="button" value="Create Account"/>
--	--

Figure 11: Product Activation Login Screen

2. As a registered user, enter your email address and your password in the **Returning users** section and click **Log In**, as shown in the following figure.



Welcome to the LSI Advanced Software License Management Portal

Your license authorization code (LAC) is printed on the LAC letter or LAC certificate that you received. To convert this LAC into an Activation Key that can enable your Software, please log in or enter your LAC below.

Returning users: * Email Address <input type="text" value="runner@acme.com"/> * Password <input type="password" value="*****"/> <input type="button" value="Log In"/> Forgot My Password	New users: * LAC <input type="text"/> <input type="button" value="Create Account"/>
--	--

Figure 12: Registered User Login

The **Product Activation** screen displays, as shown in the following figure.

3. On the **Product Activation** screen, enter the LAC and then click **Activate**.





Figure 13: Product Activation Screen

On the **Search or Add RAID Controllers** screen (Figure 14), you can choose to add a new RAID controller (as described in the **New User** steps) or select a previously registered/named RAID controller to activate software on (shown here).

4. Find or search for the desired RAID controller in the **RAID Controller Name** field on the following screen and click **Select**.


Figure 14: Search or Add RAID Controllers

When you select a previously registered RAID Controller, the Serial Number and Safe ID on the Activate LACs on RAID Controller screen is automatically populated, as shown in the following figure.

**Figure 15: Activate LACs on RAID Controller**

5. Confirm the chosen controller and select **Next**.

The Software License Agreement appears, as shown in the following figure.

**Figure 16: Read and Accept Software License Agreement**

6. Read and accept the software license agreement, and then click **Submit**.

The LAC activation is now complete. The Activation Confirmation Letter is automatically sent to the registered user or you can view it from the summary page, as shown in the following figure. You can now use the Activation Key to enable software on their RAID controller using MegaRAID Storage Manager™.




Figure 17: Activation Complete Summary Screen

5.0 Enabling Software Options in MegaRAID Storage Manager with the Activation Key

To enable the purchased software options on your registered RAID controller within MegaRAID Storage Manager, follow these steps.

1. Open MegaRAID Storage Manager.

The Dashboard panel on the MSM main menu screen appears, as shown in the following figure.




Figure 18: MegaRAID Advanced Software Options Menu

2. Perform one of the following steps.

- Select **Go to>>Controller>>Manage Advanced Software Options** from the menu bar.

- b. Click the **Manage Advanced Software Options** link from Dashboard under Action Portal.

The following screen appears.




Figure 19: Manage MegaRAID Advanced Software Options Screen

3. Click **Activate**.

The Method dialog box appears, as shown in the following figure. Use this screen to enter the Activation Key that you received by email and/or saved to file on the License Activation Portal.




Figure 20: Activation Method Dialog Box

4. Perform one of the following steps.
 - a. Enter your activation key manually in the **Enter an Activation Key** field.
 - b. Upload the **.XML** file that you saved during activation by using the **Select an Activation Key file** field.
5. Click **Next**.

This action opens the summary screen shown in the following figure. This screen lists all of the Advanced Software options that are enabled or that will be enabled after these steps are complete.




Figure 21: MegaRAID Advanced Software Options Summary Page

6. If you are satisfied with the summary, click **Finish**. To make any changes on the previous screens, click **Back**.

Appendix A

Finding the Serial Number and the Safe ID for Your RAID Controller

The Serial Number and the Safe ID are required for you to activate the License Authorization Code (LAC).

To obtain the Serial Number and the Safe ID required for LAC activation, perform the following steps.

1. Open MegaRAID Storage Manager.

The **Dashboard** panel on the MSM main menu screen appears, as shown in the following figure.




Figure 22: MegaRAID Advanced Software Options Menu

2. Perform one of the following steps.
 - a. Select **Go to>>Controller->Manage MegaRAID Advanced Software Options** from the menu bar.
 - b. Click the link **Manage MegaRAID Advanced Software Options** from Dashboard under the Action Portal.

The **Manage MegaRAID Advanced Software Options** screen appears, as shown in the following figure.




Figure 23: Manage MegaRAID Advanced Software Options Screen

The Safe ID and Serial Numbers are listed here. You can copy and paste these identifier characters into the License Activation Portal.

See [Section 3.0, Activating the LAC in the License Activation Portal for New Users](#) and [Section 4.0, Activating the LAC in the License Activation Portal for Registered Users](#) for the procedures used to activate the LAC in the License Activation Portal.

Appendix B

Supported MegaRAID Controllers for Advanced Software Licenses

The following table lists the MegaRAID controllers and the Advanced Software options that they support.

Table 1: Supported RAID Controllers for Advanced Software Options Activated by Electronic License*

MegaRAID Controller	MegaRAID CacheCade™ Software License	MegaRAID FastPath™ Software License	MegaRAID Recovery Software License	MegaRAID SafeStore™ Software License
MegaRAID SAS 9260-4i	X	X	X	X
MegaRAID SAS 9260-8i	X	X	X	X
MegaRAID SAS 9261-8i	X	X	X	X
MegaRAID SAS 9260-16i	X	X	X	X
MegaRAID SAS 9280-4i4e	X	X	X	X
MegaRAID SAS 9280-8e	X	X	X	X
MegaRAID SAS 9280-16i4e	X	X	X	X
MegaRAID SAS 9280-24i4e	X	X	X	X

*This table shows support for Advanced Software Options enabled by electronic license. It does not indicate support for Advanced Software enabled by a physical/hardware key that is attached to the RAID controller card.

Appendix C

Glossary

Activation Confirmation Letter	The letter or email that you use after you complete the product activation process on the Activation Portal. This letter contains the activation key, corresponding software product name, and instructions on how to use the key to enable your advanced software on your MegaRAID controller using MegaRAID Storage Manager (MSM).
Activation Key	The advanced software activation code that is presented in the form of a 40-digit alphanumeric string or an XML file. This key is used to activate the applicable software on the MegaRAID controller card using MegaRAID Storage Manager.
Entitlement	A commitment of future value made to a customer or partner and delivered in the form of a License Authorization Code (LAC) for a software license.
LAC Certificate	A paper certificate with the license authorization code that is sent by mail by LSI to the customer. This certificate is not ordered through the License Procurement Portal; it is ordered through standard ordering process (PO to LSI for distributors; PO to distributors for System integrators, VARs, etc). This certificate contains a LAC, a list of the products ordered, their part numbers, instructions on how to redeem the LAC for an activation key, and instructions on how to enable the software using MegaRAID Storage Manager.
LAC Letter	A letter with the license authorization codes that is sent by email by LSI to a customer after they have procured or generated an order for advanced software options on the License Procurement Portal. This letter contains a LAC, a list of the products ordered, their part numbers, instructions on how to redeem the LAC for an activation key, and instructions on how to enable the software using MegaRAID Storage Manager.
License Activation Portal	A part of the License Management Portal where users (Distributors, VARs, Sis, End users) can generate activation keys based on their License Identifier(s), as well as store and manage all key activations.
License Authorization Code (LAC)	A unique 24-character alphanumeric code that identifies the licenses purchased by the customer. This license authorization code is used to link the purchased advanced software option with the activation key for a given MegARAID controller.
License Procurement Portal	A part of the License Management Portal where distributor partners can electronically procure or generate one or more advanced software licenses.
LSI Advanced Software License Management Portal	An electronic license fulfillment portal and web application that includes license procurement and license activation management functions.
MegaRAID Advanced Software License Management Portal User Guide	A complete user guide with instructions on how to activate license authorization codes, find information like Safe ID and Serial Number, and how to enable software with activation key in MSM.
MegaRAID Advanced Software Options	Software options that enhance performance and provide advanced data management and protection for customers employing 6Gb/s MegaRAID SATA+SAS controller cards.

Safe ID A 40-digit encrypted alphanumeric string that binds the license to a specific controller. This information is required during the license activation process and can be found in MSM under the Manage Advanced Software Options link.

Serial Number A unique, identifying group of numbers and letters assigned by LSI to each individual RAID controller card.

