



Broadcom® 95xx PCIe 4.0 MegaRAID™ and HBA Tri-Mode Storage Adapters

User Guide
Version 2.15

Copyright © 2018–2026 Broadcom. All Rights Reserved. The term “Broadcom” refers to Broadcom Inc. and/or its subsidiaries. For more information, go to www.broadcom.com. All trademarks, trade names, service marks, and logos referenced herein belong to their respective companies.

Broadcom reserves the right to make changes without further notice to any products or data herein to improve reliability, function, or design. Information furnished by Broadcom is believed to be accurate and reliable. However, Broadcom does not assume any liability arising out of the application or use of this information, nor the application or use of any product or circuit described herein, neither does it convey any license under its patent rights nor the rights of others.

Table of Contents

Broadcom PCIe 4.0 MegaRAID and HBA Tri-Mode Storage Adapters.....	5
Overview.....	5
Features.....	7
RAID Features.....	7
Operating System Support.....	7
PCIe Host Interface.....	8
LED Management.....	8
Tri-Mode Storage Interface Features.....	8
Tri-Mode Storage Interface.....	10
SAS/SATA Support.....	10
PCIe (NVMe) Support.....	11
Common REFCLK and PERST# Support.....	12
Backplane Management.....	13
Universal Backplane Management.....	13
Virtual Pin Port Management.....	13
Sideband Signals.....	13
Cables and Cabling Configurations.....	16
Storage Interface Cabling.....	17
Backplane Connectors.....	18
External Adapter Connector Pinout.....	18
CacheVault Data Protection.....	20
Adapter Security.....	21
Adapter Installation Instructions.....	22
Adapter Installation.....	22
OCP Adapter Installation.....	24
Removing the OCP Adapter.....	25
M.2 Adapter Installation Instructions.....	26
Broadcom MegaRAID and HBA Tri-Mode Storage Adapter Characteristics.....	27
MegaRAID 9560-16i Adapter: Connector and LED Designations.....	27
MegaRAID 9560-8i Adapter: Connector and LED Designations.....	28
MegaRAID 9580-8i8e Adapter: Connector and LED Designations.....	30
MegaRAID 9540-8i Adapter: Connector and LED Designations.....	31
MegaRAID 9520-8i Adapter: Connector and LED Designations.....	33
MegaRAID 9524-8i Adapter: Connector and LED Designations.....	34
MegaRAID 9562-16i Adapter: Connector and LED Designations.....	35

HBA 9500-16i Adapter: Connector and LED Designations	37
HBA 9500-8i Adapter: Connector and LED Designations	38
HBA 9500-16e Adapter: Connector and LED Designations	40
HBA 9500-8e Adapter: Connector and LED Designations	41
HBA 9502-16i Adapter: Connector and LED Designations	42
Tri-Mode Storage Adapter Technical Specifications	44
Board Storage Conditions.....	44
Board Weights.....	44
Board Operating Conditions.....	45
Power Supply Requirements.....	45
MegaRAID Tri-Mode Storage Adapter Power Supply Requirements.....	45
HBA Tri-Mode Storage Adapter Power Supply Requirements.....	46
MegaRAID and HBA Tri-Mode OCP Adapter Power Supply Requirements.....	46
Marks, Certifications, Compliance, and Safety Characteristics	47
Marks, Certifications, and Compliance.....	47
FCC Compliance.....	48
Safety Characteristics.....	49
VCCI – Japan.....	49
Taiwan BSMI Compliance.....	49
Appendix A: Cable Drawings and Pinouts	50
Cable 05-60001-00.....	50
Cable 05-60002-00.....	52
Cable 05-60003-00.....	53
Cable 05-60004-00.....	54
Cable 05-60005-00.....	55
Cable 05-60006-00.....	56
Cable 05-60007-00.....	58
Cable 05-60009-00.....	59
Appendix B: Revision History	60

Broadcom PCIe 4.0 MegaRAID and HBA Tri-Mode Storage Adapters

This document is the primary reference and user guide for the Broadcom® PCIe 4.0 MegaRAID™ tri-mode storage adapters and Broadcom PCIe 4.0 HBA tri-mode storage adapters, based on the Broadcom PCIe 4.0 tri-mode controller devices. This document contains the complete installation instructions and specifications for the following PCIe 4.0 tri-mode storage adapters, referred to as adapters:

- MegaRAID 9560-16i
- MegaRAID 9560-8i
- MegaRAID 9580-8i8e
- MegaRAID 9540-8i
- MegaRAID 9520-8i
- MegaRAID 9524-8i
- MegaRAID 9562-16i
- HBA 9500-16i
- HBA 9500-8i
- HBA 9500-16e
- HBA 9500-8e
- HBA 9502-16i

Overview

The adapters, based on the SAS3916, SAS3908, SAS3816, SAS3808, or SAS3808N tri-mode controller, are high-performance PCIe-to-SATA/SAS/PCIe (tri-mode) storage adapters. Broadcom tri-mode SerDes technology enables operation of SAS, SATA, or PCIe (NVMe) storage devices in a single drive bay. A single controller can operate in all three modes concurrently: SAS, SATA, and PCIe/NVMe. The adapters negotiate between the speeds and the protocols to recognize and concurrently interface with these three storage devices types.

The adapters provide the following storage interface data transfer rates:

- SAS data transfer rates of 12Gb/s, 6Gb/s, and 3Gb/s per phy
- SATA transfer rates at 6Gb/s and 3Gb/s per phy
- PCIe (NVMe) data transfer rates of 16 GT/s, 8 GT/s, 5 GT/s, and 2.5 GT/s per lane

The following tables summarize key adapter features.

Table 1: MegaRAID Tri-Mode Storage Adapter (with DDR) Features

Adapter	9560-16i	9560-8i	9580-8i8e	9562-16i
Ports	16 internal	8 internal	8 internal, 8 external	16 internal
I/O Processor	SAS3916	SAS3908	SAS3916	SAS3916
Form Factor	LP-MD2	LP-MD2	LP-MD2	OCP NIC 3.0 SFF
Storage Interface Connectors	Two SFF-8654 x8	One SFF-8654 x8	One SFF-8654 x8, Two SFF-8644 x4	Two SFF-8654 x8 (vertical)
Host Interface	x8 PCIe 4.0	x8 PCIe 4.0	x8 PCIe 4.0	x8 PCIe 4.0

Adapter	9560-16i	9560-8i	9580-8i8e	9562-16i
Storage Interface	SAS, SATA, and PCIe (NVMe)			
RAID Level Support	00, 0, 1, 5, and 6			
RAID Span Support	10, 50, and 60			
Cache Memory	8 GB, 2666 MT/s, DDR4 SDRAM	4 GB, 2666 MT/s, DDR4 SDRAM	8 GB, 2666 MT/s, DDR4 SDRAM	8 GB, 2666 MT/s, DDR4 SDRAM
Cache Protection	Yes	Yes	Yes	Yes
Super Capacitor	CVPM05 module	CVPM05 module	CVPM05 module	CVPM05 module

Table 2: MegaRAID Tri-Mode Storage Adapter (without DDR) Features

Adapter	9540-8i	9520-8i	9524-8i
Ports	8 internal	8 internal	8 internal
I/O Processor	SAS3808	SAS3808	SAS3808N
Form Factor	LP-MD2	LP-MD2	M2
Storage Interface Connectors	One SFF-8654 x8	One SFF-8654 x8	One SFF-8654 x8
Host Interface	x8 PCIe 4.0	x8 PCIe 4.0	x4 PCIe 4.0
Storage Interface	SAS, SATA, and PCIe (NVMe)	SAS, SATA, and PCIe (NVMe)	SAS, SATA, and PCIe (NVMe)
RAID Level Support	0, 1	0, 1	0, 1
RAID Span Support	10	10	10
Requires Reserved Memory Region Reporting (RMRR)	Yes	No	No

Table 3: HBA Tri-Mode Storage Adapter Features

Adapter	9500-16i	9500-8i	9500-16e	9500-8e	9502-16i
Ports	16 internal	8 internal	16 external	8 external	16 internal
I/O Processor	SAS3816	SAS3808	SAS3816	SAS3808	SAS3816
Form Factor	LP-MD2	LP-MD2	LP-MD2	LP-MD2	OCP NIC 3.0 SFF
Storage Interface Connectors	Two SFF-8654 x8	One SFF-8654 x8	Four SFF-8644 x4	Two SFF-8644 x4	Two SFF-8654 x8 (vertical)
Host Interface	x8 PCIe 4.0	x8 PCIe 4.0	x8 PCIe 4.0	x8 PCIe 4.0	x8 PCIe 4.0
Storage Interface	SAS, SATA, and PCIe (NVMe)	SAS, SATA, and PCIe (NVMe)	SAS, SATA, and PCIe	SAS, SATA, and PCIe	SAS, SATA, and PCIe (NVMe)

Features

This chapter describes the features that the adapters support.

RAID Features

The following list includes primary RAID features that the MegaRAID adapters support. For a full description of the RAID features, refer to the *12Gb/s MegaRAID Tri-Mode Software User Guide*, located at [Support Documents and Downloads](#).

- JBOD for SDS environments
- Online Capacity Expansion (OCE)
- Auto resume after loss of system power during array rebuild or OCE
- Single controller multipathing
- Load balancing
- Configurable stripe size up to 1 MB
- Fast initialization for quick array setup
- Check Consistency for background data integrity
- SSD support with SSD Guard™ technology
- Patrol read for media scanning and repairing
- Disk data format (DDF)-compliant Configuration on Disk (COD)
- Self-Monitoring, Analysis, and Reporting Technology (S.M.A.R.T) support
- Global and dedicated hot spare with revertible hot spare support
- Automatic rebuild
- Enclosure affinity
- Emergency SATA hot spare for SAS arrays
- Enclosure management
- SCSI Enclosure Services (SES) (inband)
- SGPIO (sideband)
- DataBolt bandwidth optimizer technology support for compatible expander-based enclosures
- Shield state drive diagnostic technology

Operating System Support

The tri-mode storage adapters support the operating systems in the following list.

For specific version information, refer to the *MegaRAID Tri-Mode Device Driver Installation User Guide*, which you can download from [Support Documents and Downloads](#).

- Microsoft Windows
- VMware vSphere®/ESXi
- Red Hat Enterprise Linux
- SuSE Linux
- Ubuntu Linux
- Citrix XenServer
- CentOS Linux
- Debian Linux
- Oracle Enterprise Linux
- Fedora
- FreeBSD

Firmware and drivers are routinely updated. Visit the Broadcom [Support Documents and Downloads](#) page to download the latest firmware and driver for the adapter.

PCIe Host Interface

The adapter's PCIe 4.0 host interface provides maximum transmission and reception rates of up to 16 GT/s per lane. The tri-mode controller uses a packet-based communication protocol to communicate over the serial interconnect. The following list shows other PCIe host interface features:

- Eight-lane PCIe host interface
- PCIe hot plug
- Power management:
 - Supports the *PCI Bus Power Management Interface Specification Revision 1.2*
 - Supports Active State Power Management, including the L0 states, by placing links in a power-saving mode during times of no link activity
- Error handling
- High bandwidth per pin, with low overhead and low latency
- Lane reversal and polarity inversion
- Single-phy (one-lane) link transfer rate of 16 GT/s, 8 GT/s, 5 GT/s, and 2.5 GT/s in each direction
- Support for x8, x4, x2, and x1 link widths

LED Management

Support for managing Broadcom adapter LEDs differs between internal and external connecting adapters.

The internal adapters offer LED management support for SAS/SATA backplanes and (PCIe) NVMe backplanes. External connect adapters offer enclosure LED management support for enclosure implementations through SES. See [Backplane Management](#) for more information.

Tri-Mode Storage Interface Features

The adapter's storage interface supports concurrent operation with SAS, SATA, and PCIe (NVMe) devices to provide a fully functional solution for any storage environment:

- PCIe (NVMe) interface features:

- Up to sixteen x1, eight x2, or four x4 NVMe direct-attach drive support
- Data transfer at 16 GT/s, 8 GT/s, 5 GT/s, and 2.5 GT/s
- Independent resets and configuration
- Common reference clock and separate reference clock with independent SSC (SRIS) support
- Lane reversal and polarity inversion
- SAS features:
 - SAS data transfers at 12Gb/s, 6Gb/s, and 3Gb/s
 - DataBolt technology on all SAS phys to improve performance
 - Serial, point-to-point, enterprise-level storage interface
 - Wide ports that contain multiple phys
 - Narrow ports that contain a single phy
 - SAS phy power management
 - Data transfer by using SCSI information units
 - T10 data protection management
 - Support for persistent connection capability
 - Support for SPL-3 initiate close capability
 - Configurable Rx and Tx polarity inversion
 - Configurable phy-to-disk mapping
 - Configurable SSC
- SATA interface features:
 - SATA and STP data transfers at 6Gb/s and 3Gb/s
 - Addressing of multiple SATA targets through an expander

Tri-Mode Storage Interface

The internal adapters can direct attach to SAS, SATA, or NVMe drives. The internal and external adapters support drive attach through PCIe switches or expanders.

NOTE

Carefully assess any decision to mix SAS and SATA drives within the same virtual drive (VD). Although you can mix drives, the practice is discouraged.

MegaRAID does not permit mixing SAS and NVMe drives or SATA and NVMe drives within the same VD. To mix NVMe and SAS/SATA drives on a MegaRAID adapter, you must configure the drives in separate VDs.

SAS/SATA Support

The adapters support internal and external storage devices, which allow you to use a system that supports enterprise-class SAS drives and desktop-class SATA III drives.

The storage interface is comprised of either 16 phys or 8 phys, depending on the controller. Dedicated hardware manages the phys in groups of eight, in ascending phy order. One dedicated instance of the SAS phy management hardware manages PHY 0 to PHY 7, and a separate instance of the SAS phy management hardware manages PHY 8 to PHY 15. These SAS phy management hardware instances, or SAS cores, cannot communicate with each other.

When you configure a wide port, the connections must attach exclusively to phys all managed by the same SAS core. If the ports are not managed by the same SAS core, unexpected controller and host behavior occurs. Port 0 to port 7 can be configured as eight separate ports or combined into one or more groups called wide ports (one x4, two x4s, one x8, and so on). Similarly, port 8 to port 15 can be configured as eight separate ports or combined into one or more wide ports. A single wide port cannot combine individual ports or phys sourced by different SAS cores.

The following table indicates the connector-to-SAS core mapping for each adapter. The card layout figures in [Broadcom MegaRAID and HBA Tri-Mode Storage Adapter Characteristics](#) show the connector designations for each adapter.

Table 4: Adapter Port-to-SAS Port Associations

Adapter	Connector 0	Connector 1	Connector 2	Connector 3
9560-16i	SAS Core 0	SAS Core 1	N/A	N/A
9560-8i	SAS Core 0	N/A	N/A	N/A
9580-8i8e	SAS Core 1	SAS Core 0	SAS Core 0	N/A
9540-8i	SAS Core 0	N/A	N/A	N/A
9520-8i	SAS Core 0	N/A	N/A	N/A
9524-8i	SAS Core 0	N/A	N/A	N/A
9562-16i	SAS Core 0	SAS Core 1	N/A	N/A
9500-16i	SAS Core 0	SAS Core 1	N/A	N/A
9500-8i	SAS Core 0	N/A	N/A	N/A
9500-16e	SAS Core 0	SAS Core 0	SAS Core 1	SAS Core 1
9500-8e	SAS Core 0	SAS Core 0	N/A	N/A
9502-16i	SAS Core 0	SAS Core 1	N/A	N/A

When you configure a boot device in a multipath environment, the target must connect to one or more ports on the same SAS core with AutoPortConfig enabled. The boot device appears to the host system as a single device on the active path. The multipath environment manages a different controller as the passive path.

When you configure data-storage devices in a multipath environment, the rule for creating wide ports applies, but multiple ports from different SAS cores can connect to the data-storage devices. The multipath environment manages data-storage devices that the controller presents more than once.

PCIe (NVMe) Support

The following table shows how many NVMe drives or Broadcom PEX88000-series switches can directly attach to each adapter. The HBA 9500-16e and HBA 9500-8e adapters do not support direct attach to NVMe drives. The expected topology for the HBA 9500-16e and HBA 9500-8e adapters is a typical JBOF scenario that uses a switch to connect the NVMe drives.

The adapters do not support switch connections wider than x4 and one level deep.

Table 5: NVMe Devices or PCIe Switch Direct-Attach Options Supported for Each Adapter

Adapter	x4 NVMe Drives	x2 NVMe Drives	x1 NVMe Drives	x4 Switch
9560-16i	4	8	16	4
9560-8i	2	4	8	2
9580-8i8e	2	4	8	4
9540-8i	2	4	4	0
9520-8i	2	2	2	0
9524-8i	2	2	2	0
9562-16i	4	8	16	4
9500-16i	4	8	16	4
9500-8i	2	4	8	2
9500-16e	0	0	0	4
9500-8e	0	0	0	2
9502-16i	4	8	16	4

The tri-mode device interface contains a SAS core and a PCIe device bridge (PDB). The PDB enables the PCIe (NVMe) storage interface connections, and each PDB can support direct connect to NVMe devices or to x4 PCIe switches. The storage interface is comprised of 16 phys or 8 phys depending on the controller. One PDB manages PHY 0 to PHY 7, and a second PDB manages PHY 8 to PHY 15. The PDBs cannot communicate with each other. This means that a PCIe port of greater than one lane must attach exclusively to phys all managed by the same PDB and must be comprised of adjacent lanes.

The following table indicates how the connectors map to the PDB for each adapter. The card layout figures in [Broadcom MegaRAID and HBA Tri-Mode Storage Adapter Characteristics](#) show the connector designations for each adapter.

Table 6: Adapter Lanes-to-PDB Core Associations

Adapter	Connector 0	Connector 1	Connector 2	Connector 3
9560-16i	PDB 0	PDB 1	N/A	N/A
9560-8i	PDB 0	N/A	N/A	N/A

Adapter	Connector 0	Connector 1	Connector 2	Connector 3
9580-8i8e	PDB 1	PDB 0	PDB 0	N/A
9540-8i	PDB 0	N/A	N/A	N/A
9520-8i	PDB 0	N/A	N/A	N/A
9524-8i	PDB 0, PDB 1	N/A	N/A	N/A
9562-16i	PDB 0	PDB 1	N/A	N/A
9500-16i	PDB 0	PDB 1	N/A	N/A
9500-8i	PDB 0	N/A	N/A	N/A
9500-16e	PDB 0	PDB 0	PDB 1	PDB 1
9500-8e	PDB 0	PDB 0	N/A	N/A
9502-16i	PDB 0	PDB 1	N/A	N/A

Common REFCLK and PERST# Support

Each x8 connector is divided into two quadrants. Each quadrant includes one REFCLK and one PERST# signal.

When using x4 NVMe drives that require a common REFCLK, the REFCLK sourced by each quadrant directly clocks each attached x4 drive. When using x2 or x1 NVMe drives that require a common REFCLK, where more than one drive is sourced from a single quadrant, you must properly fan out the shared REFCLK on the backplane. To avoid fanning out the REFCLK on the backplane, use SRIS enabled x2 or x1 drives.

Similar to REFCLK, one PERST# is sourced per quad. To directly attach x2 or x1 NVMe drives, you must properly fan out PERST# on the backplane.

Backplane Management

Use the information in this chapter to set up the adapter's backplane management options.

The SFF-8448 standard defines how to detect whether the backplane supports an SGPIO or two-wire interface (I^2C) for SAS/SATA usage. SFF-9402 is a superset of SFF-8448, adding the PCIe-defined sideband signal, which means that SAS/SATA users see no change in backplane management detection when using the adapters.

Universal Backplane Management

The adapters provide LED operation and other backplane management of NVMe only, SAS/SATA only, or mixed-protocol backplanes based on the SFF-TA-1005 specification.

SFF-TA-1005 is an industry-standard backplane management specification commonly known as UBM. As long as the backplane management controller is designed in accordance with the UBM specification, the adapter automatically detects the backplane type and functions appropriately.

The adapter supports the industry-standard *SFF-TA-1005 Specification for Universal Backplane Management (UBM)*. UBM provides the following key features:

- Reports the following backplane capabilities:
 - NVMe drive widths
 - Common REFCLK or separate REFCLK support
 - Maximum speeds
 - Designed slot power
- Supports cable order independence, that is, the drive LED control and slot ID are not dependent on cable order.
- Enables drive hot-plug insertion through control of PERST# timing.

For existing SAS/SATA backplanes, if BP_TYPE = 0, the adapter uses SGPIO for legacy backplane management. Refer to the SFF-8485 specification for functionality details. Design new backplanes with the industry-standard SFF-TA-1005 (UBM) specification for backplane management.

Virtual Pin Port Management

Broadcom requires new designs to enable UBM for backplane management.

The adapter maintains support for VPP backplane management for legacy implementations. The adapters provide LED operation for NVMe devices based on the VPP over I^2C definition. Standard VPP implementation calls for one PCA9555 target per two devices. For each drive pair, the adapter expects to see one PCA9555 target responding to address 0x40 on each pair of NVMe drives.

Sideband Signals

The internal adapters have one or two x8 SFF-8654 connectors. Each x8 connector provides two sets of sidebands. This section describes the sideband signal usage. The following table defines the sideband signal's pins on the SFF-8654 connector. The last column in the table indicates the strength of the pull-up resistor or pull-down resistor values on the adapter. See [Table 8, Sideband Management Pin Settings](#), for the signal descriptions, and see [Table 9, Internal x8 SFF-8654 Connector Pinout](#), for a complete connector pinout.

Table 7: Sideband Signal Pinout

Connector A Side	Connector B Side	Sideband or Vendor Specific Pin Number	UBM Assignments	Direction	Resistor Value
A8	A26	7	BP_TYPE	Input	100-kΩ pull-down
A9	A27	4	2W_RESET#	Output	2.0-kΩ pull-up
A10	A28	3	GND	—	—
A11	A29	+	REFCLK+	Output	—
A12	A30	—	REFCLK-	Output	—
B8	B26	0	2W_CLK	Input/Output	2.0-kΩ pull-up
B9	B27	1	2W_DATA	Input/Output	2.0-kΩ pull-up
B10	B28	2	GND	—	—
B11	B29	5	PERST#	Input/Output	2.0-kΩ pull-up
B12	B30	6	C_TYPE, D_INPL#, CHANGE_DET#	Input/Output	10-kΩ pull-up

The following table describes the sideband signal pin settings.

Table 8: Sideband Management Pin Settings

Pin Name	Settings	Description
BP_TYPE	<ul style="list-style-type: none"> • 0: SPI • 1: Two-wire interface 	Indicates if the backplane uses SPI or two-wire interface for management. To maintain backwards compatibility with SPI-based backplanes, the adapter has a weak pull-down to default to SPI if the backplane does not explicitly drive the signal.
2W_RESET#	<ul style="list-style-type: none"> • 0: Reset is asserted • 1: Reset is not asserted 	Optional reset driven by the host if the UBM target reports that the target can be reset.
REFCLK+/-	—	PCIe REFCLK HCSL 100-MHz clock driven by the device side ports to PCIe devices that require REFCLK. If D_INPL# is 0 and BP_TYPE is 1, the adapter enables the REFCLK outputs for that quad of high-speed lanes. When BP_TYPE is 0 or the UBM Clock Routing bit on the backplane is 0, this output is turned off.
2W_CLK	—	The two-wire interface clock signal.
2W_DATA	—	The two-wire interface data signal.
PERST#	<ul style="list-style-type: none"> • 0: Reset is asserted • 1: Reset is not asserted 	The adapter drives the PCIe RESET# signal. This signal uses a clamp to ground so that the signal on the adapter powers up LOW until backplane detection warrants the release of this signal for open-drain use. This method ensures that PERST# does not deassert until the directly connected NVMe drive is successfully detected.


Pin Name	Settings	Description
C_TYPE, D_INPL#, CHANGE_DET#	—	<p>Open collector/drain input or output signal:</p> <ul style="list-style-type: none"> • C_TYPE. If BP_TYPE is 0, the adapter drives this signal LOW. If BP_TYPE is 1, this signal adheres to the SFF-8448 requirement to drive this signal to 1 in response to floating the signal. Because this signal is an open drain signal, <i>driving</i> to 1 is when a pull-up resistor pulls this signal HIGH. • D_INPL#. When C_TYPE is HIGH, the backplane pulls this signal to ground to indicate an NVMe device is connected and a two-wire interface backplane management target might be on the sideband's two-wire interface. • CHANGE_DET#. If D_INPL# is 0 and a UBM FRU device is discovered on the two-wire interface, the UBM FRU data can inform the adapter that the device is CHANGE_DET# feature capable. The adapter can rely on this signal as the CHANGE_DET# signal as described in the UBM specification. In this mode, the UBM controller drives this signal LOW to assert CHANGE_DET#.

Cables and Cabling Configurations

The internal adapter follows the SFF-9402 standard for connector signal assignments.

Each x8 connector includes eight PCIe transmit and receive lanes and two sets of sidebands, designated as A and B, in accordance with the SFF-9402 specification. The following figure shows the x8 SFF-8654 pin designations.

Figure 1: x8 SFF-8654 Pin Designations



The following table defines the adapter's internal SFF-8654 connector pinouts.

Table 9: Internal x8 SFF-8654 Connector Pinout

Pin	Name	Pin	Name
A1	GND	B1	GND
A2	PERp0, RX0+	B2	PETp0, TX0+
A3	PERn0, RX0-	B3	PETn0, TX0-
A4	GND	B4	GND
A5	PERp1, RX1+	B5	PETp1, TX1+
A6	PERn1, RX1-	B6	PETn1, TX1-
A7	GND	B7	GND
A8	BP_TYPEA	B8	2W-CLKA, SClockA
A9	2W_RESETA, SDataOutA	B9	2W-DATAA, SloadA
A10	GND	B10	GND
A11	REFCLKA+	B11	PERSTA#, SDatinaA
A12	REFCLKA-	B12	CPRNTA#, CNTRLR_TYPEA
A13	GND	B13	GND
A14	PERp2, RX2+	B14	PETp2, TX2+
A15	PERn2, RX2-	B15	PETn2, TX2-
A16	GND	B16	GND
A17	PERp3, RX3+	B17	PETp3, TX3+
A18	PERn3, RX3-	B18	PETn3, TX3-
A19	GND	B19	GND
A20	PERp0, RX4+	B20	PETp0, TX4+

Pin	Name	Pin	Name
A21	PERn0, RX4-	B21	PETn0, TX4-
A22	GND	B22	GND
A23	PERp1, RX5+	B23	PETp1, TX5+
A24	PERn1, RX5-	B24	PETn1, TX5-
A25	GND	B25	GND
A26	BP_TYPEB	B26	2W-CLKB, SClockB
A27	2W_RESETB, SDataOutB	B27	2W-DATAB, SLoadB
A28	GND	B28	GND
A29	REFCLKB+	B29	PERSTB#, SDatInB
A30	REFCLKB-	B30	CPRSNTB#, CNTRLR_TYPEB
A31	GND	B31	GND
A32	PERp2, RX6+	B32	PETp2, TX6+
A33	PERn2, RX6-	B33	PETn2, TX6-
A34	GND	B34	GND
A35	PERp3, RX7+	B35	PETp3, TX7+
A36	PERn3, RX7-	B36	PETn3, TX7-
A37	GND	B37	GND

Storage Interface Cabling

Choose the proper cable for the given backplane type and connectors.

The correct choice is especially important for backplanes that use SFF-8643 for the NVMe connectors. Many of these backplanes use an older, legacy-recommended pinout for the NVMe connector instead of a connector pinout based on the SFF-9402 specification. Most backplanes that use either SFF-8612 or SFF-8654 connectors follow the SFF-9402 specification. The pinout recommended in the *PCI Express OCuLink Specification* is equivalent to that recommended for SFF-9402. Verify the connector pinout for the intended backplane to make sure the proper cable is used when connecting to NVMe drives.

Broadcom provides the following cables to use for the adapter. Use the listed manufacturer part number (MPN) to order a cable from Broadcom. If you source your own cables, use the Broadcom part number from the following table and the drawings and pinouts in [Cable Drawings and Pinouts](#).

Table 10: Internal Adapter Cables

MPN	Broadcom Cable Part No.	Cable Description	Backplane Connector
05-60001-00	5067-6865	x8 8654 to 2x4 8612, AltWiring 1M	Two x4 SFF-8612 (OCuLink)
05-60002-00	5067-6862	x8 8654 to 2x4 8643 (W), SMC 1M	Two x4 SFF-8643 (mini-SAS HD)
05-60003-00	5067-6866	x8 8654 to 2x4 8643, 9402 SAS 1M	Two x4 SFF-8643 (mini-SAS HD)
05-60004-00	5067-6103	x8 8654 to 2x4 8654, 9402 1M	Two x4 SFF-8654 (SlimSAS)
05-60005-00	5067-6682	x8 8654 to 2xU.2 Direct, 1M	Two U.2 SFF-8639
05-60006-00	5067-7542	x8 8654 to 8xU.3 Direct, 1M	Eight U.3 SFF-8639

MPN	Broadcom Cable Part No.	Cable Description	Backplane Connector
05-60007-00	5067-6869	x8 8654 to 1x8 8654, 9402 1M	One x8 SFF-8654 (SlimSAS)

Table 11: Adapter Broadcom Cable Use Cases

MPN	Type	Description
05-60001-00	SAS/SATA and NVMe	Use for backplanes with x4 SFF-8612 connectors with pinouts that follow the SFF-9402 specification.
05-60002-00	NVMe	Specialty cable that provides NVMe connections for SuperMicro Purley backplanes. This cable has white SFF-8643 connectors to indicate that it must connect to the white SFF-8643 connectors on the SuperMicro Purley backplanes.
05-60003-00	SAS/SATA	Use for traditional SAS/SATA connections. Usually backplanes designed to support SAS/SATA only or are double plumbed for U.2 and SAS/SATA drives use SFF-8643 connectors.
05-60004-00	SAS/SATA and NVMe	Use for backplanes with x4 SFF-8654 connectors with pinouts that follow the SFF-9402 specification.
05-60005-00	NVMe	Enables direct connect from the adapter to a U.2 NVMe drive. Use for proof-of-concept type applications.
05-60006-00	SAS/SATA and NVMe	Enables direct connect from the adapter to a U.3 NVMe or SAS/SATA drive. This cable does not send a PCIe REFCLK or PERST# to each drive connector; that is, the U.3 drive must support SRIS and not require PERST#. Use for proof-of-concept type applications.
05-60007-00	SAS/SATA and NVMe	Use for backplanes with x8 SFF-8654 connectors with pinouts that follow the SFF-9402 specification.

Backplane Connectors

The SFF-8612 or SFF-8654 connectors are the preferred connectors to use for the NVMe backplane or multiprotocol backplanes, based on the SFF-TA-1001 universal bay definition.

Backplanes that use OCuLink connectors should follow the *PCI Express OCuLink Specification*. This pinout is also equivalent to the SFF-9402 specification recommendations. Verify the backplane connector pinout to make sure you use proper cabling to the NVMe drive. Refer to the *PCI Express OCuLink Specification* and the SFF-9402 specification for backplane NVMe connector pinout information.

External Adapter Connector Pinout

External adapters support SAS and PCIe connections.

The PCIe cable specification swaps lanes 0 and 1 compared to the SAS specification. For PCIe connections, this swap means the external pinout must place lanes 0 and 1 on the same pins as the JBOF. This swap does not impact SAS connections because lane ordering does not impact SAS designs.

For external PCIe JBOF connections, as defined by the *PCI Express External Cabling Specification*, the adapter does not connect REFCLK and PERST#. The adapter only supports an SRIS-capable endpoint, that is, no REFCLK. The JBOF handles the drive (connected to the JBOF switch) start-of-day reset, hot insertion, and clocking requirements.

The adapter expects a local (single master) two-wire bus connection to the cable or active module's EEPROM. A cable requires a local EEPROM on each end to identify cable properties, such as length, loss budget, ganging, and so on. The adapter supports no direct communication to the enclosure over two-wire. SES performs enclosure management.

The following table shows the cable pinout for the cable that Broadcom provides for the external adapter. See [Cable 05-60009-00](#) for the cable drawing and pinout. Use the drawing if you source your own cable.

Table 12: External Adapter Cable Pinout

Pin	Signal	Pin	Signal
A1	No Connect	C1	CMICLK
A2	CINT#	C2	CMIDAT
A3	GND	C3	GND
A4	PERp0, RX0+	C4	PETp0, TX0+
A5	PERn0, RX0-	C5	PETn0, TX0-
A6	GND	C6	GND
A7	PERp3, RX3+	C7	PETp3, TX3+
A8	PERn3, RX3-	C8	PETn3, TX3-
A9	GND	C9	GND
B1	PWR	D1	PWR
B2	CBLPRSNT#	D2	MGTPWR
B3	GND	D3	GND
B4	PERp1, RX1+	D4	PETp1, TX1+
B5	PERn1, RX1-	D5	PETn1, TX1-
B6	GND	D6	GND
B7	PERp2, RX2+	D7	PETp2, TX2+
B8	PERn2, RX2-	D8	PETn2, TX2-
B9	GND	D9	GND

Broadcom provides the following cable to use for external adapters. Use the MPN listed to order the cable from Broadcom. If you source your own cables, use the Broadcom part number from the following table, and the drawing and pinout in [Cable 05-60009-00](#).

Table 13: External Adapter Cable

MPN	Broadcom Cable Part No.	Cable Description	Backplane Connector
05-60009-00	5067-9643	G4/S4 x4 8644 to x4 8644, 3M	Two x4 SFF-8644

CacheVault Data Protection

The MegaRAID Tri-Mode storage adapters support data retention by using NAND flash memory on the adapter, backed up by a CacheVault™ Power Module 05 (CVPM05).

The CVPM05 module is a super-capacitor pack that provides power for the backup of your data in case of host power loss or server failure. The CVPM05 module connects to the controller remotely by cable. The data is backed up to the NAND flash memory available on the MegaRAID storage adapter.

NOTE

If you do not use the remote mount board or clip included with the CacheVault kit, do not damage the CVPM05 module when mounting in the system. For more information about mounting the CVPM05 module, refer to *CVPM02, CVPM05 Power Modules | CVFM04 Cache Module MegaRAID CacheVault Protection Products User Guide*.

In the event of host power loss or server failure, any data available in the cache is offloaded to the onboard NAND memory. During this process, the CVPM05 power module powers the necessary components needed for offload.

NOTE

You cannot hot plug CVPM05 modules. Removing or inserting a CVPM05 module with the adapter powered on might damage the board and the super-capacitor functionality. To attach or remove a CVPM05 module from an adapter, you must fully power down the adapter before you attach the module to or remove the module from its mating connector.


For more information about installation of the CVPM05 module, visit [Support Documents and Downloads](#) to download the *CacheVault Power Module 05 Getting Started Guide*.

Adapter Security

The adapter hardware secure boot security feature protects your system from malicious activity.

Hardware secure boot permits only authenticated firmware to execute on the adapter. The adapter boots from an internal boot ROM, which establishes the initial root of trust (RoT). Hardware secure boot authenticates and builds a chain of trust with succeeding firmware images by using the RoT, meaning only authorized firmware executes on the adapter.

Figure 2: Authenticated Firmware Example



3_04225-00

Hardware secure boot requires that each image be signed with a valid digital signature; otherwise, the image is considered invalid and does not execute. The adapter ships with a valid, signed firmware image. All Broadcom-supplied firmware includes a valid digital signature; therefore, the hardware secure boot process is transparent unless the adapter encounters a counterfeit image. If the adapter downloads a counterfeit image, the image authentication fails and the download utility, such as StorCLI, displays the appropriate failure messages. Contact Broadcom Technical Support for assistance.

Adapter Installation Instructions

Make sure to use the proper installation steps for your adapter:

- **Adapter Installation:** MegaRAID 9560-16i, MegaRAID 9560-8i, MegaRAID 9580-8i8e, MegaRAID 9540-8i, MegaRAID 9520-8i, HBA 9500-16i, HBA 9500-8i, HBA 9500-16e, or HBA 9500-8e
- **OCP Adapter Installation:** MegaRAID 9562-16i or HBA 9502-16i
- **M.2 Adapter Installation Instructions:** MegaRAID 9524-8i

Adapter Installation

Use the following steps to install any of the following adapters:

- MegaRAID 9560-16i
- MegaRAID 9560-8i
- MegaRAID 9580-8i8e
- MegaRAID 9540-8i
- MegaRAID 9520-8i
- HBA 9500-16i
- HBA 9500-8i
- HBA 9500-16e
- HBA 9500-8e

1. Unpack your adapter.

Unpack and remove the adapter. Inspect the adapter for damage. If it appears damaged, contact Broadcom Technical Support.

ATTENTION

To avoid the risk of data loss, back up your data before you change your system configuration.

2. Turn off the power to the system.

Turn off the power to the computer and disconnect the AC power cord. Remove the computer cover. Refer to the system documentation for instructions. Before you install the adapter, make sure that the computer is disconnected from the power and from any networks.



CAUTION

Disconnect the computer from the power supply and from any networks to which you will install the adapter, or you risk damaging the system or experiencing electrical shock.

3. Review the adapter connectors.

See [Broadcom MegaRAID and HBA Tri-Mode Storage Adapter Characteristics](#) for connector locations and descriptions.


4. Check the mounting bracket on the adapter.

5. Insert the adapter into an available PCIe slot.

Select a PCIe slot, and align the adapter's PCIe bus connector to the slot, as shown in the following figure. Press down gently, but firmly, to make sure that the adapter is seated correctly in the slot. Secure the bracket to the computer chassis with the bracket screw.

NOTE

Adapters with a x8 host interface can operate in x8 or x16 slots. However, some x16 PCIe slots support only PCIe graphics cards; an adapter installed in one of these slots will not function. Refer to your motherboard guide for information about the PCIe slots.

Figure 3: Installing an Adapter in a PCIe Slot

6. Configure and install the SAS or PCIe (NVMe) devices in the host computer case.

Refer to your device documentation for any preinstallation configuration requirements.

7. Connect the adapter to the devices.

Connect the appropriate cable that has the adapter connections on one end. Connect the appropriate connector on the other end to attach to the backplane connector.

The maximum cable length is 1 meter (39.37 in.). A single wide-port SAS or multilane PCIe (NVMe) device cannot connect to phys controlled by different SAS cores or PDBs.

8. Provide the required airflow for the installed adapter. See to find the adapter's cooling requirements.

9. Turn on the power to the system.

Reinstall the computer cover, and reconnect the AC power cords. Make sure that the power is turned on to the storage devices before, or at the same time, that the power is turned on to the host computer. Turn on power to the host computer. If the computer is powered on before these devices, the devices might not be recognized.

During boot, a BIOS message appears. The firmware takes several seconds to initialize. The configuration utility prompt times out after several seconds. The second portion of the BIOS message shows the adapter controller

number, firmware version, and cache SDRAM size. The numbering of the adapters follows the PCIe slot scanning order used by the host motherboard.

10. **Choose the correct storage profile.** Refer to the *12Gb/s MegaRAID Tri-Mode Software User Guide* and the *LSI® Storage Authority Software User Guide* for details about setting up your adapter.
11. **Install the operating system driver.** The adapters can operate under various operating systems. To operate under these operating systems, you must install the appropriate software drivers. The firmware and drivers are routinely updated and made available at [Support Documents and Downloads](#).

The hardware installation of your adapter is complete.

OCP Adapter Installation

Use the following steps to install any of the following adapters:

- MegaRAID 9562-16i
- HBA 9502-16i

1. Unpack your adapter.

Unpack and remove the adapter. Inspect the adapter for damage. If it appears damaged, contact Broadcom Technical Support.

ATTENTION

To avoid the risk of data loss, back up your data before you change your system configuration.

2. Turn off the power to the system.

Turn off the power to the computer and disconnect the AC power cord. Remove the computer cover. Refer to the system documentation for instructions. Before you install the adapter, make sure that the computer is disconnected from the power and from any networks.




CAUTION

Disconnect the computer from the power supply and from any networks to which you will install the adapter, or you risk damaging the system or experiencing electrical shock.

3. **Insert the adapter into an available OCP 3.0 SFF slot.** Select an OCP slot and align the adapter with the system rails. Push the adapter into the slot, as shown in the following figure.

Figure 4: Installing an Adapter in an OCP Slot



4. **Secure the adapter.** The adapter is secured by an internal locking mechanism. A clicking sound is made when the adapter is secured into the slot. The internal locking mechanism depends on the server vendor. Adhere to the server vendor's instructions to engage the internal lock so the adapter is retained in the slot.
5. **Attach the cables.** Attach the cables to the storage device ports.

Removing the OCP Adapter

Use the following steps to remove any of following adapters from an OCP slot:

- MegaRAID 9562-16i
- HBA 9502-16i

1. **Turn off the power to the system.**

Turn off the power to the computer and disconnect the AC power cord. Remove the computer cover. Refer to the system documentation for instructions. Before you install the adapter, make sure that the computer is disconnected from the power and from any networks.



CAUTION

Disconnect the computer from the power supply and from any networks to which you will install the adapter, or you risk damaging the system or experiencing electrical shock.

2. **Unplug the cables.** Remove the SlimSAS cables.

3. **Remove the adapter from the OCP slot.** Adhere to the server vendor's instructions to disengage the internal lock. To remove the adapter from the OCP slot, carefully apply even pressure to the inside edges of the bracket.

NOTE

Do not use the vertical SlimSAS connectors or heat sink on the adapter for leverage.

M.2 Adapter Installation Instructions

Use the following steps to install the MegaRAID 9524-8i adapter:

1. Unpack your adapter.

Unpack and remove the adapter. Inspect the adapter for damage. If it appears damaged, contact Broadcom Technical Support.

ATTENTION

To avoid the risk of data loss, back up your data before you change your system configuration.

2. Turn off the power to the system.

Turn off the power to the computer and disconnect the AC power cord. Remove the computer cover. Refer to the system documentation for instructions. Before you install the adapter, make sure that the computer is disconnected from the power and from any networks.



CAUTION

Disconnect the computer from the power supply and from any networks to which you will install the adapter, or you risk damaging the system or experiencing electrical shock.

3. Review the adapter connectors. See [MegaRAID 9524-8i Adapter: Connector and LED Designations](#) for descriptions of the adapters and their connectors.

4. Install the adapter into an available M.2 slot. Use the installation recommendations from the motherboard's vendor.

5. Provide the required airflow for the installed adapter. See [Tri-Mode Storage Adapter Technical Specifications](#) to find the adapter's cooling requirements.

6. Turn on the power to the system. Reinstall the computer cover and reconnect the AC power cords. Turn on power to the host computer.

During boot, a BIOS message appears. The firmware takes several seconds to initialize. The configuration utility prompt times out after several seconds. The second portion of the BIOS message shows the adapter controller number and firmware version. The numbering of the adapters follows the PCIe slot scanning order used by the host motherboard.

7. Choose the correct storage profile. Refer to the [12Gb/s MegaRAID Tri-Mode Software User Guide](#) and the [LSI® Storage Authority Software User Guide](#) for details about setting up your adapter.

8. Install the operating system driver. The adapters can operate under various operating systems. To operate under these operating systems, you must install the software drivers. The firmware and drivers are routinely updated and made available at [Support Documents and Downloads](#).

Broadcom MegaRAID and HBA Tri-Mode Storage Adapter Characteristics


This chapter presents the physical characteristics of each board, including the board size and the connector locations.

MegaRAID 9560-16i Adapter: Connector and LED Designations

The adapter is a 155.52 (± 0.13) mm \times 68.77 (± 0.13) mm board. The component height on the top and bottom of the adapter complies with the PCIe specification.

The following figure shows the connectors and LED locations on the adapter. A red circle near each header and connector identifies pin 1 in the figure.

Figure 5: Card Layout for the MegaRAID 9560-16i Tri-Mode Storage Adapter



The following table describes the headers and connectors on the adapter.

Table 14: Headers and Connectors

Connector	Type	Description
J2	Standard edge card connector	The interface between the storage adapter and the host system. With the PCIe interface, this connector provides power to the board and an I ² C interface connected to the I ² C bus for the Intelligent Platform Management Interface (IPMI).
J4	Default serial boot ROM (SBR) header	2-pin connector. Reserved for Broadcom use.
J7	Advanced software options hardware key header	2-pin connector. Enables support for selected advanced features.
J8	Onboard serial UART connector	4-pin connector. Reserved for Broadcom use.
J10	Global HDD activity LED header	2-pin connector. Connects to an LED that indicates activity on the drives connected to the adapter.
J11	Global drive fault LED header	2-pin connector. Connects to an LED that indicates whether a drive is in a fault condition.
J14	CacheVault power module interface	9-pin connector. Connects the adapter to a CacheVault power module.
J17, J18	Storage interface connectors	Two SFF-8654 8-port internal connectors. Connects the adapter by cable to the storage devices.

The following table describes the LEDs on the adapter.


Table 15: LED Designations

LED	Type	Description
LED2	Yellow controller over temperature	Stays on solid to indicate that the SAS3916 device temperature sensor is over the temperature threshold. When the device is in the proper temperature range, this LED is off.
LED3	Green system heartbeat	Indicates that the SAS3916 RoC ASIC is operating normally. This LED blinks at 1 Hz.
LED5	Yellow supercap fault	Indicates that the CacheVault power module is in a fault state or is over the temperature threshold. This LED resides on the non-heat-sink side of the board.
LED6	Green ONFI activity	Indicates when the ONFI is active for cache offload or recovery. This LED resides on the non-heat-sink side of the board.

MegaRAID 9560-8i Adapter: Connector and LED Designations

The adapter is a 155.52 (± 0.13) mm \times 68.77 (± 0.13) mm board. The component height on the top and bottom of the adapter complies with the PCIe specification.

The following figure shows the connectors and LED locations on the adapter. A red circle near each header and connector identifies pin 1 in the figure.

Figure 6: Card Layout for the MegaRAID 9560-8i Tri-Mode Storage Adapter**Table 16: Headers and Connectors**

Connector	Type	Description
J2	Standard edge card connector	The interface between the storage adapter and the host system. With the PCIe interface, this connector provides power to the board and an I ² C interface connected to the I ² C bus for the IPMI.
J4	Default SBR header	2-pin connector. Reserved for Broadcom use.
J7	Advanced software options hardware key header	2-pin connector. Enables support for selected advanced features.
J8	Onboard serial UART connector	4-pin connector. Reserved for Broadcom use.
J10	Global HDD activity LED header	2-pin connector. Connects to an LED that indicates activity on the drives connected to the controller.
J11	Global drive fault LED header	2-pin connector. Connects to an LED that indicates whether a drive is in a fault condition.
J14	CacheVault power module interface	9-pin connector. Connects the adapter to a CacheVault power module.
J17	Storage interface connector	One SFF-8654 8-port internal connector. Connects the adapter by cable to the storage devices.

The following table describes the LEDs on the adapter.

Table 17: LED Designations

LED	Type	Description
LED2	Yellow controller over temperature	Stays on solid to indicate that the SAS3916 device temperature sensor is over the temperature threshold. When the device is in the proper temperature range, this LED is off.
LED3	Green system heartbeat	Indicates that the SAS3916 RoC ASIC is operating normally. This LED blinks at 1 Hz.
LED5	Yellow supercap fault	Indicates that the CacheVault power module is in a fault state or is over the temperature threshold. This LED resides on the non-heat-sink side of the board.
LED6	Green ONFI activity	Indicates when the ONFI is active for cache offload or recovery. This LED resides on the non-heat-sink side of the board.

MegaRAID 9580-8i8e Adapter: Connector and LED Designations

The adapter is a 167.52 (± 0.13) mm \times 68.77 (± 0.13) mm board. The component height on the top and bottom of the adapter complies with the PCIe specification.

The following figure shows the connectors and LED locations on the adapter. A red circle near each header and connector identifies pin 1 in the figure.


Figure 7: Card Layout for the MegaRAID 9580-8i8e Tri-Mode Storage Adapter

Table 18: Headers and Connectors

Connector	Type	Description
J2	Standard edge card connector	The interface between the storage adapter and the host system. With the PCIe interface, this connector provides power to the board and an I ² C interface connected to the I ² C bus for the IPMI.
J4	Default SBR header	2-pin connector. Reserved for Broadcom use.
J7	Advanced software options hardware key header	2-pin connector. Enables support for selected advanced features.
J8	Onboard serial UART connector	4-pin connector. Reserved for Broadcom use.
J10	Global HDD activity LED header	2-pin connector. Connects to an LED that indicates activity on the drives connected to the controller.
J11	Global drive fault LED header	2-pin connector. Connects to an LED that indicates whether a drive is in a fault condition.
J14	CacheVault power module interface	9-pin connector. Connects the adapter to a CacheVault power module.
J17	Storage interface connector	Two SFF-8644 4-port external connector. Connects the adapter by cable to the storage devices.
J18	Storage interface connector	One SFF-8654 8-port internal connector. Connects the adapter by cable to the storage devices.

The following table describes the LEDs on the adapter.


Table 19: LED Designations

LED	Type	Description
LED2	Yellow controller over temperature	Stays on solid to indicate that the SAS3916 device temperature sensor is over the temperature threshold. When the device is in the proper temperature range, this LED is off.
LED3	Green system heartbeat	Indicates that the SAS3916 RoC ASIC is operating normally. This LED blinks at 1 Hz.
LED5	Yellow supercap fault	Indicates that the CacheVault power module is in a fault state or is over the temperature threshold.
LED6	Green ONFI activity	Indicates when the ONFI is active for cache offload or recovery.

MegaRAID 9540-8i Adapter: Connector and LED Designations

The adapter is a 155.52 (± 0.13) mm \times 68.77 (± 0.13) mm board. The component height on the top and bottom of the adapter complies with the PCIe specification.

The following figure shows the connectors and LED locations on the adapter. A red circle near each header and connector identifies pin 1 in the figure.

Figure 8: MegaRAID 9540-8i Tri-Mode Storage Adapter

The following table describes the headers and connectors on the adapter.

Table 20: Headers and Connectors

Connector	Type	Description
J2	Standard edge card connector	The interface between the storage adapter and the host system. With the PCIe interface, this connector provides power to the board and an I ² C interface connected to the I ² C bus for the IPMI.
J4	Default SBR header	2-pin connector. Reserved.
J7	Advanced software options hardware key header	2-pin connector. Enables support for selected advanced features.
J8	Onboard serial UART connector	4-pin connector. Reserved.
J10	Global HDD activity LED header	2-pin connector. Connects to an LED that indicates activity on the drives connected to the controller.
J11	Global drive fault LED header	2-pin connector. Connects to an LED that indicates whether a drive is in a fault condition.

Connector	Type	Description
J17	Storage interface connector	One SFF-8654 8-port internal connector. Connects the adapter by cable to the storage devices.

The following table describes the LEDs on the adapter.

Table 21: LED Designations


LED	Type	Description
LED2	Yellow IOC over temperature	Stays on solid to indicate that the SAS3808 IOC temperature sensor is over the temperature threshold. When the IOC is in the proper temperature range, this LED is off.
LED3	Green system heartbeat	Indicates that the SAS3808 IOC is operating normally.

MegaRAID 9520-8i Adapter: Connector and LED Designations

The adapter is a 155.52 (± 0.13) mm \times 68.77 (± 0.13) mm board. The component height on the top and bottom of the adapter complies with the PCIe specification.

The following figure shows the connectors and LED locations on the adapter. A red circle near each header and connector identifies pin 1 in the figure.

Figure 9: MegaRAID 9520-8i Tri-Mode Storage Adapter



The following table describes the headers and connectors on the adapter.

Table 22: Headers and Connectors

Connector	Type	Description
J2	Standard edge card connector	The interface between the storage adapter and the host system. With the PCIe interface, this connector provides power to the board and an I ² C interface connected to the I ² C bus for the IPMI.
J4	Default SBR header	2-pin connector. Reserved.
J7	Advanced software options hardware key header	2-pin connector. Enables support for selected advanced features.
J8	Onboard serial UART connector	4-pin connector. Reserved.
J10	Global HDD activity LED header	2-pin connector. Connects to an LED that indicates activity on the drives connected to the controller.
J11	Global drive fault LED header	2-pin connector. Connects to an LED that indicates whether a drive is in a fault condition.
J17	Storage interface connector	One SFF-8654 8-port internal connector. Connects the adapter by cable to the storage devices.

The following table describes the LEDs on the adapter.

Table 23: LED Designations

LED	Type	Description
LED2	Yellow IOC over temperature	Stays on solid to indicate that the SAS3808 IOC temperature sensor is over the temperature threshold. When the IOC is in the proper temperature range, this LED is off.
LED3	Green system heartbeat	Indicates that the SAS3808 IOC is operating normally.

MegaRAID 9524-8i Adapter: Connector and LED Designations

The adapter is a 22 (± 0.15) mm \times 80 (± 0.15) mm board. The top maximum is 13.3 mm. The bottom maximum is 1.5 mm. The component height on the top and bottom of the adapter complies with the PCIe Card Electromechanical specification.

The following figure shows the connectors and LED locations on the adapter. A red circle near each header and connector identifies pin 1 in the figure.

Figure 10: Card Layout for the MegaRAID 9524-8i Tri-Mode Storage Adapter**Table 24: Headers and Connectors**

Connector	Type	Description
P1	Standard edge card connector	The interface between the storage adapter and the host system. With the PCIe interface, this connector provides power to the board and an I ² C interface connected to the I ² C bus for the IPMI.
J1	Onboard serial UART connector	5-pin connector. Reserved for Broadcom use.
J1555	SSD connector	One M.2 SSD connector.

The following table describes the LEDs on the adapter.


Table 25: LED Designations

LED	Type	Description
LED4	Yellow controller over temperature	Stays on solid to indicate that the SAS3808N device temperature sensor is over the temperature threshold. When the device is in the proper temperature range, this LED is off.
D22	Green system heartbeat	Indicates that the SAS808N IOC ASIC is operating normally. This LED blinks at 1 Hz.

MegaRAID 9562-16i Adapter: Connector and LED Designations

The adapter is a 115.00 (± 0.13) mm \times 76.00 (± 0.13) mm board. The component height on the top and bottom of the adapter complies with the OCP 3.0 NIC specification.

The following figure shows the connectors and LED locations on the adapter. A red circle near each header and connector identifies pin 1 in the figure.

Figure 11: Card Layout for the MegaRAID 9562-16i Tri-Mode Storage Adapter

The following table describes the headers and connectors on the adapter.

Table 26: Headers and Connectors

Connector	Type	Description
J4	Default serial boot ROM (SBR) header	2-pin connector. Reserved for Broadcom use.
J8	Onboard serial UART connector	4-pin connector. Reserved for Broadcom use.
J14	CacheVault power module interface	9-pin connector. Connects the adapter to a CacheVault power module.
J17, J18	Storage interface connectors	Two SFF-8654 8-port internal connectors. Connects the adapter by cable to the storage devices.
J27	Card PCIe edge connector	The interface between the storage adapter and the host system.

The following table describes the LEDs on the adapter.


Table 27: LED Designations

LED	Type	Description
LED2	Yellow controller over temperature	Stays on solid to indicate that the SAS3916 device temperature sensor is over the temperature threshold. When the device is in the proper temperature range, this LED is off.
LED3	Green system heartbeat	Indicates that the SAS3916 RoC ASIC is operating normally. This LED blinks at 1 Hz.
LED5	Yellow supercap fault	Indicates that the CacheVault power module is in a fault state or is over the temperature threshold. This LED resides on the non-heat-sink side of the board.
LED6	Green ONFI activity	Indicates when the ONFI is active for cache offload or recovery. This LED resides on the non-heat-sink side of the board.

HBA 9500-16i Adapter: Connector and LED Designations

The adapter is a 155.52 (± 0.13) mm \times 68.77 (± 0.13) mm board. The component height on the top and bottom of the adapter complies with the PCIe specification.

The following figure shows the connectors and LED locations on the adapter. A red circle near each header and connector identifies pin 1 in the figure.

Figure 12: Card Layout of the HBA 9500-16i Tri-Mode Storage Adapter

The following table describes the connectors on the adapter.

Table 28: Headers and Connectors

Connector	Type	Description
J2	Standard edge card connector	The interface between the storage adapter and the host system. With the PCIe interface, this connector provides power to the board and an I ² C interface connected to the I ² C bus for the IPMI.
J4	Default SBR header	2-pin connector. Reserved for Broadcom use.
J8	Onboard serial UART connector	4-pin connector. Reserved for Broadcom use.
J17, J18	Storage interface connectors	Two SFF-8654 8-port internal connectors. Connects the adapter by cable to the storage devices.

The following table describes the LEDs on the adapter.


Table 29: LED Designations

LED	Type	Description
LED2	Yellow IOC over temperature	Stays on solid to indicate that the SAS3816 IOC temperature sensor is over the temperature threshold. When the device is in the proper temperature range, this LED is off.
LED3	Green system heartbeat	Indicates that the SAS3816 IOC is operating normally.

HBA 9500-8i Adapter: Connector and LED Designations

The adapter is a 155.52 (±0.13) mm × 68.77 (±0.13) mm board. The component height on the top and bottom of the adapter complies with the PCIe specification.

The following figure shows the connectors and LED locations on the adapter. A red circle near each header and connector identifies pin 1 in the figure.

Figure 13: Card Layout of the HBA SAS 9500-8i Tri-Mode Storage Adapter

The following table describes the headers and connectors on the adapter.

Table 30: Headers and Connectors

Connector	Type	Description
J2	Standard edge card connector	The interface between the storage adapter and the host system. With the PCIe interface, this connector provides power to the board and an I ² C interface connected to the I ² C bus for the IPMI.
J4	Default SBR header	2-pin connector. Reserved for Broadcom use.
J8	Onboard serial UART connector	4-pin connector. Reserved for Broadcom use.
J17	Storage interface connector	One SFF-8654 8-port internal connector. Connects the adapter by cable to the storage devices.

The following table describes the LEDs on the adapter.

Table 31: LED Designations


LED	Type	Description
LED2	Yellow IOC over temperature	Stays on solid to indicate that the SAS3808 IOC temperature sensor is over the temperature threshold. When the IOC is in the proper temperature range, this LED is off.
LED3	Green system heartbeat	Indicates that the SAS3808 IOC is operating normally.

HBA 9500-16e Adapter: Connector and LED Designations

The adapter is a 167.65 (± 0.13) mm \times 68.77 (± 0.13) mm board. The component height on the top and bottom of the adapter complies with the PCIe specification.

The following figure shows the connectors and LED locations on the adapter. A red circle near each header and connector identifies pin 1 in the figure.

Figure 14: Card Layout of the HBA 9500-16e Storage Adapter



The following table describes the headers and connectors on the adapter.

Table 32: Connectors

Connector	Type	Description
J2	Standard board edge connector	PCIe x8 board edge connector. With the PCIe interface, this connector provides power to the board and an I ² C interface connected to the I ² C bus for the IPMI.
J18	Storage interface connectors	Four SFF-8644 external connectors. Connects the adapter by cable to the storage devices.
J4	Default SBR header	2-pin connector. Reserved for Broadcom use.
J8	Onboard serial UART connector	4-pin connector. Reserved for Broadcom use.

The following table describes the LEDs on the adapter.

Table 33: LED Designations


LED	Type	Description
LED2	Yellow IOC over temperature	Stays on solid to indicate that the SAS3816 IOC temperature sensor is over the temperature threshold. When the device is in the proper temperature range, this LED is off. This LED resides on the non-heat-sink side of the board.
LED3	Green system heartbeat	Indicates that the SAS3816 IOC is operating normally. This LED resides on the non-heat-sink side of the board.

HBA 9500-8e Adapter: Connector and LED Designations

The adapter is a 167.65 (± 0.13) mm \times 68.77 (± 0.13) mm board. The component height on the top and bottom of the adapter complies with the PCIe specification.

The following figure shows the connectors and LED locations on the adapter. A red circle near each header and connector identifies pin 1 in the figure.

Figure 15: Card Layout of the HBA 9500-8e Storage Adapter



The following table describes the headers and connectors on the adapter.

Table 34: Headers and Connectors

Connector	Type	Description
J2	Standard board edge connector	PCIe x8 board edge connector. With the PCIe interface, this connector provides power to the board and an I ² C interface connected to the I ² C bus for the IPMI.
J18	Storage interface connectors	Two SFF-8644 external connectors. Connects the adapter by cable to the storage devices.
J4	Default SBR header	2-pin connector. Reserved for Broadcom use.
J8	Onboard serial UART connector	4-pin connector. Reserved for Broadcom use.

The following table describes the LEDs on the adapter.


Table 35: LED Designations

LED	Type	Description
LED2	Yellow IOC over temperature	Stays on solid to indicate that the SAS3816 IOC temperature sensor is over the temperature threshold. When the device is in the proper temperature range, this LED is off. This LED resides on the non-heat-sink side of the board.
LED3	Green system heartbeat	Indicates that the SAS3816 IOC is operating normally. This LED resides on the non-heat-sink side of the board.

HBA 9502-16i Adapter: Connector and LED Designations

The adapter is a 115.00 (± 0.13) mm \times 76.00 (± 0.13) mm board. The component height on the top and bottom of the adapter complies with the OCP 3.0 NIC specification.

The following figure shows the connectors and LED locations on the adapter. A red circle near each header and connector identifies pin 1 in the figure.

Figure 16: Card Layout of the HBA 9502-16i Tri-Mode Storage Adapter

The following table describes the connectors on the adapter.

Table 36: Headers and Connectors

Connector	Type	Description
J4	Default serial boot ROM (SBR) header	2-pin connector. Reserved for Broadcom use.
J8	Onboard serial UART connector	4-pin connector. Reserved for Broadcom use.
J17, J18	Storage interface connectors	Two SFF-8654 8-port internal connectors. Connects the adapter by cable to the storage devices.
J27	Card PCIe edge connector	The interface between the storage adapter and the host system.

The following table describes the LEDs on the adapter.

Table 37: LED Designations

LED	Type	Description
LED2	Yellow controller over temperature	Stays on solid to indicate that the SAS3816 device temperature sensor is over the temperature threshold. When the device is in the proper temperature range, this LED is off.
LED3	Green system heartbeat	Indicates that the SAS3816 IOC ASIC is operating normally. This LED blinks at 1 Hz.

Tri-Mode Storage Adapter Technical Specifications

This chapter presents the technical specifications of each board, including operating conditions and power supply requirements.

Board Storage Conditions

The following table lists the board storage conditions for the storage adapters.

Table 38: Board Storage Conditions

Adapter	Relative Humidity Range (Non-condensing)	Temperature Range ^a
9560-16i	10% to 90%	–40°C to +70°C
9560-8i	10% to 90%	–40°C to +70°C
9580-8i8e	10% to 90%	–40°C to +70°C
9540-8i	10% to 90%	–40°C to +70°C
9520-8i	10% to 90%	–40°C to +70°C
9524-8i	10% to 90%	–40°C to +70°C
9500-16i	10% to 90%	–40°C to +70°C
9500-8i	10% to 90%	–40°C to +70°C
9500-16e	10% to 90%	–40°C to +70°C
9500-8e	10% to 90%	–40°C to +70°C
9562-16i	10% to 90%	–40°C to +70°C
9502-16i	10% to 90%	–40°C to +70°C

Board Weights

The following table lists the net weight of each adapter and the CVPM05 module. These values do not include the packaging.

Table 39: Adapter Weights

Adapter	Weight
9560-16i	0.146 kg
9560-8i	0.146 kg
9580-8i8e	0.135 kg
9540-8i	0.133 kg
9520-8i	0.133 kg
9524-8i	0.10 kg

a. For adapters with a CVPM, this range applies with or without the CVPM attached.

Adapter	Weight
9500-16i	0.133 kg
9500-8i	0.125 kg
9500-16e	0.135 kg
9500-8e	0.135 kg
9562-16i	0.09 kg
9502-16i	0.09 kg
CVPM05	0.0605 kg

Board Operating Conditions

The following table lists the board operating conditions for the storage adapters. The minimum airflow, measured as linear feet per minute (LFM) at 55°C, must be met to avoid operating the controller's processor and board components above their maximum junction temperatures.

Table 40: Board Operating Conditions

Adapter	Minimum LFM	Temperature Range ^a
9560-16i	200	0°C to +55°C
9560-8i	200	0°C to +55°C
9580-8i8e	200	0°C to +55°C
9540-8i	150	0°C to +55°C
9520-8i	150	0°C to +55°C
9524-8i	155	0°C to +55°C
9500-16i	150	0°C to +55°C
9500-8i	150	0°C to +55°C
9500-16e	150	0°C to +55°C
9500-8e	150	0°C to +55°C
9562-16i	200	0°C to +55°C
9502-16i	150	0°C to +55°C

Power Supply Requirements

All power is supplied to the tri-mode storage adapter through the PCIe 3.3V rails (3.3V $\pm 9\%$) and the 12V rail (12V $\pm 8\%$). Onboard switching regulator circuitry operates from the 3.3V rails, and the 12V rail provides the necessary voltages.

Typical power is measured with maximum I/O traffic, typical silicon process material, and nominal voltages operating the card at an ambient temperature of 45°C with required airflow.

MegaRAID Tri-Mode Storage Adapter Power Supply Requirements

The following table describes the typical power consumption of the MegaRAID adapters.

a. For adapters with a CVPM, this range applies with or without the CVPM attached.

Table 41: MegaRAID Tri-Mode Storage Adapter Typical Power Consumption

Power Mode	Typical Power (W)					
	9560-16i	9560-8i	9580-8i8e	9540-8i	9520-8i	9524-8i
3.3V Supply	0.22	0.22	0.66	0.02	0.02	5.77
+12V Supply	12.99	9.42	13.59	5.94	5.94	—
Total Power	13.21	9.64	14.25	5.96	5.96	5.77

During the transparent learn cycle, the CacheVault power module consumes up to an additional 8W. The PCIe 3.3V rail supplies the power for the learn cycle.

HBA Tri-Mode Storage Adapter Power Supply Requirements

The following table describes the typical power consumption of the HBAs.

Table 42: HBA Tri-Mode Storage Adapter Typical Power Consumption

Power Mode	Typical Power (W)			
	9500-16i	9500-8i	9500-16e	9500-8e
3.3V Supply	0.04	0.02	0.04	0.02
+12V Supply	8.50	5.94	8.70	6.10
Total Power	8.54	5.96	8.74	6.12

MegaRAID and HBA Tri-Mode OCP Adapter Power Supply Requirements

The following table describes the typical power consumption of the OCP adapters.

Table 43: OCP Tri-Mode Storage Adapter Typical Power Consumption

Power Mode	Typical Power (W)	
	9562-16i	9502-16i
3.3V Supply	0.3	0.1
+12V Supply	13.5	8.9
Total Power	13.8	9.0

For the MegaRAID 9562-16i adapter, the CacheVault power module consumes up to an additional 8W during the transparent learn cycle. The PCIe 3.3V rail supplies the power for the learn cycle.

Marks, Certifications, Compliance, and Safety Characteristics

This chapter lists the adapter marks and certifications, FCC compliance statements, and safety characteristics.

Marks, Certifications, and Compliance

The design and implementation of the adapters minimize electromagnetic emissions, susceptibility to radio frequency energy, and the effects of electrostatic discharge.


The following adapters show the marks and certifications included in [Table 45, Adapter Marks and Certifications](#).

Table 44: Adapter Models

Adapter	Model Number
MegaRAID 9524-8i	50170
MegaRAID 9560-16i MegaRAID 9560-8i	50077
HBA 9500-16i HBA 9500-8i	2022 and forward: 50134 Previous years: 50077
MegaRAID 9540-8i MegaRAID 9520-8i	50134
MegaRAID 9580-8i8e	50076
HBA 9500-16e HBA 9500-8e	50075
MegaRAID 9562-16i HBA 9502-16i	50137

Table 45: Adapter Marks and Certifications

Mark	Symbol	Description
Australia and New Zealand RCM		Meets the following standards: <ul style="list-style-type: none">AS/NZS CISPR 32CISPR 32:2015, Class AAS/NZS CISPR 32:2015 +A1:2020, Class A
Canada EMC	CANADA ICES-003 CLASS A CANADA NMB-003 CLASSE A CAN ICES-3 (A)/NMB-3 (A)	Meets the following standards: <ul style="list-style-type: none">ICES-003:2016 Issue 7: 2016, Class ACAN/CSA CISPR 22-10CISPR 22:2008
Europe (CE)		Meets the following standards: <ul style="list-style-type: none">EN 55032, EN 55035EN 55032:2015 +A11:2020, Class AEN 55035:2017 +A11:2020, Class A

Mark	Symbol	Description
Korea (RRL)	 R-R-A8T-XXXXX	xxxxx = model number Meets the KN32/KN35 testing requirements.
Taiwan (BSMI)	 D3H413 RoHS	Meets the following standards: <ul style="list-style-type: none">• CNS15663• CNS15936
USA / Canada Safety		For use with UL-listed ITE equipment only. Meets the following standards: <ul style="list-style-type: none">• CAN/CSA C22.2 No. 62368-1-19, Third Edition• UL 62368-1, Third Edition
CB Scheme Safety	—	Meets the following standards: <ul style="list-style-type: none">• IEC 62368-1:2014 (Third edition)• EN 62368-1:2014+A11: 2017
Japan (VCCI)		Meets the following standards: <ul style="list-style-type: none">• VCCI-CISPR 32:2016
USA / Canada (FCC)		Meets the following standards: <ul style="list-style-type: none">• 47 CFR FCC Part 15, Subpart B, Class A• ANSI C63.4:2014• CISPR 32:2008
Morocco (CMIM)		Meets the following standards: <ul style="list-style-type: none">• EN 55032, EN 55035• EN 55032:2015 +A11:2020, Class A• EN 55035:2017 +A11:2020
Country of Origin	Made in XXXX	XXXX indicates the country of origin.

FCC Compliance

This device complies with part 15 of the FCC rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user is required to correct the interference at his or her own expense.

Safety Characteristics

All tri-mode storage adapters meet or exceed the requirements of UL flammability rating 94 V0. Each bare board is also marked with the supplier name or trademark, type, and UL flammability rating. For the boards installed in a PCIe bus slot, all voltages are lower than the SELV 42.4V limit.

VCCI – Japan

この装置は、クラスA機器です。この装置を住宅環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

VCCI – A

This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures. VCCI—A.

Taiwan BSMI Compliance

警告：為避免電磁干擾，本產品不應安裝或使用於住宅環境。

Warning: To avoid electromagnetic interference, this product should not be installed or used in residential environments.


Cable Drawings and Pinouts

Use the cable drawings and pinouts in this appendix if your design requires you to design your own cables.

Cable 05-60001-00

The following figure shows the drawing and pinout for Broadcom cable 05-60001-00, a x8 SFF-8654 to 2 x4 SFF-8612 connection.

Figure 17: Cable 05-60001-00 Drawing and Pinout



NOTES:


1. END TO END RESISTANCE OF INDICATED CONNECTION SHALL BE 750 MILLIOHM MAX.
2. SHORT PIN/PAD S0-A8 TO S0-B9. NO DIRECT CONNECT S0-A8 TO CONNECTOR P0.
3. SHORT PIN/PAD S0-A26 TO S0-B27. NO DIRECT CONNECT S0-A26 TO CONNECTOR P1.

Cable 05-60002-00

The following figure shows the drawing and pinout for Broadcom cable 05-60002-00, a x8 SFF-8654 to 2 x4 SFF-8643 connection. Use this cable for NVMe connections on SuperMicro Purley backplanes.

Figure 18: Cable 05-60002-00 Drawing and Pinout

REVISONS				
REV	ECO	DESCRIPTION	DATE	APPROVED
001		PRELIMINARY RELEASE. UPDATE WIRE GAUGE AND IMPEDANCE TOLERANCE ITEM 3. REVISE MARKING PER REVISION 002. ADD S0-A8 TO CONNECTOR PO. LABEL: ADD HOST AND TARGET WIRING TABLE.	09FEB18	
002	141562	WIRING CHANGE TO FOLLOWING (PADS) IN WIRING TABLE. S0-A8 TO CONNECTOR PO: B1, C1-C2, D1-D2, P1: B1, C1-C2, D1-D2	13JUL18	
003	175141	INITIAL RELEASE. REMOVE WATERMARK.	21NOV19	



NOTES:

1. DRAWING NOT TO SCALE.
2. ELECTRICAL AND MECHANICAL PERFORMANCE SHALL MEET PCIE GEN 4 INDUSTRIAL STANDARDS.
3. MARK LABEL (ITEM 8) WITH:
SLIMSA S (PCIE ONLY)
BROADCOM PART NUMBER
BROADCOM REVISION XXX
DATE CODE DD/MMM/YY
4. SEE CABLE WIRING TABLE AND RELATED NOTES.

ITEM	CALLOUT	DESCRIPTION	QUANTITY	NOTES
9	LABEL	LABEL, 40X14MM, WHITE, R2, HF	A/R	
8	LABEL	LABEL, 70X26MM, WHITE, R2, HF	A/R	SEE NOTE 3
7	TAPE	ACETATE TAPE, W=1 INCH	A/R	
6	SLEEVING	EXPANDO TUBE, OD:1MM, GREEN, VW-1, HF	A/R	
5	SLEEVING	EXPANDO TUBE, OD:10MM, GREEN, VW-1, HF	A/R	
4	WIRE	UL1061, STRANDED	A/R	SEE NOTE 4
3	CABLE	SAS CABLE: UL20744, 28-32AWG, 92.5Ω ±10% DIFF, PCIE GEN 4, VW-1, NATURAL, HF	A/R	
2	CONNECTOR	SFF-8643, 36P, STRAIGHT, X4, WHITE, SHORT, PCIE GEN 4	2	SEE NOTE 4
1	CONNECTOR	SFF-8654, 74P, STRAIGHT, X8, SAS 4.0, PCIE GEN 4	1	SEE NOTE 4

APPROVALS	DATE	UNLESS OTHERWISE SPECIFIED: DIMENSIONS IN MILLIMETERS. TOLERANCES: X,X ± 0.2 MM Y,Y ± 0.5 MM Z,Z ± 0.55 MM ANGLES ± 1°	BROADCOM®
DRAWN BY	05FEB18		
APPROVED BY	09FEB18		
		Approved/Authenticated & Copyright © 2018 Broadcom Corporation. All Rights Reserved. Any copy or distribution of this document without the express written consent of Broadcom is illegal. The present document is current. However, the latest version of this document may be available at www.broadcom.com . Please refer to the latest version of this document from their point of use.	TITLE CABLE, SFF-8654 X8 TO 2X SFF-8643 X4 (W), (M)
SCALE	1.500	1:1	SIZE D MM 5067-6862 REV 003 SHEET

CONNECTOR SIGNAL	CONNECTOR (HOST)	PIN/PAD	CONNECTOR (TARGET)	PIN/PAD	CONNECTOR SIGNAL	WIRE/CABLE
GND	SO	A1	P0	D3	GND	ITEM 3
Rx0+		A2		D4	Tx0+	ITEM 3
Rx0-		A3		D5	Tx0-	ITEM 3
GND		A4		D6	GND	ITEM 3
Rx1+		A5		D7	Tx1+	ITEM 3
Rx1-		A6		D8	Tx1-	ITEM 3
GND		A7		D9/C6	GND	ITEM 3, NOTE 2
SB7A		A8		D10	NC	NOTE 3
SB4A		A9		D11	SB7B	
SB3A		A10		D12	SB4B	
SBA+		A11		D13	SB3B	
SBA-		A12		D14	SBB+	
GND		A13		D15	SBB-	
Rx2+		A14		D16	GND	
Rx2-		A15		D17	Tx2+	ITEM 3
GND		A16		D18	Tx2-	ITEM 3
Rx3+		A17		D19	GND	
Rx3-		A18		D20	Tx3+	ITEM 3
GND		A19		D21	Tx3-	ITEM 3
SB04		B1		D22	GND	
SB1A		B2		D23	Tx4+	ITEM 3
SB2A		B3		D24	Tx4-	ITEM 3
SB5A		B4		D25	GND	
SB6A		B5		D26	Rx4+	ITEM 3
GND		B6		D27	Rx4-	ITEM 3
Tx2+		B7		D28	GND	
Tx2-		B8		D29	Tx5+	ITEM 3
GND		B9		D30	Tx5-	ITEM 3
Tx3+		B10		D31	GND	
Tx3-		B11		D32	Tx6+	ITEM 3
GND		B12		D33	Tx6-	ITEM 3
B13		B13		D34	GND	
B14		B14		D35	Tx7+	ITEM 3
B15		B15		D36	Tx7-	ITEM 3
B16		B16		D37	GND	
B17		B17				
B18		B18				
B19		B19				

CONNECTOR SIGNAL	CONNECTOR (HOST)	PIN/PAD	CONNECTOR (TARGET)	PIN/PAD	CONNECTOR SIGNAL	WIRE/CABLE
GND	SO	A19	P1	D3	GND	ITEM 3
Rx4+		A20		D4	Tx0+	ITEM 3
Rx4-		A21		D5	Tx0-	ITEM 3
GND		A22		D6	GND	ITEM 3, NOTE 2
Rx5+		A23		D7	Tx1+	ITEM 3
Rx5-		A24		D8	Tx1-	ITEM 3
GND		A25		D9	GND	ITEM 3
Rx6+		A26		D10	NC	NOTE 5
Rx6-		A27		D11	NC	
GND		A28		D12	GND	ITEM 3
SBB+		A29		D13	REFCLK+	ITEM 3
SBB-		A30		D14	REFCLK-	ITEM 3
GND		A31		D15	GND	ITEM 3
Tx7+		A32		D16	Tx2+	ITEM 3
Tx7-		A33		D17	Tx2-	ITEM 3
GND		A34		D18	GND	ITEM 3, NOTE 2
Tx8+		A35		D19	Tx3+	ITEM 3
Tx8-		A36		D20	Tx3-	ITEM 3
GND		A37		D21	GND	ITEM 3
Tx9+		A38		D22	Tx4+	ITEM 3
Tx9-		A39		D23	Tx4-	ITEM 3
GND		A40		D24	Rx4+	ITEM 3
Rx10+		A41		D25	Rx4-	ITEM 3
Rx10-		A42		D26	GND	ITEM 3
GND		A43		D27	Tx5+	ITEM 3
Tx11+		A44		D28	Tx5-	ITEM 3
Tx11-		A45		D29	GND	ITEM 3
GND		A46		D30	Tx6+	ITEM 3
Tx12+		A47		D31	Tx6-	ITEM 3
Tx12-		A48		D32	GND	ITEM 3
GND		A49		D33	Tx7+	ITEM 3
Tx13+		A50		D34	Tx7-	ITEM 3
Tx13-		A51		D35	GND	ITEM 3
GND		A52		D36	Rx5+	ITEM 3
Tx14+		A53		D37	Rx5-	ITEM 3
Tx14-		A54				

NOTES:


1. END TO END RESISTANCE OF INDICATED CONNECTION SHALL BE 750 MILLIOHM MAX.
2. CONNECT SHIELD OF DIFFERENTIAL PAIR TO INDICATED PIN/PAD AND SHORT TO SECOND INDICATED PIN/PAD.
3. SHORT PIN/PAD S0-A8 TO S0-B9. NO DIRECT CONNECT S0-A8 TO CONNECTOR P0.
4. DELETED
5. SHORT PIN/PAD S0-A26 TO S0-B27. NO DIRECT CONNECT S0-A26 TO CONNECTOR P1.
6. DELETED

Cable 05-60003-00

The following figure shows the drawing and pinout for Broadcom cable 05-60003-00, a x8 SFF-8654 to 2 x4 SFF-8643 connection.

Figure 19: Cable 05-60003-00 Drawing and Pinout

REVISIONS				
REV	ECO	DESCRIPTION	DATE	APPROVED
001		PRELIMINARY RELEASE	28FEB18	
002	175141	UPDATE WIRE GAUGE AND IMPEDANCE REVISE ITEM 3 REVISE MARKING REQUIREMENTS NOTE 3	21NOV19	



1. DRAWING NOT TO SCALE.
2. ELECTRICAL AND MECHANICAL PERFORMANCE SHALL MEET SAS 4.0 INDUSTRIAL STANDARDS.
3. MARK LABEL (ITEM 8) WITH:
SLIMAS Y (SFF-8602 SAS)
BROADCOM PART NUMBER
BROADCOM REVISION XXX
DATE CODE DD/MM/YY
4. SECONDARY MARKING WITH MANUFACTURER PART NUMBER AND REVISION ACCEPTABLE.

4. SEE CABLE WIRING TABLE AND RELATED NOTES.

ITEM	CALLOUT	DESCRIPTION	QUANTITY	NOTES
9	LABEL	LABEL, 40X14MM, WHITE, R2, HF	1	A/R
8	LABEL	LABEL, 70X26MM, WHITE, R2, HF	1	A/R SEE NOTE 3
7	TAPE	ACETATE TAPE: W=1 INCH	1	A/R
6	SLEEVING	EXPANDO TUBE: OD:10MM, BLACK, VW-1, HF	1	A/R
5	SLEEVING	EXPANDO TUBE: OD:10MM, BLACK, VW-1, HF	1	A/R
4	WIRE	UL1061, STRANDED	1	A/R SEE NOTE 4
3	CABLE	SAS CABLE: UL20742, 28-32AWG, 92.5Ω ±0.5Ω, PCIE GEN 4, VW-1, NATURAL, HF	1	A/R
2	CONNECTOR	SFF-8643, 36P, STRAIGHT, X4, BLACK, SHORT, SAS 4.0	2	SEE NOTE 4
1	CONNECTOR	SFF-8654, 74P, STRAIGHT, X8, SAS 4.0, PCIE GEN 4	1	SEE NOTE 4

APPROVALS	DATE	UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN MILLIMETERS. TOLERANCES: X: X ± 0.15 MM Y: Y ± 0.30 MM ANGLES: ± 5°	BROADCOM®
DRAWN BY	15FEB18		
APPROVED BY	28FEB18		
Comments: Confidential © Copyright Broadcom Limited All rights reserved. The person in possession of this document is responsible for verifying that the document is correct and for ensuring that it is not copied or given to any other person. The person in possession of this document is responsible for removing absolute documents from their point of use.			TITLE CABLE, SFF-8654 X8 TO 2X SFF-8643 X4, IM
SCALE	1.500	SIZE D	REV 002
		DWG NO. 5067-6866	Sheet 1

CONNECTOR SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR SIGNAL	WIRE/CABLE	NOTES
GND	S0	A1	P0	D3	GND	ITEM 3	
Rx0+		A2		D4	Tx0+	ITEM 3	
Rx0-		A3		D5	Tx0-	ITEM 3	
GND		A4		C3/D6	GND	ITEM 3 NOTE 2	
Rx1+		A5		C4	Tx1+	ITEM 3	
Rx1-		A6		C5	Tx1-	ITEM 3	
GND		A7		C6	GND	ITEM 3	
SB7A		A8		A2	SB7	ITEM 4 NOTE 1	
SB4A		A9		C2	SB4	ITEM 4 NOTE 1	
SB3A		A10		B2	SB3	ITEM 4 NOTE 1	
SBA+		A11			NC		
SBA-		A12			NC		
GND		A13		D6	GND	ITEM 3	
Rx2+		A14		D7	Tx2+	ITEM 3	
Rx2-		A15		D8	Tx2-	ITEM 3	
GND		A16		D9/C6	GND	ITEM 3 NOTE 2	
Rx3+		A17		C7	Tx3+	ITEM 3	
Rx3-		A18		C8	Tx3-	ITEM 3	
GND		A19		C9	GND	ITEM 3	
GND		B1		B3	GND	ITEM 3	
Tx0+		B2		B4	Rx0+	ITEM 3	
Tx0-		B3		B5	Rx0-	ITEM 3	
GND		B4		B6/A3	GND	ITEM 3 NOTE 2	
Rx3+		B5		A4	Rx1+	ITEM 3	
Rx3-		B6		A5	Rx1-	ITEM 3	
GND		B7		A6	GND	ITEM 3	
SB0A		B8		A1	SB0	ITEM 4 NOTE 1	
SB1A		B9		B1	SB1	ITEM 4 NOTE 1	
SB2A		B10		C1	SB2	ITEM 4 NOTE 1	
SB3A		B11		D2	SB5	ITEM 4 NOTE 1	
SB6A		B12		D1	SB6	ITEM 4 NOTE 1	
GND		B13		B6	GND	ITEM 3	
Rx2+		B14		T4+		ITEM 3	
Rx2-		B15		B7	Rx2+	ITEM 3	
GND		B16		B8	Rx2-	ITEM 3	
Rx3+		B17		B9/A6	GND	ITEM 3 NOTE 2	
Rx3-		B18		A7	Rx3+	ITEM 3	
GND		B19		A8	Rx3-	ITEM 3	


CONNECTOR SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR SIGNAL	WIRE/CABLE	NOTES
GND	S0	A19	P1	D3	GND	ITEM 3	
Rx4+		A20		D4	Tx0+	ITEM 3	
Rx4-		A21		A22		ITEM 3	
GND		A23		C3/D6	GND	ITEM 3 NOTE 2	
Rx5+		A24		C4	Tx1+	ITEM 3	
Rx5-		A25		C5	Tx1-	ITEM 3	
GND		A26		C6	GND	ITEM 3	
SB7B		A27		A2	SB7	ITEM 4 NOTE 1	
SB4B		A28		C2	SB4	ITEM 4 NOTE 1	
SB3B		A29		B2	SB3	ITEM 4 NOTE 1	
SBB+		A30			NC		
SBB-		A31		D6	GND	ITEM 3	
GND		A32		D7	Tx2+	ITEM 3	
Rx6+		A33		D8	Tx2-	ITEM 3	
GND		A34		D9/C6	GND	ITEM 3 NOTE 2	
Rx7+		A35		C7	Tx3+	ITEM 3	
Rx7-		A36		C8	Tx3-	ITEM 3	
GND		A37		C9	GND	ITEM 3	
GND		B19		B3	GND	ITEM 3	
Tx4+		B20		B4	Rx0+	ITEM 3	
Tx4-		B21		B5	Rx0-	ITEM 3	
GND		B22		B6/A3	GND	ITEM 3 NOTE 2	
Rx1+		B23		A4	Rx1+	ITEM 3	
Rx1-		B24		A5	Rx1-	ITEM 3	
GND		B25		A6	GND	ITEM 3	
SB0B		B26		A1	SB0	ITEM 4 NOTE 1	
SB1B		B27		B1	SB1	ITEM 4 NOTE 1	
SB2B		B28		C1	SB2	ITEM 4 NOTE 1	
SB5B		B29		D2	SB5	ITEM 4 NOTE 1	
SB6B		B30		D1	SB6	ITEM 4 NOTE 1	
GND		B31		B6	GND	ITEM 3	
Tx6+		B32		B7	Rx2+	ITEM 3	
Tx6-		B33		B8	Rx2-	ITEM 3	
GND		B34		B9/A6	GND	ITEM 3 NOTE 2	
Rx3+		B35		A7	Rx3+	ITEM 3	
Rx3-		B36		A8	Rx3-	ITEM 3	
GND		B37		A9	GND	ITEM 3	

1. END TO END RESISTANCE OF INDICATED CONNECTION SHALL BE 750 MILLIOHM MAX.
2. CONNECT SHIELD OF DIFFERENTIAL PAIR TO INDICATED PIN/PAD AND SHORT TO SECOND INDICATED PIN/PAD.

Cable 05-60004-00

The following figure shows the drawing and pinout for Broadcom cable 05-60004-00, a x8 SFF-8654 to 2 x4 SFF-8654 connection.

Figure 20: Cable 05-60004-00 Drawing and Pinout



CONNECTOR SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR SIGNAL	WIRE/CABLE
GND	SO	A1	P0	B1	GND	ITEM 3
Rx0+		A2		B2	Tx0+	ITEM 3
Rx0-		A3		B3	Tx0-	ITEM 3
GND		A4		B4	GND	ITEM 3
Rx1+		A5		B5	Tx1+	ITEM 3
Rx1-		A6		B6	Tx1-	ITEM 3
GND		A7		B7	GND	ITEM 3
SB7A		A8		B8	SB7	ITEM 4
SB4A		A9		B9	SB4	ITEM 4
GND(SB3A)		A10	GND(SB3)		GND(SB3)	ITEM 3
SB4+		A11		B11	SB4+	ITEM 3
SB4-		A12		B12	SB4-	ITEM 3
GND		A13		B13	GND	ITEM 3
Rx2+		A14		B14	Tx2+	ITEM 3
Rx2-		A15		B15	Tx2-	ITEM 3
GND		A16		B16	GND	ITEM 3
Rx3+		A17		B17	Tx3+	ITEM 3
Rx3-		A18		B18	Tx3-	ITEM 3
GND		A19		B19	GND	ITEM 3, NOTE 1
B1		A1			GND	ITEM 3
Tx0+		A2			Rx0+	ITEM 3
Tx0-		B3			Rx0-	ITEM 3
GND		B4			GND	ITEM 3
Tx1+		B5			Rx1+	ITEM 3
Tx1-		B6			Rx1-	ITEM 3
GND		B7			GND	ITEM 3
SB0A		B8			SB0	ITEM 4
SB1A		B9			SB1	ITEM 4
GND(SB2A)		B10	GND(SB2)		GND(SB2)	ITEM 3
SB5A		B11			SB5	ITEM 3
SB6A		B12			SB6	ITEM 3
GND		B13			GND	ITEM 3
Tx2+		B14			Tx2+	ITEM 3
Tx2-		B15			Tx2-	ITEM 3
GND		B16			GND	ITEM 3
Tx3+		B17			Tx3+	ITEM 3
Tx3-		B18			Tx3-	ITEM 3
GND		B19			GND	ITEM 3, NOTE 1


CONNECTOR SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR SIGNAL	WIRE/CABLE
GND	SO	A19	P1	B1	GND	ITEM 3, NOTE 1
Rx4+		A20		B2	Tx0+	ITEM 3
Rx4-		A21		B3	Tx0-	ITEM 3
GND		A22		B4	GND	ITEM 3
Rx5+		A23		B5	Tx1+	ITEM 3
Rx5-		A24		B6	Tx1-	ITEM 3
GND		A25		B7	GND	ITEM 3
SB7B		A26		B8	SB7	ITEM 4
SB4B		A27		B9	SB4	ITEM 4
GND(SB3B)		A28		B10	GND(SB3)	ITEM 3
SB4+		A29		B11	SB4+	ITEM 3
SB4-		A30		B12	SB4-	ITEM 3
GND		A31		B13	GND	ITEM 3
Rx6+		A32		B14	Tx2+	ITEM 3
Rx6-		A33		B15	Tx2-	ITEM 3
GND		A34		B16	GND	ITEM 3
Rx7+		A35		B17	Tx3+	ITEM 3
Rx7-		A36		B18	Tx3-	ITEM 3
GND		A37		B19	GND	ITEM 3
B1		A1			GND	ITEM 3, NOTE 1
Tx4+		A2			Rx0+	ITEM 3
Tx4-		A3			Rx0-	ITEM 3
GND		A4			GND	ITEM 3
Rx1+		A5			Rx1+	ITEM 3
Rx1-		A6			Rx1-	ITEM 3
GND		A7			GND	ITEM 3
SB0B		A8			SB0	ITEM 4
SB1B		A9			SB1	ITEM 4
GND(SB2B)		A10			GND(SB2)	ITEM 3
SB5B		A11			SB5	ITEM 3
SB6B		A12			SB6	ITEM 3
GND		A13			GND	ITEM 3
Tx6+		A14			Tx6+	ITEM 3
Tx6-		A15			Tx6-	ITEM 3
GND		A16			GND	ITEM 3
Tx7+		A17			Tx7+	ITEM 3
Tx7-		A18			Tx7-	ITEM 3
GND		A19			GND	ITEM 3

NOTES:
1. PIN/PAD ON CONNECTOR SO SHARED ON CONNECTORS P0 AND P1.

Cable 05-60005-00

The following figure shows the drawing and pinout for Broadcom cable 05-60005-00, a x8 SFF-8654 to 2 U.2 SFF-8639 connection.


Figure 21: Cable 05-60005-00 Drawing and Pinout



Cable 05-60006-00

The following figure shows the drawing and pinout for Broadcom cable 05-60006-00, a x8 SFF-8654 to x8 U.3 SFF-8639 connection.

Figure 22: Cable 05-60006-00 Drawing and Pinout



CONNECTOR SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR SIGNAL	WIRE/CABLE	NOTES
GND	SO HOST	A1	PO TARGET	S7	GND	ITEM 7	
Rx0+		A2		S6	D0_TX0+	ITEM 7	
Rx0-		A3		S5	D0_TX0-	ITEM 7	
GND		A4		S4	GND	ITEM 7	NOTE 2, NOTE 3
GND		B1		S1	GND	ITEM 7	
Tx0+		B2		S2	D0_RX0+	ITEM 7	
Tx0-		B3		S3	D0_RX0-	ITEM 7	
GND		B4		S4	GND	ITEM 7	NOTE 2, NOTE 3
12V	P10	1	PO TARGET	P13, P14, P15	12V	ITEM 9	YELLOW
GND		2		P12	GND	ITEM 9	BLACK
GND		3		P5, P6	GND	ITEM 9	BLACK
5V		4		P7, P8, P9	5V	ITEM 9	RED
NC			PO TARGET	P1	RSVD		NOTE 4
NC				P2	sPCIeRst		NOTE 4

CONNECTOR SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR SIGNAL	WIRE/CABLE	NOTES
GND	SO HOST	A4	PO TARGET	S7	D1_TX0+	ITEM 7	NOTE 2
Rx1+		A5		S6	D1_TX0-	ITEM 7	
Rx1-		A6		S5	D1_TX0-	ITEM 7	
GND		A7		S4	GND	ITEM 7	NOTE 3
GND		B4		S1	GND	ITEM 7	NOTE 2
Tx1+		B5		S2	D1_RX0+	ITEM 7	
Tx1-		B6		S3	D1_RX0-	ITEM 7	
GND		B7		S4	GND	ITEM 7	NOTE 3
12V	P11	1	PI TARGET	P13, P14, P15	12V	ITEM 9	YELLOW
GND		2		P12	GND	ITEM 9	BLACK
GND		3		P5, P6	GND	ITEM 9	BLACK
5V		4		P7, P8, P9	5V	ITEM 9	RED
NC			PI TARGET	P1	RSVD		NOTE 4
NC				P2	sPCIeRst		NOTE 4

CONNECTOR SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR SIGNAL	WIRE/CABLE	NOTES
GND	SO HOST	A13	P2 TARGET	S7	GND	ITEM 7	
Rx2+		A14		S6	D2_TX0+	ITEM 7	
Rx2-		A15		S5	D2_TX0-	ITEM 7	
GND		A16		S4	GND	ITEM 7	NOTE 3
GND		B13		S1	GND	ITEM 7	
Tx2+		B14		S2	D2_RX0+	ITEM 7	
Tx2-		B15		S3	D2_RX0-	ITEM 7	
GND		B16		S4	GND	ITEM 7	NOTE 2, NOTE 3
12V	P12	1	P2 TARGET	P13, P14, P15	12V	ITEM 9	YELLOW
GND		2		P12	GND	ITEM 9	BLACK
GND		3		P5, P6	GND	ITEM 9	BLACK
5V		4		P7, P8, P9	5V	ITEM 9	RED
NC			P2 TARGET	P1	RSVD		NOTE 4
NC				P2	sPCIeRst		NOTE 4

CONNECTOR SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR SIGNAL	WIRE/CABLE	NOTES
GND	SO HOST	A31	P6 TARGET	S7	GND	ITEM 7	
Rx6+		A32		S6	D6_TX0+	ITEM 7	
Rx6-		A33		S5	D6_TX0-	ITEM 7	
GND		A34		S4	GND	ITEM 7	NOTE 2, NOTE 3
GND		B31		S1	GND	ITEM 7	
Tx6+		B32		S2	D6_RX0+	ITEM 7	
Tx6-		B33		S3	D6_RX0-	ITEM 7	
GND		B34		S4	GND	ITEM 7	NOTE 2, NOTE 3
12V	P16	1	P6 TARGET	P13, P14, P15	12V	ITEM 9	YELLOW
GND		2		P12	GND	ITEM 9	BLACK
GND		3		P5, P6	GND	ITEM 9	BLACK
5V		4		P7, P8, P9	5V	ITEM 9	RED
NC			P6 TARGET	P1	RSVD		NOTE 4
NC				P2	sPCIeRst		NOTE 4

CONNECTOR SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR SIGNAL	WIRE/CABLE	NOTES
GND	SO HOST	A34	P7 TARGET	S7	GND	ITEM 7	NOTE 2
Rx7+		A35		S6	D7_TX0+	ITEM 7	
Rx7-		A36		S5	D7_TX0-	ITEM 7	
GND		A37		S4	GND	ITEM 7	NOTE 3
GND		B34		S1	GND	ITEM 7	NOTE 2
Tx7+		B35		S2	D7_RX0+	ITEM 7	
Tx7-		B36		S3	D7_RX0-	ITEM 7	
GND		B37		S4	GND	ITEM 7	NOTE 3
12V	P17	1	P7 TARGET	P13, P14, P15	12V	ITEM 9	YELLOW
GND		2		P12	GND	ITEM 9	BLACK
GND		3		P5, P6	GND	ITEM 9	BLACK
5V		4		P7, P8, P9	5V	ITEM 9	RED
NC			P7 TARGET	P1	RSVD		NOTE 4
NC				P2	sPCIeRst		NOTE 4

CONNECTOR SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR SIGNAL	WIRE/CABLE	NOTES
SBTA	SO HOST	A8	P8	8	BP_TYPEA	ITEM 8	NOTE 1, BLUE
SBAA		A9	P8	4	SDOA	ITEM 8	NOTE 1, YELLOW
GND/SB3A		A10	P8	6	GND	ITEM 8	NOTE 1, BROWN
SBA+		A11			NC		
SBA-		A12			NC		
SBOA		B8	P8	7	SLCKA	ITEM 8	NOTE 1, ORANGE
SBIA		B9	P8	5	SLDA	ITEM 8	NOTE 1, PINK
GND/SB2A		B10	P8	3	GND	ITEM 8	NOTE 1, BLACK
SB5A		B11	P8	2	SDIA	ITEM 8	NOTE 1, GREEN
SB6A		B12	P8	1	CTLR_TYPEA	ITEM 8	NOTE 1, WHITE
SB7B	SO HOST	A26	P9	8	BP_TYPEB	ITEM 8	NOTE 1, BLUE
SB4B		A27	P9	4	SDOB	ITEM 8	NOTE 1, YELLOW
GND/SB3B		A28	P9	6	GND	ITEM 8	NOTE 1, BROWN
SBB+		A29			NC		
SBB-		A30			NC		
SB0B		B26	P9	7	SLCKB	ITEM 8	NOTE 1, ORANGE
SB1B		B27	P9	5	SLDB	ITEM 8	NOTE 1, PINK
GND/SB2B		B28	P9	3	GND	ITEM 8	NOTE 1, BLACK
SB5B		B29	P9	2	SDIB	ITEM 8	NOTE 1, GREEN
SB6B		B30	P9	1	CTLR_TYPEB	ITEM 8	NOTE 1, WHITE

CONNECTOR SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR SIGNAL	WIRE/CABLE	NOTES
GND	SO HOST	A16	S7		SIT+		
Rx3+		A17	S6		SIT-		
Rx3-		A18	S5		SIR-		
GND		A19	S4		SIR+		
Tx3+		B16	S1		S2T+		
Tx3-		B17	S2		S2T-		
GND		B18	S3		S2R+		
GND		B19	S4		S2R*		
12V	P13	1	P13, P14, P15		12V	ITEM 9	YELLOW
GND		2		P12	GND	ITEM 9	BLACK
GND		3		P5, P6	GND	ITEM 9	BLACK
5V		4		P7, P8, P9	5V	ITEM 9	RED
NC			P1 TARGET	P1	RSVD		NOTE 4
NC				P2	sPCIeRst		NOTE 4

CONNECTOR SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR SIGNAL	WIRE/CABLE	NOTES
GND	SO HOST	A16	P3 TARGET	S7	GND	ITEM 7	NOTE 2
Rx3+		A17	P3 TARGET	S6	D3_TX0+	ITEM 7	
Rx3-		A18	P3 TARGET	S5	D3_TX0-	ITEM 7	
GND		A19	P3 TARGET	S4	GND	ITEM 7	NOTE 2, NOTE 3
Tx3+		B16	P3 TARGET	S1	GND	ITEM 7	
Tx3-		B17	P3 TARGET	S2	D3_RX0+	ITEM 7	
GND		B18	P3 TARGET	S3	D3_RX0-	ITEM 7	
GND		B19	P3 TARGET	S4	GND	ITEM 7	NOTE 2, NOTE 3
12V	P13	1	P3 TARGET	P13, P14, P15	12V	ITEM 9	YELLOW
GND		2		P12	GND	ITEM 9	BLACK
GND		3		P5, P6	GND	ITEM 9	BLACK
5V		4		P7, P8, P9	5V	ITEM 9	RED
NC			P3 TARGET	P1	RSVD		NOTE 4
NC				P2	sPCIeRst		NOTE 4

CONNECTOR SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR SIGNAL	WIRE/CABLE	NOTES
GND	SO HOST	A19	P4 TARGET	S7	GND	ITEM 7	NOTE 2
Rx4+		A20	P4 TARGET	S6	D4_TX0+	ITEM 7	
Rx4-		A21	P4 TARGET	S5	D4_TX0-	ITEM 7	
GND		A22	P4 TARGET	S4	GND	ITEM 7	NOTE 3
Tx4+		B19	P4 TARGET	S1	GND	ITEM 7	NOTE 2
Tx4-		B20	P4 TARGET	S2	D4_RX0+	ITEM 7	
GND		B21	P4 TARGET	S3	D4_RX0-	ITEM 7	
GND		B22	P4 TARGET	S4	GND	ITEM 7	NOTE 3
12V	P14	1	P4 TARGET	P13, P14, P15	12V	ITEM 9	YELLOW
GND		2		P12	GND	ITEM 9	BLACK
GND		3		P5, P6	GND	ITEM 9	BLACK
5V		4		P7, P8, P9	5V	ITEM 9	RED
NC			P4 TARGET	P1	RSVD		NOTE 4
NC				P2	sPCIeRst		NOTE 4


CONNECTOR SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR SIGNAL	WIRE/CABLE	NOTES
GND	SO HOST	A22	P5 TARGET	S7	GND	ITEM 7	NOTE 2
Rx5+		A23	P5 TARGET	S6	D5_TX0+	ITEM 7	
Rx5-		A24	P5 TARGET	S5	D5_TX0-	ITEM 7	
GND		A25	P5 TARGET	S4	GND	ITEM 7	NOTE 3
Tx5+		B22	P5 TARGET	S1	GND	ITEM 7	NOTE 2
Tx5-		B23	P5 TARGET	S2	D5_RX0+	ITEM 7	
GND		B24	P5 TARGET	S3	D5_RX0-	ITEM 7	
GND		B25	P5 TARGET	S4	GND	ITEM 7	NOTE 3
12V	P15	1	P5 TARGET	P13, P14, P15	12V	ITEM 9	YELLOW
GND	</td						

Cable 05-60007-00

The following figure shows the drawing and pinout for Broadcom cable 05-60007-00, a x8 SFF-8654 to x8 SFF-8654 connection.

Figure 23: Cable 05-60007-00 Drawing and Pinout

REVISIONS				
REV	ECO	DESCRIPTION	DATE	APPROVED
001		PRELIMINARY RELEASE	01MAY18	
002	175141	ADD WIRE GAUGE AND IMPEDANCE TOLERANCE ITEM 2. REVISE MARKING REQUIREMENTS NOTE 3.	21NOV19	



NOTES:

1. DRAWING NOT TO SCALE.
2. ELECTRICAL AND MECHANICAL PERFORMANCE SHALL MEET SAS 0.4 AND PCIE GEN 4 INDUSTRIAL SPECIFICATIONS.
3. MARK LABEL (ITEM 6) WITH:
SFF-9402 SAS/PCIE 4
BROADCOM PART NUMBER
BROADCOM FIRMWARE XX
DATE CODE DD/MM/YY
SECONDARY MARKING WITH MANUFACTURER PART NUMBER AND REVISION ACCEPTABLE.
4. SEE CABLE WIRING TABLE AND RELATED NOTES.

6	LABEL	LABEL, 70X26MM, WHITE, R2, HF	A/R	SEE NOTE 3
5	TAPE	ACETATE TAPE - W/1 INCH	A/R	
4	SLEEVING	EXPAND TUBE: OD-10MM, GREEN, VW-1, HF	A/R	
3	WIRE	UL1061, STRANDED	A/R	SEE NOTE 4
2	CABLE	SAS CABLE: UL20744, 28-32AWG, 92.5Ω ±10% DIFF, SAS4, PCIE GEN 4, VW-1, NATURAL, HF	A/R	
1	CONNECTOR	SFF-8654, 7AP, STRAIGHT, X8, STANDARD, SAS 4.0, PCIE GEN 4	2	SEE NOTE 4
ITEM	CALLOUT	DESCRIPTION	QUANTITY	NOTES

APPROVALS	DATE	UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN MILLIMETERS.		BROADCOM®		
DRAWN BY	15FEB18	DIMENSIONS		TITLE		
APPROVED BY	01MAY18	T.X. \pm 0.2 MM		CABLE, SFF-8654 TO SFF-8654,		
Company Confidential - Copyright Broadcom Corporation 2018		T.Y. \pm 0.2 MM		X8, STRAIGHT, 1M		
All rights reserved. Reproduction in whole or in part is prohibited.		T.X.X \pm 0.200 MM				
The possessor is responsible for verifying that the		ANGLES \pm 1°				
dimensions and tolerances are correct for the						
particular application.						
possessor is responsible for establishing						
the correct application of the part.						
In no event shall the possessor be liable for						
any damages resulting from the use of this						
part.						
		SCALE	2.000	DIAG	D	REV. NO.
					5067-6869	002
					SHEET	

CONNECTOR	SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR	SIGNAL	WIRE/CABLE	NOTES
GND		SO	A1	P0	B1	GND	ITEM 3		
Rx0+			A2		B2	Tx0+	ITEM 3		
Rx0-			A3		B3	Tx0-	ITEM 3		
GND			A4		B4	GND	ITEM 3		
Rx1+			A5		B5	Tx1+	ITEM 3		
Rx1-			A6		B6	Tx1-	ITEM 3		
GND			A7		B7	GND	ITEM 3		
SB7A			A8		B8	SB7A	ITEM 4	NOTE 1	
SB4A			A9		B9	SB4A	ITEM 4	NOTE 1	
GND/SB3A			A10		B10	GND/SB3A	ITEM 3		
SBA+			A11		B11	SBA+	ITEM 3		
SBA-			A12		B12	SBA-	ITEM 3		
GND			A13		B13	GND	ITEM 3		
Rx2+			A14		B14	Tx2+	ITEM 3		
Rx2-			A15		B15	Tx2-	ITEM 3		
GND			A16		B16	GND	ITEM 3		
Rx3+			A17		B17	Tx3+	ITEM 3		
Rx3-			A18		B18	Tx3-	ITEM 3		
GND			A19		B19	GND	ITEM 3		
Rx4+			A20		B20	Tx4+	ITEM 3		
Rx4-			A21		B21	Tx4-	ITEM 3		
GND			A22		B22	GND	ITEM 3		
Rx5+			A23		B23	Tx5+	ITEM 3		
Rx5-			A24		B24	Tx5-	ITEM 3		
GND			A25		B25	GND	ITEM 3		
SB7B			A26		B26	SB7B	ITEM 4	NOTE 1	
SB4B			A27		B27	SB4B	ITEM 4	NOTE 1	
GND/SB3B			A28		B28	GND/SB3B	ITEM 3		
SBB+			A29		B29	SBB+	ITEM 3		
SBB-			A30		B30	SBB-	ITEM 3		
GND			A31		B31	GND	ITEM 3		
Rx6+			A32		B32	Tx6+	ITEM 3		
Rx6-			A33		B33	Tx6-	ITEM 3		
GND			A34		B34	GND	ITEM 3		
Rx7+			A35		B35	Tx7+	ITEM 3		
Rx7-			A36		B36	Tx7-	ITEM 3		
GND			A37		B37	GND	ITEM 3		

CONNECTOR SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR SIGNAL	WIRE/CABLE	NOTES
GND	S0	B1	P0	A1	GND	ITEM 3	
Tx0+		B2		A2	Rx0+	ITEM 3	
Tx0-		B3		A3	Rx0-	ITEM 3	
GND		B4		A4	GND	ITEM 3	
Tx1+		B5		A5	Rx1+	ITEM 3	
Tx1-		B6		A6	Rx1-	ITEM 3	
GND		B7		A7	GND	ITEM 3	
SB0A		B8		A8	SB0A	ITEM 4	NOTE 1
SB1A		B9		A9	SB1A	ITEM 4	NOTE 1
GND/SB2A		B10		A10	GND/SB2A	ITEM 3	
SB5A		B11		A11	SB5A	ITEM 3	
SB6A		B12		A12	SB6A	ITEM 3	
GND		B13		A13	GND	ITEM 3	
Tx2+		B14		A14	Rx2+	ITEM 3	
Tx2-		B15		A15	Rx2-	ITEM 3	
GND		B16		A16	GND	ITEM 3	
Tx3+		B17		A17	Rx3+	ITEM 3	
Tx3-		B18		A18	Rx3-	ITEM 3	
GND		B19		A19	GND	ITEM 3	
Tx4+		B20		A20	Rx4+	ITEM 3	
Tx4-		B21		A21	Rx4-	ITEM 3	
GND		B22		A22	GND	ITEM 3	
Tx5+		B23		A23	Rx5+	ITEM 3	
Tx5-		B24		A24	Rx5-	ITEM 3	
GND		B25		A25	GND	ITEM 3	
SB0B		B26		A26	SB0B	ITEM 4	NOTE 1
SB1B		B27		A27	SB1B	ITEM 4	NOTE 1
GND/SB2B		B28		A28	GND/SB2B	ITEM 3	
SB5B		B29		A29	SB5B	ITEM 3	
SB6B		B30		A30	SB6B	ITEM 3	
GND		B31		A31	GND	ITEM 3	
Tx6+		B32		A32	Rx6+	ITEM 3	
Tx6-		B33		A33	Rx6-	ITEM 3	
GND		B34		A34	GND	ITEM 3	
Tx7+		B35		A35	Rx7+	ITEM 3	
Tx7-		B36		A36	Rx7-	ITEM 3	
GND		B37		A37	GND	ITEM 3	

NOTES:

1. END TO END RESISTANCE OF INDICATED CONNECTION SHALL BE 750 MILLIOHM MAX.

Revision History

Version 2.15, January 26, 2026

- Updated the figure and dimensions in [MegaRAID 9524-8i Adapter: Connector and LED Designations](#).
- Updated the USA / Canada Safety logo in [Marks, Certifications, and Compliance](#).
- Removed the United Kingdom (UKCA) information from [Marks, Certifications, and Compliance](#).

Version 2.14, August 20, 2025

- Updated [MegaRAID 9524-8i Adapter: Connector and LED Designations](#).
- Added [Board Weights](#).
- Updated the Taiwan (BSMI) mark in [Marks, Certifications, and Compliance](#).

Version 2.13, March 6, 2025

- Updated the MegaRAID Tri-Mode Storage Adapter (without DDR) Features table in [Overview](#).
- Added the MegaRAID 9520-8i adapter.

Version 2.6, October 21, 2024

- Restructured [Board Storage Conditions](#).
- Added [Board Operating Conditions](#).

Version 2.12, September 26, 2024

- Added [Taiwan BSMI Compliance](#).

Version 2.11, August 27, 2024

- Updated the marks and certifications in [Marks, Certifications, and Compliance](#).
- Added the 9524-8i adapter.

Version 2.10, December 20, 2023

- Updated the following layout figures in [Broadcom MegaRAID and HBA Tri-Mode Storage Adapter Characteristics](#): 9500-8i, 9560-16i, 9560-8i, 9540-8i, 9500-16i.
- Added [FCC Compliance](#).

Version 2.9, April 6, 2023

Updated the adapter dimensions in [Broadcom MegaRAID and HBA Tri-Mode Storage Adapter Characteristics](#).

Version 2.8, February 7, 2023

- Added NVMe support to the MegaRAID 9540-8i adapter.

Version 2.7, November 22, 2022

- Added [VCCI – Japan](#).

Version 2.6, August 29, 2022

- Revised RAID levels in [RAID Features](#).
- Updated the 05-60006-00 description in [Storage Interface Cabling](#).

Version 2.5, January 13, 2022

- Updated the values regarding the CacheVault power module in [MegaRAID Tri-Mode Storage Adapter Power Supply Requirements](#).
- Added [Adapter Security](#).
- Updated HBA model information in [Marks, Certifications, and Compliance](#).
- Added the MegaRAID 9562-16i and HBA 9502-16i OCP adapters.
- Added the MegaRAID 9540-8i adapter.

Version 2.4, August 25, 2020

- Updated the Sideband Signal Pinout table in [Sideband Signals](#).
- Updated [CacheVault Data Protection](#).

Version 2.3, May 1, 2020

- Updated [PCIe \(NVMe\) Support](#).

Version 2.2, March 17, 2020

- Added connector identifiers to the drawings in [Broadcom MegaRAID and HBA Tri-Mode Storage Adapter Characteristics](#).
- Template update.

Version 2.1, February 12, 2020

- Changed the relative humidity range and temperature range for operating conditions in [Board Storage Conditions](#).
- Updated the cable drawing in [Cable 05-60002-00](#).
- Added [Cable 05-60006-00](#) and [Cable 05-60007-00](#).

Version 2.0, December 17, 2019

- Updated [Operating System Support](#).
- Removed Backplanes with Mini-SAS HD Connectors.
- Updated [Figure 5](#).
- Added [External Adapter Connector Pinout](#), [Virtual Pin Port Management](#), [Sideband Signals](#), and [Cable Drawings and Pinouts](#).
- Updated board dimensions in [HBA 9500-16e Adapter: Connector and LED Designations](#), and [HBA 9500-8e Adapter: Connector and LED Designations](#).
- Updated connector and LED locations in [MegaRAID 9580-8i8e Adapter: Connector and LED Designations](#).

Preliminary, Version 1.0, September 27, 2018

Initial document release.

