



# **Broadcom<sup>®</sup> 96xx PCIe 4.0, 24G SAS MegaRAID<sup>™</sup> and eHBA Tri-Mode Storage Adapters**

**User Guide  
Version 2.6**

## Documentation Legal Notice

---

Copyright © 2020–2024 Broadcom. All Rights Reserved. The term “Broadcom” refers to Broadcom Inc. and/or its subsidiaries. For more information, go to [www.broadcom.com](http://www.broadcom.com). All trademarks, trade names, service marks, and logos referenced herein belong to their respective companies.

Broadcom reserves the right to make changes without further notice to any products or data herein to improve reliability, function, or design. Information furnished by Broadcom is believed to be accurate and reliable. However, Broadcom does not assume any liability arising out of the application or use of this information, nor the application or use of any product or circuit described herein, neither does it convey any license under its patent rights nor the rights of others.

# Table of Contents

<b>Overview</b> .....	<b>5</b>
<b>Features</b> .....	<b>7</b>
<b>RAID and eHBA Features</b> .....	<b>7</b>
MegaRAID 9670W-16i, 9670-24i, and 9660-16i Adapter RAID Features.....	7
MegaRAID 9620-16i eHBA Features.....	7
eHBA 9600 Adapter Features.....	8
<b>Operating System Support</b> .....	<b>8</b>
<b>PCIe Host Interface</b> .....	<b>9</b>
<b>LED Management</b> .....	<b>9</b>
<b>Tri-Mode Storage Interface Features</b> .....	<b>9</b>
<b>Tri-Mode Storage Interface</b> .....	<b>11</b>
<b>SAS/SATA Support</b> .....	<b>11</b>
<b>PCIe (NVMe) Support</b> .....	<b>12</b>
<b>Common REFCLK Support</b> .....	<b>16</b>
<b>Backplane Management</b> .....	<b>17</b>
<b>Universal Backplane Management</b> .....	<b>17</b>
<b>Virtual Pin Port Management</b> .....	<b>17</b>
<b>Sideband Signals</b> .....	<b>17</b>
<b>Cables and Cabling Configurations</b> .....	<b>20</b>
<b>Internal Adapter Connector Pinout</b> .....	<b>20</b>
Storage Interface Cabling.....	21
<b>Backplane Connectors</b> .....	<b>22</b>
<b>External Adapter Connector Pinout</b> .....	<b>22</b>
<b>CacheVault Data Protection</b> .....	<b>24</b>
<b>Adapter Security</b> .....	<b>25</b>
<b>Hardware Secure Boot</b> .....	<b>25</b>
<b>Device Authentication</b> .....	<b>25</b>
Device Certificate.....	26
<b>Attestation Procedure</b> .....	<b>26</b>
<b>SPDM Capabilities</b> .....	<b>26</b>
<b>Adapter Installation Instructions</b> .....	<b>28</b>
<b>Adapter Installation</b> .....	<b>28</b>
<b>OCP Adapter Installation</b> .....	<b>30</b>
Removing the OCP Adapter.....	31
<b>Broadcom MegaRAID and HBA Tri-Mode Storage Adapter Characteristics</b> .....	<b>32</b>

<b>MegaRAID 9670W-16i Adapter – Connector and LED Designations.....</b>	<b>32</b>
<b>MegaRAID 9670-24i Adapter – Connector and LED Designations.....</b>	<b>33</b>
Auxiliary Power Connector.....	35
<b>MegaRAID 9660-16i Adapter – Connector and LED Designations.....</b>	<b>36</b>
<b>eHBA 9620-16i Adapter – Connector and LED Designations.....</b>	<b>38</b>
<b>eHBA 9600-24i Adapter – Connector and LED Designations.....</b>	<b>40</b>
<b>eHBA 9600-16i Adapter – Connector and LED Designations.....</b>	<b>42</b>
<b>eHBA 9600-8i8e Adapter – Connector and LED Designations.....</b>	<b>43</b>
<b>eHBA 9600W-16e Adapter – Connector and LED Designations.....</b>	<b>45</b>
<b>eHBA 9600-16e Adapter – Connector and LED Designations.....</b>	<b>46</b>
<b>eHBA 9602W-16e Adapter – Connector and LED Designations.....</b>	<b>48</b>
<b>Tri-Mode Storage Adapter Technical Specifications.....</b>	<b>49</b>
Board Storage Conditions.....	49
Board Operating Conditions.....	49
Power Supply Requirements.....	50
MegaRAID Tri-Mode Storage Adapter Power Supply Requirements.....	50
eHBA Tri-Mode Storage Adapter Power Supply Requirements.....	50
Overtemperature Behavior.....	51
<b>Marks, Certifications, Compliance, and Safety Characteristics.....</b>	<b>52</b>
Marks, Certifications, and Compliance.....	52
FCC Compliance.....	54
Safety Characteristics.....	54
<b>Appendix A: Cable Drawings and Pinouts.....</b>	<b>55</b>
Cable 05-60001-00.....	55
Cable 05-60002-00.....	57
Cable 05-60003-00.....	58
Cable 05-60004-00.....	59
Cable 05-60005-00.....	60
Cable 05-60006-00.....	61
Cable 05-60007-00.....	63
Cable 05-60009-00.....	64
<b>Appendix B: Revision History.....</b>	<b>65</b>

## Overview

The Broadcom® 96xx adapters, based on a 24G SAS tri-mode controller, are high-performance PCIe-to-SATA/SAS/PCIe (tri-mode) storage adapters. Broadcom tri-mode SerDes technology enables operation of SAS, SATA, or PCIe (NVMe) storage devices in a single drive bay. A single controller can operate in all three modes concurrently: SAS, SATA, and PCIe/NVMe. The adapters negotiate between the speeds and the protocols to recognize and concurrently interface with these three storage devices types.

The adapters provide the following storage interface data transfer rates:

- SAS data transfer rates of 22.5Gb/s, 12Gb/s, and 6Gb/s per phy
- SATA transfer rates at 6Gb/s per phy
- PCIe (NVMe) data transfer rates of 16 GT/s, 8 GT/s, 5 GT/s, and 2.5 GT/s per lane

The following tables summarize key adapter features.

**Table 1: MegaRAID Tri-Mode Storage Adapter and eHBA 9620-16i Features**

Adapter	9670W-16i	9670-24i	9660-16i	9620-16i
Ports	16 internal	24 internal	16 internal	16 internal
I/O Processor	SAS4116W	SAS4124	SAS4116	SAS4016
Host Interface	x16 PCIe 4.0	x8 PCIe 4.0	x8 PCIe 4.0	x8 PCIe 4.0
Storage Interface	SAS, SATA, and PCIe (NVMe)	SAS, SATA, and PCIe (NVMe)	SAS, SATA, and PCIe (NVMe)	SAS, SATA, and PCIe (NVMe)
Form Factor	FH-MD2	FH-MD2	LP-MD2	LP-MD2
RAID Levels	0, 1, 5, and 6	0, 1, 5, and 6	0, 1, 5, and 6	0 and 1
Cache Memory	8 GB, dual channel, 3200 MT/s, DDR4 SDRAM	8 GB, single channel, 3200 MT/s, DDR4 SDRAM	4 GB, single channel, 3200 MT/s, DDR4 SDRAM	—
Storage Interface Connectors	Two SFF-8654 x8	Three SFF-8654 x8	Two SFF-8654 x8	Two SFF-8654 x8
Cache Protection	Yes	Yes	Yes	—
Energy Backup	CVPM05 module	CVPM05 module	CVPM05 module	—

**Table 2: eHBA Internal Tri-Mode Storage Adapter Features**

Adapter	9600-24i	9600-16i	9600-8i8e
Ports	24 internal	16 internal	8 internal 8 external
I/O Processor	SAS4024	SAS4016	SAS4016
Host Interface	x8 PCIe 4.0	x8 PCIe 4.0	x8 PCIe 4.0
Form Factor	LP-MD2	LP-MD2	LP-MD2
Storage Interface	SAS, SATA, and PCIe (NVMe)	SAS, SATA, and PCIe (NVMe)	SAS, SATA, and PCIe (NVMe)
Storage Interface Connectors	Three SFF-8654 x8	Two SFF-8654 x8	One SFF-8654 x8 Two SFF-8674 x4

**Table 3: eHBA External Tri-Mode Storage Adapter Features**

<b>Adapter</b>	<b>9600W-16e</b>	<b>9600-16e</b>	<b>9602W-16e</b>
<b>Ports</b>	16 external	16 external	16 external
<b>I/O Processor</b>	SAS4016W	SAS4016	SAS4016W
<b>Host Interface</b>	x16 PCIe 4.0	x8 PCIe 4.0	x16 PCIe 4.0
<b>Form Factor</b>	LP-MD2	LP-MD2	TSFF
<b>Storage Interface</b>	SAS, SATA, and PCIe	SAS, SATA, and PCIe	SAS, SATA, and PCIe
<b>Storage Interface Connectors</b>	Four SFF-8674 x4	Four SFF-8674 x4	Four SFF-8674 x4

# Features

---

This chapter describes the features that the adapters support.

## RAID and eHBA Features

The following sections list primary RAID and eHBA features that the adapters support. For a full description of the RAID features, refer to the *MegaRAID Tri-Mode Software User Guide*, which can be found in the [Support Documents and Downloads](#) section of the Broadcom website.

### MegaRAID 9670W-16i, 9670-24i, and 9660-16i Adapter RAID Features

The MegaRAID adapters support the following RAID features:

- RAID levels 0, 1, 5, and 6
- RAID spans 10, 50, and 60
- SAS/SATA drives: 240
- NVMe SSDs: 32
- JBOD physical drive (PD) state for SDS environments
- Online Capacity Expansion (OCE)
- Auto resume after loss of system power during array rebuild or OCE
- Single controller multipathing
- Load balancing
- Fast initialization for quick array setup
- Check consistency for background data integrity
- SSD support with SSD Guard™ technology
- Patrol read for media scanning and repairing
- Sixty-four virtual drive support
- Disk data format (DDF)-compliant Configuration on Disk (COD)
- Self-Monitoring, Analysis, and Reporting Technology (SMART) support
- Global and dedicated hot spare with revertible hot spare support:
  - Automatic rebuild
  - Enclosure affinity
  - Emergency SATA hot spare for SAS arrays
- Enclosure management support:
  - Universal Backplane Management (UBM)
  - SES (inband)
  - SGPIO (sideband)
  - Virtual Pin Port (VPP)
- DataBolt bandwidth optimizer technology support for compatible expander-based enclosures
- Shield state drive diagnostic technology
- MegaRAID SafeStore™ software for SED key management

### MegaRAID 9620-16i eHBA Features

The MegaRAID 9620-16i adapter supports the following features:

- RAID levels 0 and 1
- RAID span 10
- SAS/SATA drives: 32
- NVMe SSDs: 32
- JBOD PD state for SDS environments
- Single controller multipathing
- Load balancing
- Fast initialization for quick array setup
- Check consistency for background data integrity
- SSD support with SSD Guard technology
- Patrol read for media scanning and repairing
- Four virtual drive support
- DDF-compliant COD
- SMART support
- Global and dedicated hot spare with revertible hot spare support:
  - Automatic rebuild
  - Emergency SATA hot spare for SAS arrays
- Enclosure management support:
  - UBM
  - SES (inband)
  - SGPIO (sideband)
  - VPP
- DataBolt bandwidth optimizer technology support for compatible expander-based enclosures
- Shield state drive diagnostic technology
- MegaRAID SafeStore software for SED key management

## eHBA 9600 Adapter Features

The eHBA 9600 adapters support the following eHBA features:

- SAS/SATA devices: 240
- NVMe SSDs: 32
- Shingled magnetic recording (SMR) drive support
- Multi-actuator drive support

## Operating System Support

The tri-mode storage adapters support the operating systems in the following list.

For specific version information, refer to the *MegaRAID Tri-Mode Device Driver Installation User Guide*, which you can download from [Support Documents and Downloads](#).



- Microsoft Windows
- VMware® vSphere®/ESXi
- Red Hat Enterprise Linux
- SuSE Linux
- Ubuntu Linux
- Citrix XenServer
- CentOS Linux
- Debian Linux
- Oracle Enterprise Linux
- Fedora
- FreeBSD

Firmware and drivers are routinely updated. Visit the Broadcom [Support Documents and Downloads](#) page to download the latest firmware and driver for the adapter.

## PCIe Host Interface

The adapter's PCIe 4.0 host interface provides maximum transmission and reception rates of up to 16 GT/s per lane. The tri-mode controller uses a packet-based communication protocol to communicate over the serial interconnect. Other PCIe host interface features include the following:

- Eight-lane or sixteen-lane PCIe host interface
- PCIe hot plug
- Power management:
  - Supports the *PCI Bus Power Management Interface Specification Revision 1.2*
  - Supports Active State Power Management, including the L0 states, by placing links in a power-saving mode during times of no link activity
- Error handling
- High bandwidth per pin with low overhead and low latency
- Lane reversal and polarity inversion
- Single-phy (one-lane) link transfer rate of 16 GT/s, 8 GT/s, 5 GT/s, and 2.5 GT/s in each direction
- Eight-lane aggregate bandwidth of up to 16GB/s
- Sixteen-lane aggregate bandwidth of up to 32GB/s
- Support for x16, x8, x4, x2, and x1 link widths

## LED Management

Broadcom adapter LED management support differs between internal and external connecting adapters.

The internal adapters offer LED management support for SAS/SATA backplanes and (PCIe) NVMe backplanes. External connect adapters offer enclosure LED management support for enclosure implementations through SES. See [Backplane Management](#) for more information.

## Tri-Mode Storage Interface Features

The adapter's storage interface supports concurrent operation with SAS, SATA, and PCIe (NVMe) devices to provide a fully functional solution for any storage environment:

- PCIe (NVMe) interface features:

- Up to sixteen x1, eight x2, or four x4 NVMe direct-attach drive support
- Data transfer at 16 GT/s, 8 GT/s, 5 GT/s, and 2.5 GT/s
- Independent resets and configuration
- Common reference clock and separate reference clock independent SSC (SRIS) support
- SAS features:
  - SAS data transfers at 22.5Gb/s, 12Gb/s, and 6Gb/s
  - DataBolt technology on all SAS phys to improve performance
  - Serial, point-to-point, enterprise-level storage interface
  - Wide ports that contain multiple phys
  - Narrow ports that contain a single phy
  - SAS phy power management
  - Data transfer by using SCSI information units
  - T10 data protection management
  - Support for persistent connection capability
  - Support for SPL-3 initiate close capability
  - Configurable Rx and Tx polarity inversion
  - Configurable phy-to-disk mapping
  - Configurable SSC
- SATA interface features:
  - SATA and STP data transfers at 6Gb/s
  - Addressing of multiple SATA targets through an expander

## Tri-Mode Storage Interface

The adapter uses one or two CSW blocks for the storage interface.

The tri-mode interface groups phys into the CSW blocks that contain 16 phys each. Limitations exist on how the phys can be grouped to create wide ports for SAS/SATA or multilane ports for PCIe.

The following table indicates how the connectors map to the phys within each CSW. Card layout figures in [Broadcom MegaRAID and eHBA Tri-Mode Storage Adapter Characteristics](#) show the connector designations for each adapter.

**Table 4: Adapter Connector-to-CSW Port Associations**

Adapter	Connector 0	Connector 1	Connector 2	Connector 3
9670W-16i	CSW1[0:7]	CSW1[8:15]	—	—
9670-24i	CSW1[0:7]	CSW1[8:15]	CSW0[8:15]	—
9660-16i	CSW0[0:7]	CSW1[0:7]	—	—
9620-16i	CSW1[8:15]	CSW0[8:15]	—	—
9600-24i	CSW1[8:15]	CSW0[8:15]	CSW1[0:7]	—
9600-16i	CSW1[8:15]	CSW0[8:15]	—	—
9600-8i8e	CSW1[0:7]	CSW0[12:15]	CSW0[8:11]	—
9600W-16e	CSW0[12:15]	CSW0[8:11]	CSW0[4:7]	CSW0[0:3]
9600-16e	CSW0[12:15]	CSW0[8:11]	CSW0[4:7]	CSW0[0:3]
9602W-16e	CSW1[12:15]	CSW1[8:11]	CSW1[4:7]	CSW1[0:3]

The internal adapters can direct attach to SAS, SATA, or NVMe drives. The internal and external adapters support drive attach through PCIe switches or expanders.

### NOTE

Carefully assess any decision to mix SAS and SATA drives within the same virtual drive (VD). Although you can mix drives, the practice is discouraged.

MegaRAID does not permit mixing SAS and NVMe drives or SATA and NVMe drives within the same VD. To mix NVMe and SAS/SATA drives on a MegaRAID adapter, you must configure the drives in separate VDs.

The following sections describe the connector options for a single direct-attach type solution. Adhere to the same guidelines if you combine device types.

## SAS/SATA Support

The storage interface is comprised of either 24 phys or 16 phys, depending on the adapter. Dedicated SAS phy management hardware manages the phys in groups of eight within each CSW: CSW0[0:7], CSW0[8:15], CSW1[0:7], and CSW1[8:15]. Depending on the adapter, one or more of these CSW groups are used for the SAS/SATA interfaces and these SAS phy management hardware instances cannot communicate with each other.

When you configure a wide port, the connections must attach exclusively to phys all managed by the same CSW group. If the ports are not managed by the same CSW group, unexpected controller and host behavior occurs. You can create combinations of a x1 to x8 wide link within CSW0[0:7], CSW0[8:15], CSW1[0:7], or CSW1[8:15]. You cannot create a wide link by spanning RX/TX pairs between CSW0 and CSW1 or between phys 8:15 and 0:7 within the same CSW group.

## PCIe (NVMe) Support

The following table shows how many NVMe drives or Broadcom PEX88000-series switches can directly attach to each adapter.

The 9600W-16e adapter, 9600-16e adapter, 9602W-16e adapter, and 9600-8i8e adapter (external ports) do not support direct attach to NVMe drives. The expected topology for these adapters is a typical just a bunch of flash (JBOF) scenario that uses a switch to connect the NVMe drives.

### NOTE

Connected NVMe drives must support end-to-end CRC (ECRC).

**Table 5: NVMe Device or PCIe Switch Direct-Attach Options Supported for Each Adapter**

Adapter	x4 NVMe Drives	x2 NVMe Drives	x1 NVMe Drives	x16 Switch	x8 Switches	x4 Switches
9670W-16i	4	8	16	1	2	4
9670-24i	6	12	24	1	3	6
9660-16i	4	8	16	0	2	4
9620-16i	4	8	16	0	2	2
9600-24i	6	12	24	0	3	6
9600-16i	4	8	16	0	2	4
9600-8i8e <sup>a</sup>	2	4	8	0	2	4
9600W-16e	0	0	0	1	2	4
9600-16e	0	0	0	1	2	4
9602W-16e	0	0	0	1	2	4

The adapter phys are grouped into two CSWs: CSW1[0:15] and CSW0[0:15]. Depending on the adapter, 8 or 16 of these phys are used consecutively for the PCIe host interface and the remaining tri-mode phys are available for connection to any supported SAS, SATA, or PCIe (NVMe) storage devices. The following tables indicate supported topologies. Typical backplane designs naturally align with these topology rules, but you must take care not to design anything atypical that might interfere with the adapter's operation.

**Table 6: 9670W-16i Adapter PCIe Topology Configuration Combinations**

Connector 0								Connector 1							
CSW1[0:7]								CSW1[8:15]							
0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
x16															
x8								x8							
x8								x4				x4			
x4				x4				x4				x4			
x8								x2		x2		x2		x2	
x4				x4				x2		x2		x2		x2	

a. Only internal internal ports support direct-attach NVMe drives.

Connector 0								Connector 1							
CSW1[0:7]								CSW1[8:15]							
0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
x2		x2		x2		x2		x2		x2		x2		x2	
x8								x1	x1	x1	x1	x1	x1	x1	x1
x4				x4				x1	x1	x1	x1	x1	x1	x1	x1
x1	x1	x1	x1	x1	x1	x1	x1	x1	x1	x1	x1	x1	x1	x1	x1
x4				x4				x8							
x2		x2		x2		x2		x8							
x1	x1	x1	x1	x1	x1	x1	x1	x8							
x2		x2		x2		x2		x4				x4			
x1	x1	x1	x1	x1	x1	x1	x1	x4				x4			

**Table 7: 9660-16i Adapter PCIe Topology Configuration Combinations**

Connector 0								Connector 1							
CSW0[0:7]								CSW1[0:7]							
0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7
x8								x8							
x8								x4				x4			
x4				x4				x4				x4			
x8								x2		x2		x2		x2	
x4				x4				x2		x2		x2		x2	
x2		x2		x2		x2		x2		x2		x2		x2	
x8								x1	x1	x1	x1	x1	x1	x1	x1
x4				x4				x1	x1	x1	x1	x1	x1	x1	x1
x1	x1	x1	x1	x1	x1	x1	x1	x1	x1	x1	x1	x1	x1	x1	x1
x4				x4				x8							
x2		x2		x2		x2		x8							
x1	x1	x1	x1	x1	x1	x1	x1	x8							
x2		x2		x2		x2		x4				x4			
x1	x1	x1	x1	x1	x1	x1	x1	x4				x4			

**Table 8: 9670-24i Adapter PCIe Topology Configuration Combinations**

Connector 0								Connector 1								Connector 2							
CSW1[0:7]								CSW1[8:15]								CSW0[8:15]							
8	9	10	11	12	13	14	15									00	11	22	33	44	55	66	77
x16 (paired with Connector 2)								x8								x16 (paired with Connector 0)							
x16 (paired with Connector 2)								x4				x4				x16 (paired with Connector 0)							
x16 (paired with Connector 2)								x2		x2		x2		x2		x16 (paired with Connector 0)							
x16 (paired with Connector 2)								x1	x1	x1	x1	x1	x1	x1	x1	x16 (paired with Connector 0)							
Use any row from the previous 9660-16i Adapter PCIe Topology Configuration Combinations table.								x8															
Use any row from the previous 9660-16i Adapter PCIe Topology Configuration Combinations table.								x4				x4											
Use any row from the previous 9660-16i Adapter PCIe Topology Configuration Combinations table.								x2		x2		x2		x2									
Use any row from the previous 9660-16i Adapter PCIe Topology Configuration Combinations table.								x1	x1	x1	x1	x1	x1	x1	x1	x1	x1	x1	x1	x1	x1	x1	x1

**Table 9: 9600-16i Adapter and 9620-16i Adapter PCIe Topology Configuration Combinations**

Connector 0								Connector 1							
CSW1[8:15]								CSW0[8:15]							
								88	99	1010	1111	1212	1313	1414	1515
x8								x8							
x8								x4				x4			
x4				x4				x4				x4			
x8								x2		x2		x2		x2	
x4				x4				x2		x2		x2		x2	
x2		x2		x2		x2		x2		x2		x2		x2	
x8								x1	x1	x1	x1	x1	x1	x1	x1
x4				x4				x1	x1	x1	x1	x1	x1	x1	x1
x1	x1	x1	x1	x1	x1	x1	x1	x1	x1	x1	x1	x1	x1	x1	x1
x4				x4				x8							
x2		x2		x2		x2		x8							
x1	x1	x1	x1	x1	x1	x1	x1	x8							
x2		x2		x2		x2		x4				x4			
x1	x1	x1	x1	x1	x1	x1	x1	x4				x4			

**Table 10: 9600-24i Adapter PCIe Topology Configuration Combinations**

Connector 0								Connector 1								Connector 2							
CSW1[8:15]								CSW0[8:15]								CSW1[0:7]							
8	9	10	11	12	13	14	15	8	9	10	11	12	13	14	15	0	1	2	3	4	5	6	7
x8								x8								x8							
x8								x4				x4				x4				x4			
x4				x4				x2		x2		x2		x2		x2		x2		x2		x2	
x8								x2		x2		x2		x2		x1	x1	x1	x1	x1	x1	x1	x1
x4				x4				x2		x2		x2		x2		Combine with any of the first four configurations in this column.							
x2		x2		x2		x2		x1	x1	x1	x1	x1	x1	x1	x1	Combine with any of the first four configurations in this column.							
x8								x1	x1	x1	x1	x1	x1	x1	x1	Combine with any of the first four configurations in this column.							
x4				x4				x1	x1	x1	x1	x1	x1	x1	x1	Combine with any of the first four configurations in this column.							
x1	x1	x1	x1	x1	x1	x1	x1	x8								Combine with any of the first four configurations in this column.							
x4				x4				x8								Combine with any of the first four configurations in this column.							
x2		x2		x2		x2		x8								Combine with any of the first four configurations in this column.							
x1	x1	x1	x1	x1	x1	x1	x1	x4				x4				Combine with any of the first four configurations in this column.							
x2		x2		x2		x2		x4				x4				Combine with any of the first four configurations in this column.							
x1	x1	x1	x1	x1	x1	x1	x1	x4				x4				Combine with any of the first four configurations in this column.							

**Table 11: 9600W-16e Adapter and 9600-16e Adapter PCIe Topology Configuration Combinations**

Connector 0				Connector 1				Connector 2				Connector 3			
CSW0[12:15]				CSW0[8:11]				CSW0[4:7]				CSW0[0:3]			
12	13	14	15	8	9	10	11	4	5	6	7	0	1	2	3
x16															
x8								x8							
x4				x4				x4				x4			

**Table 12: 9602W-16e Adapter PCIe Topology Configuration Combinations**

Connector 0				Connector 1				Connector 2				Connector 3			
CSW1[12:15]				CSW1[8:11]				CSW1[4:7]				CSW1[0:3]			
12	13	14	15	8	9	10	11	4	5	6	7	0	1	2	3
x16															
x8								x8							
x4				x4				x4				x4			

**Table 13: 9600-8i8e Adapter PCIe Topology Configuration Combinations**

Connector 0								Connector 1				Connector 2			
CSW1[0:7]								CSW0[12:15]				CSW0[8:11]			
0	1	2	3	4	5	6	7	12	13	14	15	8	9	10	11
x8								x8							
x4				x4				x4				x4			
x2		x2		x2		x2		—							
x1	x1	x1	x1	x1	x1	x1	x1	—							

## Common REFCLK Support

Connections that require a common REFCLK include one REFCLK for each quadrant. Each connector is divided into two quadrants.

The adapter uses x8 SFF-8654 (SlimSAS) connectors. For x4 NVMe or PCIe switch connections, the REFCLK sourced by each quadrant directly clocks each attached x4 PCIe connection.

To directly attach x2 or x1 NVMe drives that require a common REFCLK, where more than one drive is sourced from a single quadrant, you must properly fan out the shared REFCLK on the backplane. For x2 and x1 NVMe connections, use SRIS-enabled drives to avoid fanning the clock out on the backplane.



# Backplane Management

---

Use the information in this chapter to set up the adapter's backplane management options.

The SFF-8448 standard defines how to detect whether the backplane supports a SGPIO or two-wire interface (I<sup>2</sup>C) for SAS/SATA usage. SFF-9402 is a superset of SFF-8448, adding the PCIe-defined sideband signal, which means that SAS/SATA users see no change in backplane management detection when using the adapters.

## Universal Backplane Management

The adapters provide LED operation and other backplane management of NVMe only, SAS/SATA only, or mixed-protocol backplanes based on the SFF-TA-1005 specification.

SFF-TA-1005 is an industry-standard backplane management specification commonly known as UBM. As long as the backplane management controller is designed in accordance with the UBM specification, the adapter automatically detects the backplane type and functions appropriately.

The adapter supports the industry-standard *SFF-TA-1005 Specification for Universal Backplane Management (UBM)*. UBM provides the following key features:

- Reports the backplane capabilities, including the following:
  - NVMe drive widths
  - Common REFCLK or separate REFCLK support
  - Maximum speeds
  - Designed slot power
- Supports cable order independence, that is, the drive LED control and slot ID are not dependent on cable order.
- Enables drive hot plug insertion through control of PERST# timing.

For existing SAS/SATA backplanes, if BP\_TYPE = 0, the adapter uses SGPIO for legacy backplane management. Refer to the SFF-8485 specification for functionality details. Design new backplanes with the industry-standard SFF-TA-1005 (UBM) specification for backplane management.

## Virtual Pin Port Management

Broadcom requires new designs to enable UBM for backplane management.

The adapter maintains support for Virtual Pin Port (VPP) backplane management for legacy implementations. The adapters provide LED operation for NVMe devices based on the VPP over I<sup>2</sup>C definition. Standard VPP implementation calls for one PCA9555 target per two devices. For each drive pair, the adapter expects to see one PCA9555 target responding to address 0x4C on each pair of NVMe drives.

## Sideband Signals

The internal adapters have one or two x8 SFF-8654 connectors. Each x8 connector provides two sets of sidebands. This section describes the sideband signal usage. The following table defines the sideband signal's pins on the SFF-8654 connector. The last column in the table indicates the strength of the pull-up resistor or pull-down resistor values on the adapter. See [Table 15, Sideband Management Pin Settings](#), for the signal descriptions, and see [Table 16, Internal x8 SFF-8654 Connector Pinout](#), for a complete connector pinout.

**Table 14: Sideband Signal Pinout**

Connector A Side	Connector B Side	Sideband or Vendor Specific Pin Number	UBM Assignments	Direction	Resistor Value
A8	A26	7	BP_TYPE	Input	100-kΩ pull-down
A9	A27	4	2W_RESET#	Output	2.0-kΩ pull-up
A10	A28	3	GND	—	—
A11	A29	+	REFCLK+	Output	—
A12	A30	–	REFCLK-	Output	—
B8	B26	0	2W_CLK	Input/Output	2.0-kΩ pull-up
B9	B27	1	2W_DATA	Input/Output	2.0-kΩ pull-up
B10	B28	2	GND	—	—
B11	B29	5	PERST#	Input/Output	2.0-kΩ pull-up
B12	B30	6	C_TYPE, D_INPL#, CHANGE_DET#	Input/Output	10-kΩ pull-up

The following table describes the sideband signal pin settings.

**Table 15: Sideband Management Pin Settings**

Pin Name	Settings	Description
BP_TYPE	<ul style="list-style-type: none"> <li>0: SGPIO</li> <li>1: Two-wire interface</li> </ul>	Indicates if the backplane uses SGPIO or two-wire interface for management. To maintain backwards compatibility with SPGIO-based backplanes, the adapter has a weak pull-down to default to SGPIO if the backplane does not explicitly drive the signal.
2W_RESET#	<ul style="list-style-type: none"> <li>0: Reset is asserted</li> <li>1: Reset is not asserted</li> </ul>	Optional reset driven by the host if the UBM target reports that the target can be reset.
REFCLK+/-	—	PCIe REFCLK HCSL 100-MHz clock driven by the device side ports to PCIe devices that require REFCLK. If D_INPL# is 0 and BP_TYPE is 1, the adapter enables the REFCLK outputs for that quad of high-speed lanes. When BP_TYPE is 0 or the UBM Clock Routing bit on the backplane is 0, this output is turned off.
2W_CLK	—	The two-wire interface clock signal.
2W_DATA	—	The two-wire interface data signal.
PERST#	<ul style="list-style-type: none"> <li>0: Reset is asserted</li> <li>1: Reset is not asserted</li> </ul>	The adapter drives the PCIe RESET# signal. This signal uses a clamp to ground so that the signal on the adapter powers up LOW until backplane detection warrants the release of this signal for open-drain use. This method ensures that PERST# does not deassert until the directly connected NVMe drive is successfully detected.

Pin Name	Settings	Description
C_TYPE, D_INPL#, CHANGE_DET#	—	<p>Open collector/drain input or output signal:</p> <ul style="list-style-type: none"> <li>• C_TYPE. If BP_TYPE is 0, the adapter drives this signal LOW. If BP_TYPE is 1, this signal adheres to the SFF-8448 requirement to drive this signal to 1 in response to floating the signal. Because this signal is an open drain signal, <i>driving</i> to 1 is when a pull-up resistor pulls this signal HIGH.</li> <li>• D_INPL#. When C_TYPE is HIGH, the backplane pulls this signal to ground to indicate an NVMe device is connected and a two-wire interface backplane management target might be on the sideband's two-wire interface.</li> <li>• CHANGE_DET#. If D_INPL# is 0 and a UBM FRU device is discovered on the two-wire interface, the UBM FRU data can inform the adapter that the device is CHANGE_DET# feature capable. The adapter can rely on this signal as the CHANGE_DET# signal as described in the UBM specification. In this mode, the UBM controller drives this signal LOW to assert CHANGE_DET#.</li> </ul>

## Cables and Cabling Configurations


Use the following sections to select or design internal or external connectors and cables.

### Internal Adapter Connector Pinout

The internal adapter follows the SFF-9402 standard for connector signal assignments.

Each x8 connector includes eight PCIe transmit and receive lanes and two sets of sidebands designated as A and B, in accordance with the SFF-9402 specification. The following figure shows the x8 SFF-8654 pin designations.

**Figure 1: x8 SFF-8654 Pin Designations**



The following table defines the adapter's internal SFF-8654 connector pinouts.

**Table 16: Internal x8 SFF-8654 Connector Pinout**

Pin	Name	Pin	Name
A1	GND	B1	GND
A2	PERp0, RX0+	B2	PETp0, TX0+
A3	PERn0, RX0-	B3	PETn0, TX0-
A4	GND	B4	GND
A5	PERp1, RX1+	B5	PETp1, TX1+
A6	PERn1, RX1-	B6	PETn1, TX1-
A7	GND	B7	GND
A8	BP_TYPEA	B8	2W-CLKA, SClockA
A9	2W_RESETA, SDataOutA	B9	2W-DATAA, SloadA
A10	GND	B10	GND
A11	REFCLKA+	B11	PERSTA#, SDataInA
A12	REFCLKA-	B12	CPRSNTA#, CNTRLR_TYPEA
A13	GND	B13	GND
A14	PERp2, RX2+	B14	PETp2, TX2+
A15	PERn2, RX2-	B15	PETn2, TX2-
A16	GND	B16	GND
A17	PERp3, RX3+	B17	PETp3, TX3+

Pin	Name	Pin	Name
A18	PERn3, RX3-	B18	PETn3, TX3-
A19	GND	B19	GND
A20	PERp0, RX4+	B20	PETp0, TX4+
A21	PERn0, RX4-	B21	PETn0, TX4-
A22	GND	B22	GND
A23	PERp1, RX5+	B23	PETp1, TX5+
A24	PERn1, RX5-	B24	PETn1, TX5-
A25	GND	B25	GND
A26	BP_TYPEB	B26	2W-CLKB, SClockB
A27	2W_RESETB, SDataOutB	B27	2W-DATAB, SLoadB
A28	GND	B28	GND
A29	REFCLKB+	B29	PERSTB#, SDataInB
A30	REFCLKB-	B30	CPRSNTB#, CNTRLR_TYPEB
A31	GND	B31	GND
A32	PERp2, RX6+	B32	PETp2, TX6+
A33	PERn2, RX6-	B33	PETn2, TX6-
A34	GND	B34	GND
A35	PERp3, RX7+	B35	PETp3, TX7+
A36	PERn3, RX7-	B36	PETn3, TX7-
A37	GND	B37	GND

## Storage Interface Cabling

Choose the proper cable for the given backplane type and connectors.

The correct choice is especially important for backplanes that use SFF-8643 for the NVMe connectors. Many of these backplanes use an older legacy-recommended pinout for the NVMe connector instead of a connector pinout based on the SFF-9402 specification. Most backplanes that use either SFF-8612 or SFF-8654 connectors follow the SFF-9402 specification. The pinout recommended in the *PCI Express OCUlink Specification* is equivalent to that recommended for SFF-9402. Verify the connector pinout for the intended backplane to make sure the proper cable is used when connecting to NVMe drives.

Broadcom provides the following cables to use for the adapter. Use the MPN listed to order a cable from Broadcom. If you source your own cables, use the Broadcom part number from the following table and the drawings and pinouts in [Cable Drawings and Pinouts](#).

**Table 17: Internal Adapter Cables**

MPN	Broadcom Cable Part No.	Cable Description	Backplane Connector
05-60001-00	5067-6865	x8 8654 to 2x4 8612, AltWiring 1M	Two x4 SFF-8612 (OCuLink)
05-60002-00	5067-6862	x8 8654 to 2x4 8643 (W), SMC 1M	Two x4 SFF-8643 (mini-SAS HD)
05-60003-00	5067-6866	x8 8654 to 2x4 8643, 9402 SAS 1M	Two x4 SFF-8643 (mini-SAS HD)

MPN	Broadcom Cable Part No.	Cable Description	Backplane Connector
05-60004-00	5067-6103	x8 8654 to 2x4 8654, 9402 1M	Two x4 SFF-8654 (SlimSAS)
05-60005-00	5067-6682	x8 8654 to 2xU.2 Direct, 1M	Two U.2 SFF-8639
05-60006-00	5067-7542	x8 8654 to 8xU.3 Direct, 1M	Eight U.3 SFF-8639
05-60007-00	5067-6869	x8 8654 to 1x8 8654, 9402 1M	One x8 SFF-8654 (SlimSAS)

**Table 18: Adapter Broadcom Cable Use Cases**

MPN	Type	Description
05-60001-00	SAS/SATA and NVMe	Use for backplanes with x4 SFF-8612 connectors with pinouts that follow the SFF-9402 specification.
05-60002-00	NVMe	Specialty cable that provides NVMe connections for SuperMicro Purley backplanes. This cable has white SFF-8643 connectors to indicate that it must connect to the white SFF-8643 connectors on the SuperMicro Purley backplanes.
05-60003-00	SAS/SATA	Use for traditional SAS/SATA connections. Usually backplanes designed to support SAS/SATA only or are double plumbed for U.2 and SAS/SATA drives use SFF-8643 connectors.
05-60004-00	SAS/SATA and NVMe	Use for backplanes with x4 SFF-8654 connectors with pinouts that follow the SFF-9402 specification.
05-60005-00	NVMe	Enables direct connect from the adapter to a U.2 NVMe drive. Use for proof-of-concept type applications.
05-60006-00	SAS/SATA and NVMe	Enables direct connect from the adapter to a U.3 NVMe or SAS/SATA drive. This cable does not send a PCIe REFCLK or PERST# to each drive connector; that is, the U.3 drive must support SRIS and not require PERST#. Use for proof-of-concept type applications.
05-60007-00	SAS/SATA and NVMe	Use for backplanes with x8 SFF-8654 connectors with pinouts that follow the SFF-9402 specification.

## Backplane Connectors

The SFF-8612 or SFF-8654 connectors are the preferred connectors to use for the NVMe backplane or multiprotocol backplanes, based on the SFF-TA-1001 universal bay definition.

Backplanes that use OCUlink connectors should follow the *PCI Express OCUlink Specification*. This pinout is also equivalent to the SFF-9402 specification recommendations. Verify the backplane connector pinout to make sure you use proper cabling to the NVMe drive. Refer to the *PCI Express OCUlink Specification* and the SFF-9402 specification for backplane NVMe connector pinout information.

## External Adapter Connector Pinout

External adapters support SAS and PCIe connections.

The PCIe cable specification swaps lanes 0 and 1 compared to the SAS specification. For PCIe connections, this swap means the external pinout must place lanes 0 and 1 on the same pins as the JBOF. This swap does not impact SAS connections because lane ordering does not impact SAS designs.

For external PCIe JBOF connections, as defined by the *PCI Express External Cabling Specification*, the adapter does not connect REFCLK and PERST#. The adapter only supports an SRIS-capable endpoint, that is, no REFCLK. The JBOF handles the drive (connected to the JBOF switch) start-of-day reset, hot insertion, and clocking requirements.

The adapter expects a local (single master) two-wire bus connection to the cable or active module's EEPROM. A cable requires a local EEPROM on each end to identify cable properties, such as length, loss budget, ganging, and so on. The adapter supports no direct communication to the enclosure over two-wire. SES performs enclosure management.

When using active cables with the 9600-16e adapter, eHBA 9600-8e adapter, eHBA 9600-8i8e adapter or eHBA 9602-16e adapter, you must implement an additional step if your active cable requires that the Vman port (management interface power) be toggled. The Broadcom adapter toggles the active cable's Vact port (active cable power), but not the Vman port after an online firmware update or for other conditions that result in a soft reset. If your active cable requires that the Vman port be toggled, the cable must be removed and reinserted, or power to the card slot must be cycled. If neither action is done, the PCIe/SAS link will not be restored. If the active cable requires that only the Vact port toggle, no power cycle or cable re-insertion is needed.

The following table shows the cable pinout for the cable that Broadcom provides for the external adapter. See [Cable 05-60009-00](#) for the cable drawing and pinout. Use the drawing if you source your own cable.

**Table 19: External Adapter Cable Pinout**

Pin	Signal	Pin	Signal
A1	No Connect	C1	CMICK
A2	CINT#	C2	CMIDAT
A3	GND	C3	GND
A4	PERp0, RX0+	C4	PETp0, TX0+
A5	PERn0, RX0-	C5	PETn0, TX0-
A6	GND	C6	GND
A7	PERp3, RX3+	C7	PETp3, TX3+
A8	PERn3, RX3-	C8	PETn3, TX3-
A9	GND	C9	GND
B1	PWR	D1	PWR
B2	CBLPRSNT#	D2	MGTPWR
B3	GND	D3	GND
B4	PERp1, RX1+	D4	PETp1, TX1+
B5	PERn1, RX1-	D5	PETn1, TX1-
B6	GND	D6	GND
B7	PERp2, RX2+	D7	PETp2, TX2+
B8	PERn2, RX2-	D8	PETn2, TX2-
B9	GND	D9	GND

Broadcom provides the following cable to use for external adapters. Use the MPN listed to order the cable from Broadcom. If you source your own cables, use the Broadcom part number from the following table, and the drawing and pinout in [Cable 05-60009-00](#).

**Table 20: External Adapter Cable**

MPN	Broadcom Cable Part No.	Cable Description	Backplane Connector
05-60009-00	5067-9643	G4/S4 x4 8644 to x4 8644, 3M	Two x4 SFF-8674

## CacheVault Data Protection

---

The MegaRAID Tri-Mode storage adapters support data retention by using NAND flash memory on the adapter, backed up by a CacheVault™ Power Module 05 (CVPM05).

The CVPM05 module is a super-capacitor pack that provides power for the backup of your data in case of host power loss or server failure. The CVPM05 module connects to the controller remotely by cable. The data is backed up to the NAND flash memory available on the MegaRAID storage adapter.

### NOTE

If you do not use the remote mount board or clip included with the CacheVault kit, do not damage the CVPM05 module when mounting in the system. For more information about mounting the CVPM05 module, refer to *CVPM02, CVPM05 Power Modules | CVFM04 Cache Module MegaRAID CacheVault Protection Products User Guide*.

In the event of host power loss or server failure, any data available in the cache is offloaded to the onboard NAND memory. During this process, the CVPM05 power module powers the necessary components needed for offload.

### NOTE

You cannot hot plug CVPM05 modules. Removing or inserting a CVPM05 module with the adapter powered on might damage the board and the super-capacitor functionality. To attach or remove a CVPM05 module from an adapter, you must fully power down the adapter before you attach the module to or remove the module from its mating connector.

For more information about installation of the CVPM05 module, visit [Support Documents and Downloads](#) to download the *CacheVault Power Module 05 Getting Started Guide*.



## Adapter Security

The adapters provide two security features to protect your system from malicious activity:


- Hardware secure boot – Permits only authenticated firmware to execute on the adapter
- Device authentication – Enables another entity in the server to authenticate the adapter

The following sections provide details about each security feature.

### Hardware Secure Boot

Hardware secure boot permits only authenticated firmware to execute on the adapter. The adapter boots from an internal boot ROM, which establishes the initial root of trust (RoT). Hardware secure boot authenticates and builds a chain of trust (CoT) with succeeding firmware images by using the RoT, meaning only authorized firmware executes on the adapter.

**Figure 2: Authenticated Firmware Example**



Hardware secure boot requires that each image be signed with a valid digital signature; otherwise, the image is considered invalid and does not execute. The adapter ships with a valid signed firmware image. All Broadcom-supplied firmware includes a valid digital signature; therefore, the hardware secure boot process is transparent unless the adapter encounters a counterfeit image. If the adapter downloads a counterfeit image, the image authentication fails and the download utility, such as StorCLI2, displays the appropriate failure messages. Contact Broadcom Technical Support for assistance.

### Device Authentication

Device authentication allows the adapter to prove its unique device identity to another entity in the server as part of a platform attestation implementation. The adapter proves its unique device identity with a device ID certificate and a challenge protocol.

The device authentication process includes a platform RoT device (a baseboard management controller [BMC] or a discreet component) and the adapter (the attested device). The platform RoT device requests the device certificate from the controller on the adapter for authentication. If the device authentication process fails, the platform RoT device operates in accordance with its platform security policy.

## Device Certificate

The controller on the adapter uses a device certificate and associated certificate chain to present evidence of its device identity. The certificate chain is based on the X.509 v3 standards and the *Security Protocol and Data Model (SPDM) Specification*, version 1.1.

The device certificate contains identifying information about the controller, including the device serial number. The private key of a parent and intermediate signing certificate signs the device certificate. The device certificate cannot be modified after manufacture.

Broadcom manufacturing provisions each board with its device certificate. Every 96xx adapter manufactured is provisioned with a certificate chain. When the SPDM `GET_CERTIFICATE` command queries the controller, the controller returns the device certificate chain, which includes a hash of the root certificate.

## Attestation Procedure

Attestation is the process in which the server's BMC, or other discrete logic, challenges the adapter for proof of authenticity.

Using attestation in the server is optional. The adapter functions without performing attestation. If attestation fails, the adapter continues to function normally. You must determine the next steps for your system if the adapter fails attestation.

**Figure 3: Attestation Procedure Example**



To support attestation, you must obtain the external root certificate authority to configure the platform RoT, such as BMC. You can download the external root certificate from [Support Documents and Downloads](#).

## SPDM Capabilities

*Security Protocol and Data Model (SPDM) Specification v1.1* enables the Requester (BMC/discrete logic) and the Responder (adapter) to exchange keys to enable encryption support for the management interface information exchange. By default, if the Requester asks, the adapter enables authenticated encryption of the management interface. This process occurs dynamically between the Requester and Responder as part of the attestation procedure and requires no change to the adapter's settings.

The following table lists the SPDM v1.1 endpoint CAPABILITIES response message flags. Flags listed as supported respond to the `GET_CAPABILITIES` request message.

**Table 21: SPDM CAPABILITIES Response Message Support**

CAPABILITIES Response Flags Field	Value
CACHE_CAP	0
CERT_CAP	1
CHAL_CAP	1
MEAS_CAP	10
MEAS_FRESH_CAP	0
ENCRYPT_CAP	1
MAC_CAP	1
MUT_AUTH_CAP	1
KEY_EX_CAP	1
PSK_CAP	00
ENCAP_CAP	1
HBEAT_CAP	1
KEY_UPD_CAP	1
HANDSHAKE_IN_THE_CLEAR_CAP	0/1
PUB_KEY_ID_CAP	0

The adapter supports SPDM mutual authentication. The HANDSHAKE\_IN\_THE\_CLEAR\_CAP capability bit is shown as 0/1 because the value is subject to negotiation. The firmware sets the HANDSHAKE\_IN\_THE\_CLEAR\_CAP bit to 0, but the firmware can set the bit to 1 if the Requester sets the bit to 1. While the adapter supports all capabilities listed in the previous table, the Requester might not support the same capabilities. The adapter correctly negotiates its capabilities with that of the Requester. Refer to the *StorCLI2 Utility User Guide* for additional security command information.

# Adapter Installation Instructions

---

This chapter provides detailed instructions on how to install your adapter.

Make sure to use the proper installation steps for your adapter:

- [Adapter Installation](#): MegaRAID 9670W-16i, MegaRAID 9670-24i, MegaRAID 9660-16i, eHBA 9620-16i, eHBA 9600-24i, eHBA 9600-16i, eHBA 9600-8i8e, eHBA 9600W-16e, or eHBA 9600-16e
- [OCP Adapter Installation](#): eHBA 9602W-16e

## Adapter Installation

Use the steps in this section to install the Broadcom adapter.

### 1. Unpack your adapter.

Unpack and remove the adapter. Inspect the adapter for damage. If it appears damaged, contact Broadcom Technical Support.

#### ATTENTION

To avoid the risk of data loss, back up your data before you change your system configuration.

### 2. Turn off the power to the system.

Turn off the power to the computer and disconnect the AC power cord. Remove the computer cover. Refer to the system documentation for instructions. Before you install the adapter, make sure that the computer is disconnected from the power and from any networks.



#### CAUTION

Disconnect the computer from the power supply and from any networks to which you will install the adapter, or you risk damaging the system or experiencing electrical shock.

### 3. Review the adapter connectors.

See [Broadcom MegaRAID and HBA Tri-Mode Storage Adapter Characteristics](#) for descriptions of the adapters that show their connectors.

### 4. Check the mounting bracket on the adapter.

If required for your system, replace the full-profile mounting bracket that ships on the adapter with the low-profile bracket supplied. Complete the following steps to attach the low-profile bracket:

- a) Using a No. 1 Phillips screwdriver that is ESD safe, remove the two Phillips screws that connect the full-profile bracket to the board. Unscrew the two screws located at the top and bottom edges of the board. Avoid touching any board components with the screwdriver or the bracket.
- b) Remove the full-profile bracket. Do not damage the adapter.
- c) Place the adapter on top of the low-profile bracket. Position the bracket so that the screw holes in the tabs align with the openings in the board.
- d) Using a No. 1 Phillips torque screwdriver that is ESD safe, set to a maximum torque of  $4.8 \pm 0.5$  inch-pounds. Replace the two Phillips screws removed in Step a.

#### ATTENTION

Exceeding this torque specification can damage the board, connectors, or screws, and can void the warranty on the board.

**ATTENTION**


Damage caused to the board as a result of changing the bracket can void the warranty on the board. Adapters returned without a bracket mounted on the board will be sent back without return merchandise authorization (RMA) processing.

5. **Insert the adapter into an available PCIe slot.** Select a PCIe slot, and align the adapter's PCIe bus connector to the slot, as shown in the following figure. Press down gently, but firmly, to make sure that the adapter is seated correctly in the slot. Secure the bracket to the computer chassis with the bracket screw.

**NOTE**

Adapters with a x8 host interface can operate in x8 or x16 slots. However, some x16 PCIe slots support only PCIe graphics cards; an adapter installed in one of these slots will not function. Refer to the guide for your motherboard for information about the PCIe slots.

**Figure 4: Installing an Adapter in a PCIe Slot**



6. **Configure and install the SAS, SATA, or PCIe (NVMe) devices in the host computer case.**

Refer to documentation for the devices for any preinstallation configuration requirements.

7. **Connect the adapter to the devices.** Connect the appropriate cable that has the connectors on one end for the adapter. Connect the appropriate connector on the other end to attach to the backplane connector.  

The maximum cable length is 1 meter (39.37 in.). A single wide-port SAS or multilane PCIe (NVMe) device cannot connect to phys controlled by different CSWs. See [Tri-Mode Storage Interface](#) for more information.
8. **Provide the required airflow for the installed adapter.** See [Board Operating Conditions](#) to find the adapter's cooling requirements.
9. **Turn on the power to the system.** Reinstall the computer cover, and reconnect the AC power cords. Make sure that the power is turned on to the storage devices before or at the same time that the power is turned on to the host computer. Turn on power to the host computer. If the computer is powered on before these devices, the devices might not be recognized.  

During boot, a BIOS message appears. The firmware takes several seconds to initialize. The configuration utility prompt times out after several seconds. The second portion of the BIOS message shows the adapter controller number, firmware version, and cache SDRAM size. The numbering of the adapters follows the PCIe slot scanning order used by the host motherboard.
10. **Choose the correct storage profile.** Refer to the *MegaRAID Tri-Mode Software User Guide* and the *LSI® Storage Authority Software User Guide* for details about setting up your adapter.
11. **Install the operating system driver.** The adapters can operate under various operating systems. To operate under these operating systems, you must install the software drivers. The firmware and drivers are routinely updated and made available at [Support Documents and Downloads](#).

The hardware installation of your adapter is complete.

## OCP Adapter Installation

Use the following steps to install any of the following adapters:

- eHBA 9602W-16e

1. **Unpack your adapter.**

Unpack and remove the adapter. Inspect the adapter for damage. If it appears damaged, contact Broadcom Technical Support.

**ATTENTION**

To avoid the risk of data loss, back up your data before you change your system configuration.

2. **Turn off the power to the system.**

Turn off the power to the computer and disconnect the AC power cord. Remove the computer cover. Refer to the system documentation for instructions. Before you install the adapter, make sure that the computer is disconnected from the power and from any networks.




**CAUTION**

Disconnect the computer from the power supply and from any networks to which you will install the adapter, or you risk damaging the system or experiencing electrical shock.



3. **Insert the adapter into an available OCP 3.0 TSFF slot.** Select an OCP slot and align the adapter with the system rails. Push the adapter into the slot, as shown in the following figure.

**Figure 5: Installing an Adapter in an OCP Slot**



4. **Secure the adapter.**
5. **Attach the cables.** Attach the cables to the storage device ports.

## Removing the OCP Adapter

Use the following steps to remove any of following adapters from an OCP slot:

- eHBA 9602W-16e

1. **Turn off the power to the system.**

Turn off the power to the computer and disconnect the AC power cord. Remove the computer cover. Refer to the system documentation for instructions. Before you install the adapter, make sure that the computer is disconnected from the power and from any networks.



### CAUTION

Disconnect the computer from the power supply and from any networks to which you will install the adapter, or you risk damaging the system or experiencing electrical shock.

2. **Unplug the cables.** Remove the SlimSAS cables.
3. **Remove the adapter from the OCP slot.**
  - eHBA 9602W-16e. Open the ejector latch and use the latch to remove the adapter from the slot.

# Broadcom MegaRAID and HBA Tri-Mode Storage Adapter Characteristics


This chapter presents the physical characteristics of each board, including the board size and the connector locations.

## MegaRAID 9670W-16i Adapter – Connector and LED Designations

The adapter is a 167.52 (±0.13) mm × 111.15 (±0.13) mm board. The component height on the top and bottom of the adapter complies with the PCIe specification.

The following figure shows the connectors and LED locations on the adapter. Pin 1 on the headers and connectors is highlighted in red in the figure.

Figure 6: Card Layout for the MegaRAID 9670W-16i Tri-Mode Storage Adapter



The following table describes the headers and connectors on the adapter.



**Table 22: Headers and Connectors**

Connector	Type	Description
J2	Standard edge card connector	The interface between the storage adapter and the host system. With the PCIe interface, this connector provides power to the board and an I <sup>2</sup> C interface connected to the I <sup>2</sup> C bus for the Intelligent Platform Management Interface (IPMI).
J4	Default SBR header	2-pin connector. Reserved for Broadcom use.
J7	Advanced software options hardware key header	2-pin connector. Enables support for selected advanced features.
J8	Onboard serial UART connector	4-pin connector. Reserved for Broadcom use.
J10	Global HDD activity LED header	2-pin connector. Connects to an LED that indicates activity on the drives connected to the adapter.
J11	Global drive fault LED header	2-pin connector. Connects to an LED that indicates whether a drive is in a fault condition.
J14	CacheVault power module interface	9-pin connector. Connects the adapter to a CacheVault power module.
J17, J18	Storage interface connectors	Two SFF-8654 8-port internal connectors. Connect the adapter by cable to the storage devices.

The following table describes the LEDs on the adapter.


**Table 23: LED Designations**

LED	Type	Description
LED2	Yellow controller overtemperature	Stays on solid to indicate that the SAS4116W RoC temperature sensor is over the temperature threshold. When the device is in the proper temperature range, this LED is off.
LED3	Green system heartbeat	Indicates that the SAS4116W RoC ASIC is operating normally. This LED blinks at 1 Hz.
LED5	Yellow supercap fault	Indicates that the CacheVault power module is in fault state or is overtemperature. When the energy pack is in the FAULT condition or is missing, this LED is on.
LED6	Green ONFI activity	Indicates when the ONFI is active for cache offload or recovery.

## MegaRAID 9670-24i Adapter – Connector and LED Designations

The adapter is a 167.65 (±0.13) mm × 111.15 (±0.13) mm board. The component height on the top and bottom of the adapter complies with the PCIe specification.

The following figure shows the connectors and LED locations on the adapter. Pin 1 on the headers and connectors is highlighted in red in the figure.

**Figure 7: Card Layout for the MegaRAID 9670-24i Tri-Mode Storage Adapter**

The following table describes the headers and connectors on the adapter.

**Table 24: Headers and Connectors**

Connector	Type	Description
J2	Standard edge card connector	The interface between the storage adapter and the host system. With the PCIe interface, this connector provides power to the board and an I <sup>2</sup> C interface connected to the I <sup>2</sup> C bus for the Intelligent Platform Management Interface (IPMI).
J4	Default SBR header	2-pin connector. Reserved for Broadcom use.
J7	Advanced software options hardware key header	2-pin connector. Enables support for selected advanced features.
J8	Onboard serial UART connector	4-pin connector. Reserved for Broadcom use.
J10	Global HDD activity LED header	2-pin connector. Connects to an LED that indicates activity on the drives connected to the adapter.
J11	Global drive fault LED header	2-pin connector. Connects to an LED that indicates whether a drive is in a fault condition.

Connector	Type	Description
J14	CacheVault power module interface	9-pin connector. Connects the adapter to a CacheVault power module.
J17, J18, J100	Storage interface connectors	Three SFF-8654 8-port internal connectors. Connect the adapter by cable to the storage devices.
J29	Auxiliary power connector	6-pin connector.

The following table describes the LEDs on the adapter.


**Table 25: LED Designations**

LED	Type	Description
LED 2	Yellow controller overtemperature	Stays on solid to indicate that the SAS4124 RoC temperature sensor is over the temperature threshold. When the device is in the proper temperature range, this LED is off.
LED 3	Green system heartbeat	Indicates that the SAS4124 RoC ASIC is operating normally. This LED blinks at 1 Hz.
LED 5	Yellow supercap fault	Indicates that the CacheVault power module is in fault state or is overtemperature. When the energy pack is in the FAULT condition, this LED is on.
LED 6	Green ONFI activity	Indicates when the ONFI is active for cache offload or recovery.

## Auxiliary Power Connector

The MegaRAID 9670-24i adapter supports the *PCI Express Card Electromechanical Specification* defined 2×3 auxiliary power connector. Connect the auxiliary power connector if the slot cannot supply the required power as defined in [MegaRAID Tri-Mode Storage Adapter Power Supply Requirements](#). The power check algorithm detects if auxiliary power is connected to the adapter. If auxiliary power is connected, the power check is bypassed and the card is fully enabled. The auxiliary power connector's pin definition meets the PCIe CEM specification and the following table is included for reference. The following figure shows the connector's pin designations.

**Figure 8: Auxiliary Power Connector**




**Table 26: Auxiliary Power Connector Pin Definition**

Pin	Signal
1	+12V
2	+12V
3	+12V
4	Ground
5	Sense
6	Ground

## MegaRAID 9660-16i Adapter – Connector and LED Designations

The adapter is a 155.52 ( $\pm 0.13$ ) mm  $\times$  68.77 ( $\pm 0.13$ ) mm board. The component height on the top and bottom of the adapter complies with the PCIe specification.

The following figure shows the connectors and LED locations on the adapter. Pin 1 on the headers and connectors is highlighted in red in the figure.

**Figure 9: Card Layout for the MegaRAID 9660-16i Tri-Mode Storage Adapter**

The following table describes the headers and connectors on the adapter.

**Table 27: Headers and Connectors**

Connector	Type	Description
J2	Standard edge card connector	The interface between the storage adapter and the host system. With the PCIe interface, this connector provides power to the board and an I <sup>2</sup> C interface connected to the I <sup>2</sup> C bus for the Intelligent Platform Management Interface (IPMI).
J4	Default SBR header	2-pin connector. Reserved for Broadcom use.
J7	Advanced software options hardware key header	2-pin connector. Enables support for selected advanced features.
J8	Onboard serial UART connector	4-pin connector. Reserved for Broadcom use.
J10	Global HDD activity LED header	2-pin connector. Connects to an LED that indicates activity on the drives connected to the adapter.

Connector	Type	Description
J11	Global drive fault LED header	2-pin connector. Connects to an LED that indicates whether a drive is in a fault condition.
J14	CacheVault power module interface	9-pin connector. Connects the adapter to a CacheVault power module.
J17, J18	Storage interface connectors	Two SFF-8654 8-port internal connectors. Connect the adapter by cable to the storage devices.

The following table describes the LEDs on the adapter. These LEDs reside on the nonheat-sink side of the board.

**Table 28: LED Designations**


LED	Type	Description
LED2	Yellow controller overtemperature	Stays on solid to indicate that the SAS4116 device temperature sensor is over the temperature threshold. When the device is in the proper temperature range, this LED is off.
LED3	Green system heartbeat	Indicates that the SAS4116 RoC ASIC is operating normally. This LED blinks at 1 Hz.
LED5	Yellow supercap fault	Indicates that the CacheVault power module is in fault state or is overtemperature. When the energy pack is in the FAULT condition or is missing, this LED is on.
LED6	Green ONFI activity	Indicates when the ONFI is active for cache offload or recovery.

## eHBA 9620-16i Adapter – Connector and LED Designations

The adapter is a 155.52 (±0.13) mm × 68.77 (±0.13) mm board. The component height on the top and bottom of the adapter complies with the PCIe specification.

The following figure shows the connectors and LED locations on the adapter. Pin 1 on the headers and connectors is highlighted in red in the figure.



**Figure 10: Card Layout for the eHBA 9620-16i Storage Adapter**

The following table describes the headers and connectors on the adapter.

**Table 29: Headers and Connectors**

Connector	Type	Description
J2	Standard edge card connector	The interface between the storage adapter and the host system. With the PCIe interface, this connector provides power to the board and an I <sup>2</sup> C interface connected to the I <sup>2</sup> C bus for the Intelligent Platform Management Interface (IPMI).
J4	Default SBR header	2-pin connector. Reserved for Broadcom use.
J8	Onboard serial UART connector	4-pin connector. Reserved for Broadcom use.
J10	Global HDD activity LED header	2-pin connector. Connects to an LED that indicates activity on the drives connected to the adapter.
J11	Global drive fault LED header	2-pin connector. Connects to an LED that indicates whether a drive is in a fault condition.

Connector	Type	Description
J17, J18	Storage interface connectors	Two SFF-8654 8-port internal connectors. Connect the adapter by cable to the storage devices.

The following table describes the LEDs on the adapter.


**Table 30: LED Designations**

LED	Type	Description
LED2	Yellow controller overtemperature	Stays on solid to indicate that the SAS4116 device temperature sensor is over the temperature threshold. When the device is in the proper temperature range, this LED is off.
LED3	Green system heartbeat	Indicates that the SAS4116 RoC ASIC is operating normally. This LED blinks at 1 Hz.

## eHBA 9600-24i Adapter – Connector and LED Designations

The adapter is a 155.52 (±0.13) mm × 68.77 (±0.13) mm board. The component height on the top and bottom of the adapter complies with the PCIe specification.



**Figure 11: Card Layout of the eHBA 9600-24i Tri-Mode Storage Adapter**

The following table describes the connectors on the adapter.

**Table 31: Headers and Connectors**

Connector	Type	Description
J2	Standard edge card connector	The interface between the storage adapter and the host system. With the PCIe interface, this connector provides power to the board and an I <sup>2</sup> C interface connected to the I <sup>2</sup> C bus for the IPMI.
J4	Default SBR header	2-pin connector. Reserved for Broadcom use.
J8	Onboard serial UART connector	4-pin connector. Reserved for Broadcom use.
J17, J18, J26	Storage interface connectors	Three SFF-8654 8-port internal connectors. Connect the adapter by cable to the storage devices.


The following table describes the LEDs on the adapter.

**Table 32: LED Designations**

LED	Type	Description
LED2	Yellow IOC overtemperature	Stays on solid to indicate that the SAS4024 IOC temperature sensor is over the temperature threshold. When the device is in the proper temperature range, this LED is off. This LED resides on the nonheat-sink side of the board.
LED3	Green system heartbeat	Indicates that the SAS4024 IOC is operating normally. This LED resides on the nonheat-sink side of the board.

## eHBA 9600-16i Adapter – Connector and LED Designations

The adapter is a 155.52 (±0.13) mm × 68.77 (±0.13) mm board. The component height on the top and bottom of the adapter complies with the PCIe specification.

**Figure 12: Card Layout of the eHBA 9600-16i Tri-Mode Storage Adapter**

The following table describes the connectors on the adapter.

**Table 33: Headers and Connectors**

Connector	Type	Description
J2	Standard edge card connector	The interface between the storage adapter and the host system. With the PCIe interface, this connector provides power to the board and an I <sup>2</sup> C interface connected to the I <sup>2</sup> C bus for the IPMI.
J4	Default SBR header	2-pin connector. Reserved for Broadcom use.
J8	Onboard serial UART connector	4-pin connector. Reserved for Broadcom use.
J17, J18	Storage interface connectors	Two SFF-8654 8-port internal connectors. Connect the adapter by cable to the storage devices.

The following table describes the LEDs on the adapter.


**Table 34: LED Designations**

LED	Type	Description
LED2	Yellow IOC overtemperature	Stays on solid to indicate that the SAS4016 IOC temperature sensor is over the temperature threshold. When the device is in the proper temperature range, this LED is off. This LED resides on the nonheat-sink side of the board.
LED3	Green system heartbeat	Indicates that the SAS4016 IOC is operating normally. This LED resides on the nonheat-sink side of the board.

## eHBA 9600-8i8e Adapter – Connector and LED Designations

The adapter is a 167.51 (±0.13) mm × 68.78 (±0.13) mm board. The component height on the top and bottom of the adapter complies with the PCIe specification.

The following figure shows the connectors and LED locations on the adapter. A red circle near each header and connector identifies pin 1 in the figure.

**Figure 13: Card Layout of the eHBA 9600-8i8e Tri-Mode Storage Adapter**

The following table describes the connectors on the adapter.

**Table 35: Headers and Connectors**

Connector	Type	Description
J2	Standard edge card connector	The interface between the storage adapter and the host system. With the PCIe interface, this connector provides power to the board and an I <sup>2</sup> C interface connected to the I <sup>2</sup> C bus for the IPMI.
J4	Default SBR header	2-pin connector. Reserved for Broadcom use.
J8	Onboard serial UART connector	4-pin connector. Reserved for Broadcom use.
J26	Storage interface connector	One SFF-8654 8-port internal connector. Connect the adapter by cable to the storage devices.
J163, J28	Storage interface connectors	Two SFF-8674 4-port external connectors.

The following table describes the LEDs on the adapter.


**Table 36: LED Designations**

LED	Type	Description
LED2	Yellow IOC overtemperature	Stays on solid to indicate that the SAS4016 IOC temperature sensor is over the temperature threshold. When the device is in the proper temperature range, this LED is off. This LED resides on the nonheat-sink side of the board.
LED3	Green system heartbeat	Indicates that the SAS4016 IOC is operating normally. This LED resides on the nonheat-sink side of the board.

## eHBA 9600W-16e Adapter – Connector and LED Designations

The adapter is a 167.51 (±0.13) mm × 68.78 (±0.13) mm board. The component height on the top and bottom of the adapter complies with the PCIe specification.

**Figure 14: Card Layout of the eHBA 9600W-16e Storage Adapter**



The following table describes the headers and connectors on the adapter.

**Table 37: Connectors**

Connector	Type	Description
J2	Standard board edge connector	PCIe x8 board edge connector. With the PCIe interface, this connector provides power to the board and an I <sup>2</sup> C interface connected to the I <sup>2</sup> C bus for the IPMI.
J4	Default SBR header	2-pin connector. Reserved for Broadcom use.
J8	Onboard serial UART connector	4-pin connector. Reserved for Broadcom use.
J164, J28, J29, J30	Storage interface connectors	Four SFF-8674 external connectors. Connect the adapter by cable to the storage devices.

The following table describes the LEDs on the adapter.

**Table 38: LED Designations**

LED	Type	Description
LED2	Yellow IOC overtemperature	Stays on solid to indicate that the SAS4016W IOC temperature sensor is over the temperature threshold. When the device is in the proper temperature range, this LED is off.
LED3	Green system heartbeat	Indicates that the SAS4016W IOC is operating normally.

## eHBA 9600-16e Adapter – Connector and LED Designations

The adapter is a 167.51 (±0.13) mm × 68.77 (±0.13) mm board. The component height on the top and bottom of the adapter complies with the PCIe specification.

The following figure shows the connectors and LED locations on the adapter. A red circle near each header and connector identifies pin 1 in the figure.



**Figure 15: Card Layout of the eHBA 9600-16e Storage Adapter**

The following table describes the headers and connectors on the adapter.

**Table 39: Connectors**

Connector	Type	Description
J2	Standard board edge connector	PCIe x8 board edge connector. With the PCIe interface, this connector provides power to the board and an I <sup>2</sup> C interface connected to the I <sup>2</sup> C bus for the IPMI.
J4	Default SBR header	2-pin connector. Reserved for Broadcom use.
J8	Onboard serial UART connector	4-pin connector. Reserved for Broadcom use.
J30, J29, J28, J163	Storage interface connectors	Four SFF-8674 external connectors. Connect the adapter by cable to the storage devices.

The following table describes the LEDs on the adapter.

**Table 40: LED Designations**

LED	Type	Description
LED2	Yellow IOC overtemperature	Stays on solid to indicate that the SAS4016 IOC temperature sensor is over the temperature threshold. When the device is in the proper temperature range, this LED is off.
LED3	Green system heartbeat	Indicates that the SAS4016 IOC is operating normally.

## eHBA 9602W-16e Adapter – Connector and LED Designations

The adapter is a 115.00 (±0.13) mm × 76.00 (±0.13) mm board. The board is OCP 3.0 compliant with a TSFF internal lock bracket.

The following table describes the headers and connectors on the adapter.

**Table 41: Connectors**

Connector	Type	Description
J2	Card PCIe edge connector	The interface between the storage adapter and the host system.
J4	Default SBR header	2-pin connector. Reserved for Broadcom use.
J8	Onboard serial UART connector	4-pin connector. Reserved for Broadcom use.
J163, J28, J29, J30	Storage interface connectors	Four SFF-8674 external connectors. Connect the adapter by cable to the storage devices.

The following table describes the LEDs on the adapter.

**Table 42: LED Designations**

LED	Type	Description
LED2	Yellow IOC overtemperature	Stays on solid to indicate that the SAS4016W IOC temperature sensor is over the temperature threshold. When the device is in the proper temperature range, this LED is off.
LED3	Green system heartbeat	Indicates that the SAS4016W IOC is operating normally.



## Tri-Mode Storage Adapter Technical Specifications

This chapter presents the technical specifications of each board, including operating conditions and power supply requirements.

### Board Storage Conditions

The following table lists the board storage conditions for the storage adapters.

**Table 43: Board Storage Conditions**

Adapter	Relative Humidity Range (Non-condensing)	Temperature Range <sup>a</sup>
9670W-16i	10% to 90%	-40°C to +70°C
9670-24i	10% to 90%	-40°C to +70°C
9660-16i	10% to 90%	-40°C to +70°C
9620-16i	10% to 90%	-40°C to +70°C
9600-24i	10% to 90%	-40°C to +70°C
9600-16i	10% to 90%	-40°C to +70°C
9600-8i8e	10% to 90%	-40°C to +70°C
9600W-16e	10% to 90%	-40°C to +70°C
9600-16e	10% to 90%	-40°C to +70°C
9602W-16e	10% to 90%	-40°C to +70°C

### Board Operating Conditions

The following table lists the board operating conditions for the storage adapters. The minimum airflow, measured as linear feet per minute (LFM) at 55°C, must be met to avoid operating the controller's processor and board components above their maximum junction temperatures.

**Table 44: Board Operating Conditions**

Adapter	Minimum LFM	Temperature Range <sup>a</sup>
9670W-16i	200	0°C to +55°C
9670-24i	200	0°C to +55°C
9660-16i	250	0°C to +55°C
9620-16i	150	0°C to +55°C
9600-24i	150	0°C to +55°C
9600-16i	150	0°C to +55°C
9600-8i8e	200	0°C to +55°C

a. For adapters with a CVPM, this range applies with or without the CVPM attached.  
a. For adapters with a CVPM, this range applies with or without the CVPM attached.

Adapter	Minimum LFM	Temperature Range <sup>a</sup>
9600W-16e	200	0°C to +55°C
9600-16e	200	0°C to +55°C
9602W-16e	200	0°C to +55°C

## Power Supply Requirements

All power is supplied to the tri-mode storage adapter through the PCIe 3.3V rails (3.3V ±9%) and the 12V rail (12V ±8%). Onboard switching regulator circuitry operates from the 3.3V rails and the 12V rail provides the necessary voltages.

Typical power is measured with maximum I/O traffic, typical silicon process material, and nominal voltages operating the card at an ambient temperature of 45°C with required airflow.

The system might transmit a PCI Set Slot Power Limit Message that indicates the maximum amount of power that the adapter might use. During the start-up procedure, the adapter's power consumption is limited to 25W because the storage phys are not enabled until the Auto Port Enable procedure begins. When this procedure begins, the adapter's power check algorithm compares the power allocated by the SET\_SLOT\_POWER\_LIMIT message to the adapter's slot power requirement. If the SET\_SLOT\_POWER\_LIMIT message indicates that the slot's power budget is at or greater than the adapter's requirement, Auto Port Enable proceeds. Refer to *SAS95xx Adapters and SAS96xx Adapters Slot Power Limit Settings Specification* for more information about slot power requirements.

If no SET\_SLOT\_POWER\_LIMIT message is received by the time Auto Port Enable is to start, the adapter continues with port enable. You must make sure enough power is available to the slot if the SET\_SLOT\_POWER\_LIMIT message is not used. For adapters with auxiliary power connectors, the slot power check is bypassed if the auxiliary power connector is connected. For more information about the auxiliary power connector, see [Auxiliary Power Connector](#).

## MegaRAID Tri-Mode Storage Adapter Power Supply Requirements

The following table describes the typical power consumption of the MegaRAID adapters.

**Table 45: MegaRAID Tri-Mode Storage Adapter Typical Power Consumption**

Adapter	Typical Power (W)
9670W-16i	28
9670-24i	28
9660-16i	20

During the transparent learn cycle, the CacheVault power module consumes up to an additional 8W. The PCIe 3.3V rail supplies the power for the learn cycle.

## eHBA Tri-Mode Storage Adapter Power Supply Requirements

The following table describes the typical power consumption of the eHBAs.

**Table 46: eHBA Tri-Mode Storage Adapter Typical Power Consumption**

Adapter	Typical Power (W)
9620-16i	17
9600-24i	20

a. For adapters with a CVPM, this range applies with or without the CVPM attached.

Adapter	Typical Power (W)
9600-16i	17
9600-8i8e	17
9600W-16e	20
9600-16e	17
9602W-16e	20

## Overtemperature Behavior

The adapter supports the following temperature threshold events to alert of overtemperature situations when sufficient airflow is not provided. If supported, the system can use the events generated in the Persistent Event Log (PEL) to manage fan speed and mitigate overtemperature conditions. While these events assist in managing overtemperature conditions, potential damage can occur if sufficient airflow is not provided to the adapter.

**Table 47: Temperature Threshold Events**

Condition	RoC or IOC Junction Temperature (°C)	Result
Warning	105	Generate a PEL event.
Critical	107	Generate a PEL event and decrease device-side ports to their slowest operating speed. The junction temperature must return to 104°C, or lower, to resume normal operation.
Fatal	115	Generate a PEL event and fault the adapter. The junction temperature must return to 104°C, or lower, and the adapter must be reset to resume normal operation.

## Marks, Certifications, Compliance, and Safety Characteristics

This chapter lists the adapter marks and certifications, FCC compliance statements, and safety characteristics.

### Marks, Certifications, and Compliance



The design and implementation of the adapters minimize electromagnetic emissions, susceptibility to radio frequency energy, and the effects of electrostatic discharge.








The following adapters show the marks and certifications included in [Table 49, Adapter Marks and Certifications](#).

**Table 48: Adapter Models**

Adapter	Model Number
MegaRAID 9670W-16i	50113
MegaRAID 9660-16i	50107
eHBA 9600-24i eHBA 9600-16i eHBA 9620-16i	50111
eHBA 9600-8i8e	50145
eHBA 9600W-16e	50108
eHBA 9600-16e	50118
eHBA 9602W-16e	50160

**Table 49: Adapter Marks and Certifications**

Mark	Symbol	Description
Australia and New Zealand RCM		Meets the following standards: <ul style="list-style-type: none"> <li>AS/NZS CISPR 32</li> <li>CISPR 32:2015, Class A</li> <li>AS/NZS CISPR 32:2015 +A1:2020, Class A</li> </ul>
Canada EMC	CANADA ICES-003 CLASS A CANADA NMB-003 CLASSE A CAN ICES-3 (A)/NMB-3 (A)	Meets the following standards: <ul style="list-style-type: none"> <li>ICES-003:2016 Issue 7: 2016, Class A</li> <li>CAN/CSA CISPR 22-10</li> <li>CISPR 22:2008</li> </ul>
Europe (CE)		Meets the following standards: <ul style="list-style-type: none"> <li>EN 55032, EN 55035</li> <li>EN 55032:2015 +A11:2020, Class A</li> <li>EN 55035:2017 +A11:2020, Class A</li> </ul>

Mark	Symbol	Description
Korea (RRL)		xxxxx = model number Meets the KN32/KN35 testing requirements.
Taiwan (BSMI)		Meets the following standards: <ul style="list-style-type: none"> <li>• CNS15663</li> <li>• CNS15936</li> </ul>
USA / Canada Safety (UL Listed)		For use with UL-listed ITE equipment only. Meets the following standards: <ul style="list-style-type: none"> <li>• CAN/CSA C22.2 No. 62368-1-19, Third Edition</li> <li>• UL 62368-1, Third Edition</li> </ul>
CB Scheme Safety	—	Meets the following standards: <ul style="list-style-type: none"> <li>• IEC 62368-1:2014 (Third edition)</li> <li>• EN 62368-1:2014+A11: 2017</li> </ul>
Japan (VCCI)		Meets the following standards: <ul style="list-style-type: none"> <li>• VCCI-CISPR 32:2016</li> </ul>
USA / Canada (FCC)		Meets the following standards: <ul style="list-style-type: none"> <li>• 47 CFR FCC Part 15, Subpart B, Class A</li> <li>• ANSI C63.4:2014</li> <li>• CISPR 32:2008</li> </ul>
Morocco (CMIM)		Meets the following standards: <ul style="list-style-type: none"> <li>• EN 55032, EN 55035</li> <li>• EN 55032:2015 +A11:2020, Class A</li> <li>• EN 55035:2017 +A11:2020</li> </ul>
United Kingdom (UKCA)		Meets the following standards: <ul style="list-style-type: none"> <li>• EN 55032, EN 55035</li> <li>• EN 55032:2015 +A11:2020, Class A</li> <li>• EN 55035:2017 +A11:2020</li> </ul>
Country of Origin	Made in XXXX	XXXX indicates the country of origin.

## FCC Compliance

This device complies with part 15 of the FCC rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### NOTE

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user is required to correct the interference at his or her own expense.

## Safety Characteristics

All tri-mode storage adapters meet or exceed the requirements of UL flammability rating 94 V0. Each bare board is also marked with the supplier name or trademark, type, and UL flammability rating. For the boards installed in a PCIe bus slot, all voltages are lower than the SELV 42.4V limit.

## Cable Drawings and Pinouts

---


Use the cable drawings and pinouts in this appendix if your design requires you to design your own cables.

### Cable 05-60001-00

The following figure shows the drawing and pinout for Broadcom cable 05-60001-00, a x8 SFF-8654 to 2 x4 SFF-8612 connection.

Figure 16: Cable 05-60001-00 Drawing and Pinout

REVISIONS				
REV	ECO	DESCRIPTION	DATE	APPROVED
001		PRELIMINARY RELEASE	26FEB18	
002	175141	UPDATE WIRE GAUGE AND IMPEDANCE TOLERANCE ITEM 3, REVISE MARKING REQUIREMENTS NOTE 3.	21NOV19	



- NOTES:**
- DRAWING NOT TO SCALE.
  - ELECTRICAL AND MECHANICAL PERFORMANCE SHALL MEET PCIe GEN 4 AND SAS 4.0 INDUSTRIAL STANDARDS.
  - MARK LABEL (ITEM 8) WITH:  
SLIMSAS Y (PCIe)  
BROADCOM PART NUMBER  
BROADCOM REVISION-XXX  
DATE CODE DD/MM/YY  
SECONDARY MARKING WITH MANUFACTURER PART NUMBER AND REVISION ACCEPTABLE.
  - SEE CABLE WIRING TABLE AND RELATED NOTES.

ITEM	CALLOUT	DESCRIPTION	QUANTITY	NOTES
9	LABEL	LABEL, 40X14MM, WHITE, R2, HF	A/R	
8	LABEL	LABEL, 70X28MM, WHITE, R2, HF	A/R	SEE NOTE 3
7	TAPE	ACETATE TAPE: W=1 INCH	A/R	
6	SLEEVING	EXPANDO TUBE: OD=7MM, GREEN, VW-1, HF	A/R	
5	SLEEVING	EXPANDO TUBE: OD=10MM, GREEN, VW-1, HF	A/R	
4	WIRE	UL1061, STRANDED	A/R	SEE NOTE 4
3	CABLE	SAS CABLE: UL20744, 28-32AWG, 92.5(2) ±10% DIFF, SAS4, PCIe GEN 4, VW-1, NATURAL, HF	A/R	
2	CONNECTOR	SFF-8612, 42P, STRAIGHT, ACTIVE LATCH, X4, SAS 4.0, PCIe GEN 4	2	SEE NOTE 4
1	CONNECTOR	SFF-8654, 74P, STRAIGHT, X8, SAS 4.0, PCIe GEN 4	1	SEE NOTE 4
ITEM	CALLOUT	DESCRIPTION	QUANTITY	NOTES

APPROVALS	DATE	UNLESS OTHERWISE SPECIFIED, DIMENSIONS ARE IN MILLIMETERS.	BROADCOM®			
DRAWN BY	06FEB18	TOLERANCES: X, Y, Z: 0.2 MM X, Y, Z: 0.15 MM X, Y, Z: 0.050 MM ANGLES: ±0.5°	TITLE: CABLE, SFF-8654 X8 TO 2X SFF-8612 X4, PCIe, 1M			
APPROVED BY	26FEB18	SCALE: 1:500	SIZE: D	DRG NO.: 5067-6865	REV: 002	SHEET

CONNECTOR	SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR	SIGNAL	WIRE/CABLE	NOTES
NC		S0 HOST	A1	P0 BACKPLANE	B1	NC			
GND			A2		B2	GND	ITEM 3		
Rx0+			A3		B3	Tx0+	ITEM 3		
Rx0-			A4		B4	Tx0-	ITEM 3		
GND			A5		B5	GND	ITEM 3		
Rx1+			A6		B6	Tx1+	ITEM 3		
Rx1-			A7		B7	Tx1-	ITEM 3		
GND			A8		B8	GND	ITEM 3		
SB7A			A9		B9	NC		NOTE 2	
SB4A			A10		B10	CWAKE#	ITEM 4	NOTE 1	
SB3A			A11		B11	CBL_ID	ITEM 4	NOTE 1	
SB3A			A12		B12	GND	ITEM 3		
SBA+			A13		B13	REFCLK+	ITEM 3		
SBA-			A14		B14	REFCLK-	ITEM 3		
GND			A15		B15	GND	ITEM 3		
Rx2+			A16		B16	Tx2+	ITEM 3		
Rx2-			A17		B17	Tx2-	ITEM 3		
GND			A18		B18	GND	ITEM 3		
Rx3+			A19		B19	Tx3+	ITEM 3		
GND			B20	GND	ITEM 3				
NC			B21	NC					
NC			A1	NC					
GND			A2	GND	ITEM 3				
Tx0+			A3	Rx0+	ITEM 3				
Tx0-			A4	Rx0-	ITEM 3				
GND			A5	GND	ITEM 3				
Tx1+			A6	Rx1+	ITEM 3				
Tx1-			A7	Rx1-	ITEM 3				
GND			A8	GND	ITEM 3				
SB0A			A9	SCL	ITEM 4	NOTE 1			
SB1A			A10	SDA	ITEM 4	NOTE 1			
SB2A			A11	GND	ITEM 3				
SB5A			A12	PERST#	ITEM 3				
SB6A			A13	D_INPL#	ITEM 3				
GND			A14	GND	ITEM 3				
Tx2+			A15	Rx2+	ITEM 3				
Tx2-			A16	Rx2-	ITEM 3				
GND			A17	GND	ITEM 3				
Tx3+			A18	Rx3+	ITEM 3				
Tx3-			A19	Rx3-	ITEM 3				
GND			A20	GND	ITEM 3				
NC			A21	NC					

- NOTES:**
- END TO END RESISTANCE OF INDICATED CONNECTION SHALL BE 750 MILLIOHM MAX.
  - SHORT PIN/PAD S0-A8 TO S0-B9. NO DIRECT CONNECT S0-A8 TO CONNECTOR P0.
  - SHORT PIN/PAD S0-A26 TO S0-B27. NO DIRECT CONNECT S0-A26 TO CONNECTOR P1.

CONNECTOR	SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR	SIGNAL	WIRE/CABLE	NOTES
NC		S0 HOST	A19	P1 BACKPLANE	B1	NC			
GND			A20		B2	GND	ITEM 3		
Rx4+			A21		B3	Tx0+	ITEM 3		
Rx4-			A22		B4	Tx0-	ITEM 3		
GND			A23		B5	GND	ITEM 3		
Rx5+			A24		B6	Tx1+	ITEM 3		
Rx5-			A25		B7	Tx1-	ITEM 3		
GND			A26		B8	GND	ITEM 3		
SB7B			A27		B9	NC		NOTE 3	
SB4B			A28		B10	CWAKE#	ITEM 4	NOTE 1	
SB3B			A29		B11	CBL_ID	ITEM 4	NOTE 1	
SB3B			A30		B12	GND	ITEM 3		
SB0+			A31		B13	REFCLK+	ITEM 3		
SB-			A32		B14	REFCLK-	ITEM 3		
GND			A33		B15	GND	ITEM 3		
Rx6+			A34		B16	Tx2+	ITEM 3		
Rx6-			A35		B17	Tx2-	ITEM 3		
GND			A36		B18	GND	ITEM 3		
Rx7+			A37		B19	Tx3+	ITEM 3		
Rx7-					B20	Tx3-	ITEM 3		
GND					B21	GND	ITEM 3		
NC					B22	NC			
NC					B23	NC			
GND					B24	GND	ITEM 3		
Tx4+					B25	Rx0+	ITEM 3		
Tx4-					B26	Rx0-	ITEM 3		
GND					B27	GND	ITEM 3		
Tx5+					B28	Rx1+	ITEM 3		
Tx5-					B29	Rx1-	ITEM 3		
GND					B30	GND	ITEM 3		
SB0B					B31	SCL	ITEM 4	NOTE 1	
SB1B					B32	SDA	ITEM 4	NOTE 1	
SB2B					B33	GND	ITEM 3		
SB5B					B34	PERST#	ITEM 3		
SB6B					B35	D_INPL#	ITEM 3		
GND					B36	GND	ITEM 3		
Tx6+					B37	Rx2+	ITEM 3		
Tx6-				Rx2-	ITEM 3				
GND				GND	ITEM 3				
Tx7+				Rx3+	ITEM 3				
Tx7-				Rx3-	ITEM 3				
GND				GND	ITEM 3				
NC				NC					




# Cable 05-60002-00

The following figure shows the drawing and pinout for Broadcom cable 05-60002-00, a x8 SFF-8654 to 2 x4 SFF-8643 connection. Use this cable for NVMe connections on SuperMicro Purley backplanes.

Figure 17: Cable 05-60002-00 Drawing and Pinout

REVISIONS				
REV	ECO	DESCRIPTION	DATE	APPROVED
001		PRELIMINARY RELEASE	09FEB18	
002	141562	PRELIMINARY RELEASE. UPDATE WIRE GAUGE AND IMPEDANCE TOLERANCE. ITEM 3, REVISE MARKING REQUIREMENTS NOTE. ADD HOST CONNECTOR LABEL. ADD HOST AND TARGET WIRING TABLE. WIRING CHANGES TO FOLLOWING PIN/PADS IN WIRING TABLE: S0: B9-B10, B4-B26; P0: B1, C1-C2, D1-D2, P1: B1, C1-C2, D1-D2	13JUL18	
003	175141	INITIAL RELEASE. REMOVE WATERMARK.	21NOV19	



- NOTES:**
- DRAWING NOT TO SCALE.
  - ELECTRICAL AND MECHANICAL PERFORMANCE SHALL MEET PCIe GEN 4 INDUSTRIAL STANDARDS.
  - MARK LABEL (ITEM B) WITH:  
SLIMSAS Y (PCIe ONLY)  
BROADCOM PART NUMBER  
BROADCOM REVISION XXX  
DATE CODE DD/MM/YY  
SECONDARY MARKING WITH MANUFACTURER PART NUMBER AND REVISION ACCEPTABLE.
  - SEE CABLE WIRING TABLE AND RELATED NOTES.

ITEM	CALLOUT	DESCRIPTION	QUANTITY	NOTES
9	LABEL	LABEL, 40X14MM, WHITE, R2, HF	A/R	
8	LABEL	LABEL, 70X26MM, WHITE, R2, HF	A/R	SEE NOTE 3
7	TAPE	ACETATE TAPE: W=1 INCH	A/R	
6	SLEEVING	EXPANDO TUBE: OD=7MM, GREEN, VW-1, HF	A/R	
5	SLEEVING	EXPANDO TUBE: OD=10MM, GREEN, VW-1, HF	A/R	
4	WIRE	UL1061, STRANDED	A/R	SEE NOTE 4
3	CABLE	SAS CABLE: UL20744, 28-32AWG, 92 SC ±10% DIFF, PCIe GEN 4, VW-1, NATURAL, HF	A/R	SEE NOTE 4
2	CONNECTOR	SFF-8643, 36P, STRAIGHT, X4, WHITE, SHORT, PCIe GEN 4	2	SEE NOTE 4
1	CONNECTOR	SFF-8654, 74P, STRAIGHT, X8, SAS 4.0, PCIe GEN 4	1	SEE NOTE 4

APPROVALS	DATE	UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN MILLIMETERS.	BROADCOM®	
APPROVED BY	05FEB18	TOLERANCES: X, Y, Z ± 0.25 MM X, Y, Z ± 0.15 MM X, Y, Z ± 0.250 MM	TITLE	
APPROVED BY	09FEB18	ANGLES ± 0.250 MM	CABLE, SFF-8654 X8 TO 2X SFF-8643 X4 (W), 1M	
<small>Company Confidential © Copyright Broadcom Limited. All rights reserved. No copy or use is permitted without the express written consent of Broadcom. The purchaser is responsible for verifying that the dimensions of this product are consistent with the dimensions of the original manufacturer's documents from their point of sale.</small>			SIZE	DWG NO. 5067-6862
			REV	003
			SHEET	

CONNECTOR SIGNAL	CONNECTOR (HOST)	PIN/PAD	CONNECTOR (TARGET)	PIN/PAD	CONNECTOR SIGNAL	WIRE/CABLE
GND	S0	A1	P0	D3	GND	ITEM 3
Rx0+		A2		D4	Tx0+	ITEM 3
Rx0-		A3		D5	Tx0-	ITEM 3
GND		A4		C3/D6	GND	ITEM 3, NOTE 2
Rx1+		A5		C4	Tx1+	ITEM 3
Rx1-		A6		C5	Tx1-	ITEM 3
GND		A7		C6	GND	ITEM 3
SB7A		A8			NC	NOTE 3
SB4A		A9			NC	
SB3A		A10		A3	GND	ITEM 3
SB4+		A11		A2	REFCLK+	ITEM 3
SB4-		A12		A1	REFCLK-	ITEM 3
GND		A13		D6	GND	ITEM 3
Rx2+		A14		D7	Tx2+	ITEM 3
Rx2-		A15		D8	Tx2-	ITEM 3
GND		A16		D9/C6	GND	ITEM 3, NOTE 2
Rx3+		A17		C7	Tx3+	ITEM 3
Rx3-		A18		C8	Tx3-	ITEM 3
GND		A19		C9	GND	ITEM 3
GND		B1		B3	GND	ITEM 3
Tx0+		B2		B4	Rx0+	ITEM 3
Tx0-		B3		B5	Rx0-	ITEM 3
GND		B4		B6/A3	GND	ITEM 3, NOTE 2
Tx1+		B5		A4	Rx1+	ITEM 3
Tx1-		B6		A5	Rx1-	ITEM 3
GND		B7		A6	GND	ITEM 3
SB0A		B8		D1	2W_CLK	ITEM 4, NOTE 1
SB1A		B9		D2	2W_SDA	ITEM 4, NOTE 1
SB2A		B10			NC	SHORT TO GND
SB5A		B11		B2	PERST#	ITEM 4, NOTE 1
SB6A		B12			NC	SHORT TO GND
GND		B13		B6	GND	ITEM 3
Tx2+		B14		B7	Rx2+	ITEM 3
Tx2-		B15		B8	Rx2-	ITEM 3
GND		B16		B9/A6	GND	ITEM 3, NOTE 2
Tx3+		B17		A7	Rx3+	ITEM 3
Tx3-		B18		A8	Rx3-	ITEM 3
GND		B19		A9	GND	ITEM 3
				C1	NC	
				C2	NC	
				B1	NC	

CONNECTOR SIGNAL	CONNECTOR (HOST)	PIN/PAD	CONNECTOR (TARGET)	PIN/PAD	CONNECTOR SIGNAL	WIRE/CABLE
GND	S0	A19	P1	D3	GND	ITEM 3
Rx4+		A20		D4	Tx0+	ITEM 3
Rx4-		A21		D5	Tx0-	ITEM 3
GND		A22		C3/D6	GND	ITEM 3, NOTE 2
Rx5+		A23		C4	Tx1+	ITEM 3
Rx5-		A24		C5	Tx1-	ITEM 3
GND		A25		C6	GND	ITEM 3
SB7B		A26			NC	NOTE 5
SB4B		A27			NC	
SB3B		A28		A3	GND	ITEM 3
SB4+		A29		A2	REFCLK+	ITEM 3
SB4-		A30		A1	REFCLK-	ITEM 3
GND		A31		D6	GND	ITEM 3
Rx6+		A32		D7	Tx2+	ITEM 3
Rx6-		A33		D8	Tx2-	ITEM 3
GND		A34		D9/C6	GND	ITEM 3, NOTE 2
Rx7+		A35		C7	Tx3+	ITEM 3
Rx7-		A36		C8	Tx3-	ITEM 3
GND		A37		C9	GND	ITEM 3
GND		B19		B3	GND	ITEM 3
Tx4+		B20		B4	Rx0+	ITEM 3
Tx4-		B21		B5	Rx0-	ITEM 3
GND		B22		B6/A3	GND	ITEM 3, NOTE 2
Tx5+		B23		A4	Rx1+	ITEM 3
Tx5-		B24		A5	Rx1-	ITEM 3
GND		B25		A6	GND	ITEM 3
SB0B		B26		D1	2W_CLK	ITEM 4, NOTE 1
SB1B		B27		D2	2W_SDA	ITEM 4, NOTE 1
SB2B		B28			NC	SHORT TO GND
SB5B		B29		B2	PERST#	ITEM 4, NOTE 1
SB6B		B30			NC	SHORT TO GND
GND		B31		B6	GND	ITEM 3
Tx6+		B32		B7	Rx2+	ITEM 3
Tx6-		B33		B8	Rx2-	ITEM 3
GND		B34		B9/A6	GND	ITEM 3, NOTE 2
Tx7+		B35		A7	Rx3+	ITEM 3
Tx7-		B36		A8	Rx3-	ITEM 3
GND		B37		A9	GND	ITEM 3
				C1	NC	
				C2	NC	
				B1	NC	


- NOTES:**
- END TO END RESISTANCE OF INDICATED CONNECTION SHALL BE 750 MILLIOHM MAX.
  - CONNECT SHIELD OF DIFFERENTIAL PAIR TO INDICATED PIN/PAD AND SHORT TO SECOND INDICATED PIN/PAD.
  - SHORT PIN/PAD S0-A8 TO S0-B9. NO DIRECT CONNECT S0-A8 TO CONNECTOR P0.
  - DELETED
  - SHORT PIN/PAD S0-A26 TO S0-B27. NO DIRECT CONNECT S0-A26 TO CONNECTOR P1.
  - DELETED

# Cable 05-60003-00

The following figure shows the drawing and pinout for Broadcom cable 05-60003-00, a x8 SFF-8654 to 2 x4 SFF-8643 connection.

Figure 18: Cable 05-60003-00 Drawing and Pinout

REVISIONS				
REV	ECO	DESCRIPTION	DATE	APPROVED
001		PRELIMINARY RELEASE	28FEB18	
002	175141	UPDATE WIRE GAUGE AND IMPEDANCE TOLERANCE ITEM 3; REVISE MARKING REQUIREMENTS NOTE 3.	21NOV19	



- NOTES:**
- DRAWING NOT TO SCALE.
  - ELECTRICAL AND MECHANICAL PERFORMANCE SHALL MEET SAS 4.0 INDUSTRIAL STANDARDS.
  - MARK LABEL (ITEM 8) WITH:  
SLIMSAS Y (SFF-9402 SAS)  
BROADCOM PART NUMBER  
BROADCOM REVISION XXX  
DATE CODE DD/MM/YY  
SECONDARY MARKING WITH MANUFACTURER PART NUMBER AND REVISION ACCEPTABLE.
  - SEE CABLE WIRING TABLE AND RELATED NOTES.

ITEM	CALLOUT	DESCRIPTION	QUANTITY	NOTES
9	LABEL	LABEL, 40X14MM, WHITE, R2, HF	A/R	
8	LABEL	LABEL, 70X26MM, WHITE, R2, HF	A/R	SEE NOTE 3
7	TAPE	ACETATE TAPE: W=1 INCH	A/R	
6	SLEEVING	EXPANDO TUBE: OD=7MM, BLACK, VW-1, HF	A/R	
5	SLEEVING	EXPANDO TUBE: OD=10MM, BLACK, VW-1, HF	A/R	
4	WIRE	UL1061, STRANDED	A/R	SEE NOTE 4
3	CABLE	SAS CABLE: UL20744, 28-32AWG, 92.5Ω ±10% DIFF, PCIe GEN 4, VW-1, NATURAL, HF	A/R	
2	CONNECTOR	SFF-8643, 36P, STRAIGHT, X4, BLACK, SHORT, SAS 4.0	2	SEE NOTE 4
1	CONNECTOR	SFF-8654, 74P, STRAIGHT, X8, SAS 4.0, PCIe GEN 4	1	SEE NOTE 4

APPROVALS	DATE	UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN MILLIMETERS. TOLERANCES:	BROADCOM®		
DESIGNED BY:	15FEB18	L.X ± 0.2 MM	TITLE	CABLE, SFF-8654 X8 TO 2X	
APPROVED BY:	28FEB18	L.X ± 0.15 MM		SFF-8643 X4, 1M	
		L.X ± 0.050 MM	SCALE	1:500	
		ANGLES ± 1°	SHEET	D	
			DWG NO.	5067-6866	
			REV	002	SHEET

CONNECTOR SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR SIGNAL	WIRE/CABLE	NOTES
GND	S0	A1	P0	D3	GND	ITEM 3	
Rx0+	S0	A2	P0	D4	Tx0+	ITEM 3	
Rx0-	S0	A3	P0	D5	Tx0-	ITEM 3	
GND	S0	A4	P0	C3/D6	GND	ITEM 3	NOTE 2
Rx1+	S0	A5	P0	C4	Tx1+	ITEM 3	
Rx1-	S0	A6	P0	C5	Tx1-	ITEM 3	
GND	S0	A7	P0	C6	GND	ITEM 3	
SB7A	S0	A8	P0	A2	SB7	ITEM 4	NOTE 1
SB4A	S0	A9	P0	C2	SB4	ITEM 4	NOTE 1
SB3A	S0	A10	P0	B2	SB3	ITEM 4	NOTE 1
SB0+	S0	A11	P0		NC		
SB0-	S0	A12	P0		NC		
GND	S0	A13	P0	D6	GND	ITEM 3	
Rx2+	S0	A14	P0	D7	Tx2+	ITEM 3	
Rx2-	S0	A15	P0	D8	Tx2-	ITEM 3	
GND	S0	A16	P0	D9/C6	GND	ITEM 3	NOTE 2
Rx3+	S0	A17	P0	C7	Tx3+	ITEM 3	
Rx3-	S0	A18	P0	C8	Tx3-	ITEM 3	
GND	S0	A19	P0	C9	GND	ITEM 3	
GND	S0	B1	P0	B3	GND	ITEM 3	
Tx0+	S0	B2	P0	B4	Rx0+	ITEM 3	
Tx0-	S0	B3	P0	B5	Rx0-	ITEM 3	
GND	S0	B4	P0	B6/A3	GND	ITEM 3	NOTE 2
Tx1+	S0	B5	P0	A4	Rx1+	ITEM 3	
Tx1-	S0	B6	P0	A5	Rx1-	ITEM 3	
GND	S0	B7	P0	A6	GND	ITEM 3	
SBOA	S0	B8	P0	A1	SBO	ITEM 4	NOTE 1
SB1A	S0	B9	P0	B1	SB1	ITEM 4	NOTE 1
SB2A	S0	B10	P0	C1	SB2	ITEM 4	NOTE 1
SB5A	S0	B11	P0	D2	SB5	ITEM 4	NOTE 1
SB6A	S0	B12	P0	D1	SB6	ITEM 4	NOTE 1
GND	S0	B13	P0	B6	GND	ITEM 3	
Tx2+	S0	B14	P0	B7	Rx2+	ITEM 3	
Tx2-	S0	B15	P0	B8	Rx2-	ITEM 3	
GND	S0	B16	P0	B9/A6	GND	ITEM 3	NOTE 2
Tx3+	S0	B17	P0	A7	Rx3+	ITEM 3	
Tx3-	S0	B18	P0	A8	Rx3-	ITEM 3	
GND	S0	B19	P0	A9	GND	ITEM 3	

CONNECTOR SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR SIGNAL	WIRE/CABLE	NOTES
GND	S0	A19	P1	D3	GND	ITEM 3	
Rx4+	S0	A20	P1	D4	Tx4+	ITEM 3	
Rx4-	S0	A21	P1	D5	Tx4-	ITEM 3	
GND	S0	A22	P1	C3/D6	GND	ITEM 3	NOTE 2
Rx5+	S0	A23	P1	C4	Tx5+	ITEM 3	
Rx5-	S0	A24	P1	C5	Tx5-	ITEM 3	
GND	S0	A25	P1	C6	GND	ITEM 3	
SB7B	S0	A26	P1	A2	SB7	ITEM 4	NOTE 1
SB4B	S0	A27	P1	C2	SB4	ITEM 4	NOTE 1
SB3B	S0	A28	P1	B2	SB3	ITEM 4	NOTE 1
SB0+	S0	A29	P1		NC		
SB0-	S0	A30	P1		NC		
GND	S0	A31	P1	D6	GND	ITEM 3	
Rx6+	S0	A32	P1	D7	Tx2+	ITEM 3	
Rx6-	S0	A33	P1	D8	Tx2-	ITEM 3	
GND	S0	A34	P1	D9/C6	GND	ITEM 3	NOTE 2
Rx7+	S0	A35	P1	C7	Tx3+	ITEM 3	
Rx7-	S0	A36	P1	C8	Tx3-	ITEM 3	
GND	S0	A37	P1	C9	GND	ITEM 3	
GND	S0	B19	P1	B3	GND	ITEM 3	
Tx4+	S0	B20	P1	B4	Rx0+	ITEM 3	
Tx4-	S0	B21	P1	B5	Rx0-	ITEM 3	
GND	S0	B22	P1	B6/A3	GND	ITEM 3	NOTE 2
Tx5+	S0	B23	P1	A4	Rx1+	ITEM 3	
Tx5-	S0	B24	P1	A5	Rx1-	ITEM 3	
GND	S0	B25	P1	A6	GND	ITEM 3	
SB0B	S0	B26	P1	A1	SBO	ITEM 4	NOTE 1
SB1B	S0	B27	P1	B1	SB1	ITEM 4	NOTE 1
SB2B	S0	B28	P1	C1	SB2	ITEM 4	NOTE 1
SB5B	S0	B29	P1	D2	SB5	ITEM 4	NOTE 1
SB6B	S0	B30	P1	D1	SB6	ITEM 4	NOTE 1
GND	S0	B31	P1	B6	GND	ITEM 3	
Tx6+	S0	B32	P1	B7	Rx2+	ITEM 3	
Tx6-	S0	B33	P1	B8	Rx2-	ITEM 3	
GND	S0	B34	P1	B9/A6	GND	ITEM 3	NOTE 2
Tx7+	S0	B35	P1	A7	Rx3+	ITEM 3	
Tx7-	S0	B36	P1	A8	Rx3-	ITEM 3	
GND	S0	B37	P1	A9	GND	ITEM 3	


- NOTES:**
- END TO END RESISTANCE OF INDICATED CONNECTION SHALL BE 750 MILLIOHM MAX.
  - CONNECT SHIELD OF DIFFERENTIAL PAIR TO INDICATED PIN/PAD AND SHORT TO SECOND INDICATED PIN/PAD.

# Cable 05-60004-00

The following figure shows the drawing and pinout for Broadcom cable 05-60004-00, a x8 SFF-8654 to 2 x4 SFF-8654 connection.

Figure 19: Cable 05-60004-00 Drawing and Pinout

REVISIONS				
REV	ECO	DESCRIPTION	DATE	APPROVED
001		INITIAL RELEASE	02JAN18	



- NOTES:**
- DRAWING NOT TO SCALE.
  - ELECTRICAL AND MECHANICAL PERFORMANCE SHALL MEET SAS 4.0 AND PCIe GEN 4 INDUSTRIAL STANDARDS.
  - MARK LABEL (ITEM 8) WITH:  
SFF-9402 SLIMSAS Y (PCIe & SAS)  
PART NUMBER  
REVISION XXX  
DATE CODE DD/MM/YY
  - SEE CABLE WIRING TABLE.

ITEM	CALCOUT	DESCRIPTION	QUANTITY	NOTES
9	LABEL	LABEL, 40X14MM, WHITE, R2, HF		A/R
8	LABEL	LABEL, 70X26MM, WHITE, R2, HF		A/R SEE NOTE 3
7	TAPE	ACETATE TAPE, W:1 INCH		A/R
6	SLEEVING	EXPANDO TUBE: OD:2MM, GREEN, VW-1, HF		A/R
5	SLEEVING	EXPANDO TUBE: OD:10MM, GREEN, VW-1, HF		A/R
4	WIRE	UL1061, 32AWG, STRANDED		A/R
3	CABLE	SAS CABLE: UL20744, 32AWG, 85OHM DIFF, SAS4, PCIe GEN 4, VW-1, NATURAL, HF		A/R
2	CONNECTOR	SFF-8654, 38P, STRAIGHT, X4, SAS 4.0, PCIe GEN 4	2	SEE NOTE 4
1	CONNECTOR	SFF-8654, 74P, STRAIGHT, X8, SAS 4.0, PCIe GEN 4	1	SEE NOTE 4

APPROVALS	DATE	UNLESS OTHERWISE SPECIFIED, DIMENSIONS ARE IN MILLIMETERS.	BROADCOM®	
DESIGNED BY	27DEC17	X.XX ± 0.2 MM X.XX ± 0.15 MM X.XX ± 0.050 MM ANGLES ± 1°	CABLE, SFF-8654 X8 TO 2X SFF-8654 X4, 1M	
APPROVED BY	02JAN18			
Copyright © 2017 Broadcom Limited. All Rights Reserved. No part of this document may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, without the prior written permission of Broadcom Limited. The purchaser is responsible for verifying that the dimensions in this document are correct. The purchaser is responsible for ensuring accurate dimensions from their point of sale.			SCALE	SIZE
			1:500	D 5067-6103
				REV 001 SHEET

CONNECTOR SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR SIGNAL	WIRE/CABLE
GND	SO	A1	PO	B1	GND	ITEM 3
Rx0+		A2	B2	Tx0+	ITEM 3	
Rx0-		A3	B3	Tx0-	ITEM 3	
GND		A4	B4	GND	ITEM 3	
Rx1+		A5	B5	Tx1+	ITEM 3	
Rx1-		A6	B6	Tx1-	ITEM 3	
GND		A7	B7	GND	ITEM 3	
SB7A		A8	B8	SB7	ITEM 4	
SB4A		A9	B9	SB4	ITEM 4	
GND(SB3A)		A10	B10	GND(SB3)	ITEM 3	
SB4+		A11	B11	SB4+	ITEM 3	
SB4-		A12	B12	SB4-	ITEM 3	
GND		A13	B13	GND	ITEM 3	
Rx2+		A14	B14	Tx2+	ITEM 3	
Rx2-		A15	B15	Tx2-	ITEM 3	
GND		A16	B16	GND	ITEM 3	
Rx3+		A17	B17	Tx3+	ITEM 3	
Rx3-		A18	B18	Tx3-	ITEM 3	
GND		A19	B19	GND	ITEM 3, NOTE 1	
GND		B1	A1	GND	ITEM 3	
Tx0+		B2	A2	Rx0+	ITEM 3	
Tx0-		B3	A3	Rx0-	ITEM 3	
GND		B4	A4	GND	ITEM 3	
Tx1+		B5	A5	Rx1+	ITEM 3	
Tx1-		B6	A6	Rx1-	ITEM 3	
GND		B7	A7	GND	ITEM 3	
SB0A		B8	A8	SB0	ITEM 4	
SB1A		B9	A9	SB1	ITEM 4	
GND(SB2A)		B10	A10	GND(SB2)	ITEM 3	
SB5A		B11	A11	SB5	ITEM 3	
SB6A		B12	A12	SB6	ITEM 3	
GND		B13	A13	GND	ITEM 3	
Tx2+		B14	A14	Rx2+	ITEM 3	
Tx2-		B15	A15	Rx2-	ITEM 3	
GND		B16	A16	GND	ITEM 3	
Tx3+		B17	A17	Rx3+	ITEM 3	
Tx3-		B18	A18	Rx3-	ITEM 3	
GND		B19	A19	GND	ITEM 3, NOTE 1	


- NOTES:**
- PIN/PAD ON CONNECTOR SO SHARED ON CONNECTORS PO AND PI.

CONNECTOR SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR SIGNAL	WIRE/CABLE
GND	SO	A19	PI	B1	GND	ITEM 3, NOTE 1
Rx4+		A20	B2	Tx0+	ITEM 3	
Rx4-		A21	B3	Tx0-	ITEM 3	
GND		A22	B4	GND	ITEM 3	
Rx5+		A23	B5	Tx1+	ITEM 3	
Rx5-		A24	B6	Tx1-	ITEM 3	
GND		A25	B7	GND	ITEM 3	
SB7B		A26	B8	SB7	ITEM 4	
SB4B		A27	B9	SB4	ITEM 4	
GND(SB3B)		A28	B10	GND(SB3)	ITEM 3	
SB8+		A29	B11	SB4+	ITEM 3	
SB8-		A30	B12	SB4-	ITEM 3	
GND		A31	B13	GND	ITEM 3	
Rx6+		A32	B14	Tx2+	ITEM 3	
Rx6-		A33	B15	Tx2-	ITEM 3	
GND		A34	B16	GND	ITEM 3	
Rx7+		A35	B17	Tx3+	ITEM 3	
Rx7-		A36	B18	Tx3-	ITEM 3	
GND		A37	B19	GND	ITEM 3	
GND		B19	A1	GND	ITEM 3, NOTE 1	
Tx4+		B20	A2	Rx0+	ITEM 3	
Tx4-		B21	A3	Rx0-	ITEM 3	
GND		B22	A4	GND	ITEM 3	
Tx5+		B23	A5	Rx1+	ITEM 3	
Tx5-		B24	A6	Rx1-	ITEM 3	
GND		B25	A7	GND	ITEM 3	
SB0B		B26	A8	SB0	ITEM 4	
SB1B		B27	A9	SB1	ITEM 4	
GND(SB2B)		B28	A10	GND(SB2)	ITEM 3	
SB5B		B29	A11	SB5	ITEM 3	
SB6B		B30	A12	SB6	ITEM 3	
GND		B31	A13	GND	ITEM 3	
Tx6+		B32	A14	Rx2+	ITEM 3	
Tx6-		B33	A15	Rx2-	ITEM 3	
GND		B34	A16	GND	ITEM 3	
Tx7+		B35	A17	Rx3+	ITEM 3	
Tx7-		B36	A18	Rx3-	ITEM 3	
GND		B37	A19	GND	ITEM 3	

# Cable 05-60005-00

The following figure shows the drawing and pinout for Broadcom cable 05-60005-00, a x8 SFF-8654 to 2 U.2 SFF-8639 connection.

Figure 20: Cable 05-60005-00 Drawing and Pinout



- DRAWING NOT TO SCALE.
- ELECTRICAL AND MECHANICAL PERFORMANCE SHALL MEET PCIe GEN 4 INDUSTRIAL STANDARD.
- MARK LABEL (ITEM 11) WITH:  
SFF-8602 U.2  
BROADCOM PART NUMBER  
BROADCOM REVISION XXX  
DATE CODE DD/MM/YY  
SECONDARY MARKING WITH MANUFACTURER PART NUMBER AND REVISION ACCEPTABLE.
- SEE CABLE WIRING TABLES AND RELATED NOTES.

CONNECTOR SIGNAL	CON	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR SIGNAL	WIRE/CABLE
GND	S0	A1	P0	E15	GND	ITEM 5
Rx0+		A2		E14	PERP0	ITEM 5
Rx0-		A3		E13	PERA0	ITEM 5
GND		A4		E12/S22	GND	ITEM 5, NOTE 1
Rx1+		A5		S21	PERB1	ITEM 5
Rx1-		A6		S20	PERA1	ITEM 5
GND		A7		S19	GND	ITEM 5
SB7A		A8		NC	NC	NOTE 2
SB8A		A9		NC	NC	
GND/SB3A		A10		E9	GND	ITEM 5
SB4+		A11		E7	REFCLK+	ITEM 5
SB4-		A12		E8	REFCLK-	ITEM 5
GND		A13		S28	GND	ITEM 5
Rx2+		A14		S27	PERB2	ITEM 5
Rx2-		A15		S26	PERA2	ITEM 5
GND		A16		E22/S25	GND	ITEM 5, NOTE 1
Rx3+		A17		E21	PERB3	ITEM 5
Rx3-		A18		E20	PERA3	ITEM 5
GND		A19		E19	GND	ITEM 5
GND		B1		E9	GND	ITEM 5
Tx0+		B2		E10	PE10	ITEM 5
Tx0-		B3		E11	PE10	ITEM 5
GND		B4		E12/S14	GND	ITEM 5, NOTE 1
Tx1+		B5		S17	PE11	ITEM 5
Tx1-		B6		S18	PE11	ITEM 5
GND		B7		S19	GND	ITEM 5
SB0A		B8		E23	SMCLK	ITEM 6, NOTE 4
SB1A		B9		E24	SMDAT	ITEM 6, NOTE 4
GND/SB2A		B10		E22	GND	ITEM 6, NOTE 4
SB4A		B11		E5	PER1A	ITEM 6, NOTE 4
SB6A		B12		P4	IFDET0	ITEM 6, NOTE 4
GND		B13		S22	GND	ITEM 5
Tx2+		B14		S23	PE12p	ITEM 5
Tx2-		B15		S24	PE12a	ITEM 5
GND		B16		S25/S28	GND	ITEM 5, NOTE 1
Tx3+		B17		E17	PE13	ITEM 5
Tx3-		B18		E18	PE13	ITEM 5
GND		B19		E19	GND	ITEM 5

CONNECTOR SIGNAL	CON	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR SIGNAL	WIRE/CABLE
GND	S0	A19	P1	E15	GND	ITEM 5
Rx4+		A20		E14	PERB0	ITEM 5
Rx4-		A21		E13	PERA0	ITEM 5
GND		A22		E12/S22	GND	ITEM 5, NOTE 1
Rx5+		A23		S21	PERB1	ITEM 5
Rx5-		A24		S20	PERA1	ITEM 5
GND		A25		S19	GND	ITEM 5
SB7B		A26		NC	NC	NOTE 3
SB8B		A27		NC	NC	
GND/SB3B		A28		E9	GND	ITEM 5
SB8+		A29		E7	REFCLK+	ITEM 5
SB8-		A30		E8	REFCLK-	ITEM 5
GND		A31		S28	GND	ITEM 5
Rx6+		A32		S27	PERB2	ITEM 5
Rx6-		A33		S26	PERA2	ITEM 5
GND		A34		S25/S22	GND	ITEM 5, NOTE 1
Rx7+		A35		E21	PERB3	ITEM 5
Rx7-		A36		E20	PERA3	ITEM 5
GND		A37		E19	GND	ITEM 5
GND		B19		E9	GND	ITEM 5
Tx4+		B20		E10	PE10	ITEM 5
Tx4-		B21		E11	PE10	ITEM 5
GND		B22		E12/S14	GND	ITEM 5, NOTE 1
Tx5+		B23		S17	PE11	ITEM 5
Tx5-		B24		S18	PE11	ITEM 5
GND		B25		S19	GND	ITEM 5
SB0B		B26		E23	SMCLK	ITEM 6, NOTE 4
SB1B		B27		E24	SMDAT	ITEM 6, NOTE 4
GND/SB2B		B28		E22	GND	ITEM 6, NOTE 4
SB5B		B29		E5	PER1A	ITEM 6, NOTE 4
SB6B		B30		P4	IFDET0	ITEM 6, NOTE 4
GND		B31		S22	GND	ITEM 5
Tx6+		B32		S23	PE12p	ITEM 5
Tx6-		B33		S24	PE12a	ITEM 5
GND		B34		S25/S28	GND	ITEM 5, NOTE 1
Tx7+		B35		E17	PE13	ITEM 5
Tx7-		B36		E18	PE13	ITEM 5
GND		B37		E19	GND	ITEM 5

- CONNECT SHIELD OF DIFFERENTIAL PAIR TO INDICATED PIN/PAD AND SHORT TO SECOND INDICATED PIN/PAD.
- SHORT PIN/PAD S0-A8 TO S0-B9. NO DIRECT CONNECT S0-A8 TO CONNECTOR P0.
- SHORT PIN/PAD S0-A26 TO S0-B21. NO DIRECT CONNECT S0-A26 TO CONNECTOR P1.
- END TO END RESISTANCE OF INDICATED CONNECTION SHALL BE 750 MILLIOM MAX.

CONNECTOR	PIN/PAD	CONNECTOR SIGNAL	NOTES
PO/P1	S2	S0T+	NO CONNECT
	S3	S0T-	
	S5	S0B-	PIN/PAD SHALL NOT BE CONNECTED VIA CONNECTOR INTERNALS NOR VIA WIRE
	S6	S0B+	
	S9	S1T+	
	S10	S1T-	
	S12	S1B-	
	S13	S1B+	
	S15	RSVD	
	E1	REFCLK+	
	E2	REFCLK-	
	E3	3.3Vaux	
	E4	ePERST#	
	E6	RSVD	
	E16	RSVD	
	E25	DualPortEn#	
	P1	RSVD	
	P2	sPCIeRs1	
	P3	RSVD	
	P10	PRST#	
	P11	Activity	

CONNECTOR	PIN/PAD	CONNECTOR SIGNAL	NOTES
PO/P1	S1	GND	GROUND
	S4	GND	ALL PIN/PAD SHALL BE CONNECTED TO COMMON INDIVIDUAL CONNECTOR GROUND
	S5	GND	
	S8	GND	
	S11	GND	
	S14	GND	
	P5	GND	
	P6	GND	
	P12	GND	


POWER CONNECTOR	PIN SYMBOL	CONNECTOR	PIN SYMBOL	WIRE COLOR
P2	1 12V	P0	P13, P14, P15	YELLOW
	2 GND		P12	ITEM 7 BLACK
	3 GND		P6	ITEM 7 BLACK
	4 5V		P7, P8, P9	ITEM 7 RED
P3	1 12V	P1	P13, P14, P15	ITEM 7 YELLOW
	2 GND		P12	ITEM 7 BLACK
	3 GND		P6	ITEM 7 BLACK
	4 5V		P7, P8, P9	ITEM 7 RED

# Cable 05-60006-00

The following figure shows the drawing and pinout for Broadcom cable 05-60006-00, a x8 SFF-8654 to x8 U.3 SFF-8639 connection.

Figure 21: Cable 05-60006-00 Drawing and Pinout

REVISIONS				
REV	ECO	DESCRIPTION	DATE	APPROVED
001		PRELIMINARY RELEASE	12APR18	
002	14709	PRELIMINARY RELEASE, REVISE CONN P10-P17 PIN 1 LOCATION, REVISE ITEM 7 DESCRIPTION, REVISE NOTE 3, REVISE MAIN AND DETAIL A VIEWS.	12OCT18	
003	17514	CHANGE NOTE 3 MARKING FROM U.317 TO SAS24A.	21NOV19	



CONNECTOR	SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR	SIGNAL	WIRE/CABLE	NOTES			
S0 HOST	GND	P0 TARGET	A1	S7	GND	ITEM 7						
	Rx0+		A2							S6	DO_TX0+	ITEM 7
	Rx0-		A3							S5	DO_TX0-	ITEM 7
	GND		A4							S4	GND	ITEM 7
	GND	P10	B1	P13, P14, P15	I2V	ITEM 9	YELLOW					
	Tx0+		B2							S2	DO_RX0+	ITEM 7
	Tx0-		B3							S3	DO_RX0-	ITEM 7
	GND		B4							S4	GND	ITEM 7
	GND	P0 TARGET	1	P12	GND	ITEM 9	BLACK					
	12V		2							P5, P6	GND	ITEM 9
GND	3		P7, P8, P9							5V	ITEM 9	RED
5V	4		P1							RSVD	NOTE 4	
NC	P0 TARGET		P2	sPCIeRsI	NOTE 4							
NC												

CONNECTOR	SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR	SIGNAL	WIRE/CABLE	NOTES			
S0 HOST	GND	P3 TARGET	A16	S7	GND	ITEM 7			NOTE 2			
	Rx3+		A17							S6	D3_TX0+	ITEM 7
	Rx3-		A18							S5	D3_TX0-	ITEM 7
	GND		A19							S4	GND	ITEM 7
	GND	P13	B16	P13, P14, P15	I2V	ITEM 9	YELLOW					
	Tx3+		B17							S2	D3_RX0+	ITEM 7
	Tx3-		B18							S3	D3_RX0-	ITEM 7
	GND		B19							S4	GND	ITEM 7
	GND	P3 TARGET	1	P12	GND	ITEM 9	BLACK					
	12V		2							P5, P6	GND	ITEM 9
GND	3		P7, P8, P9							5V	ITEM 9	RED
5V	4		P1							RSVD	NOTE 4	
NC	P3 TARGET		P2	sPCIeRsI	NOTE 4							
NC												

CONNECTOR	SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR	SIGNAL	WIRE/CABLE	NOTES			
S0 HOST	GND	P1 TARGET	A4	S7	GND	ITEM 7			NOTE 2			
	Rx1+		A5							S6	D1_TX0+	ITEM 7
	Rx1-		A6							S5	D1_TX0-	ITEM 7
	GND		A7							S4	GND	ITEM 7
	GND	P11	B4	P13, P14, P15	I2V	ITEM 9	YELLOW					
	Tx1+		B5							S2	D1_RX0+	ITEM 7
	Tx1-		B6							S3	D1_RX0-	ITEM 7
	GND		B7							S4	GND	ITEM 7
	GND	P1 TARGET	1	P12	GND	ITEM 9	BLACK					
	12V		2							P5, P6	GND	ITEM 9
GND	3		P7, P8, P9							5V	ITEM 9	RED
5V	4		P1							RSVD	NOTE 4	
NC	P1 TARGET		P2	sPCIeRsI	NOTE 4							
NC												

CONNECTOR	SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR	SIGNAL	WIRE/CABLE	NOTES			
S0 HOST	GND	P4 TARGET	A19	S7	GND	ITEM 7			NOTE 2			
	Rx4+		A20							S6	D4_TX0+	ITEM 7
	Rx4-		A21							S5	D4_TX0-	ITEM 7
	GND		A22							S4	GND	ITEM 7
	GND	P14	B19	P13, P14, P15	I2V	ITEM 9	YELLOW					
	Tx4+		B20							S2	D4_RX0+	ITEM 7
	Tx4-		B21							S3	D4_RX0-	ITEM 7
	GND		B22							S4	GND	ITEM 7
	GND	P4 TARGET	1	P12	GND	ITEM 9	BLACK					
	12V		2							P5, P6	GND	ITEM 9
GND	3		P7, P8, P9							5V	ITEM 9	RED
5V	4		P1							RSVD	NOTE 4	
NC	P4 TARGET		P2	sPCIeRsI	NOTE 4							
NC												

CONNECTOR	SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR	SIGNAL	WIRE/CABLE	NOTES			
S0 HOST	GND	P2 TARGET	A13	S7	GND	ITEM 7			NOTE 2			
	Rx2+		A14							S6	D2_TX0+	ITEM 7
	Rx2-		A15							S5	D2_TX0-	ITEM 7
	GND		A16							S4	GND	ITEM 7
	GND	P12	B13	P13, P14, P15	I2V	ITEM 9	YELLOW					
	Tx2+		B14							S2	D2_RX0+	ITEM 7
	Tx2-		B15							S3	D2_RX0-	ITEM 7
	GND		B16							S4	GND	ITEM 7
	GND	P2 TARGET	1	P12	GND	ITEM 9	BLACK					
	12V		2							P5, P6	GND	ITEM 9
GND	3		P7, P8, P9							5V	ITEM 9	RED
5V	4		P1							RSVD	NOTE 4	
NC	P2 TARGET		P2	sPCIeRsI	NOTE 4							
NC												

CONNECTOR	SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR	SIGNAL	WIRE/CABLE	NOTES			
S0 HOST	GND	P5 TARGET	A22	S7	GND	ITEM 7			NOTE 2			
	Rx5+		A23							S6	D5_TX0+	ITEM 7
	Rx5-		A24							S5	D5_TX0-	ITEM 7
	GND		A25							S4	GND	ITEM 7
	GND	P15	B22	P13, P14, P15	I2V	ITEM 9	YELLOW					
	Tx5+		B23							S2	D5_RX0+	ITEM 7
	Tx5-		B24							S3	D5_RX0-	ITEM 7
	GND		B25							S4	GND	ITEM 7
	GND	P5 TARGET	1	P12	GND	ITEM 9	BLACK					
	12V		2							P5, P6	GND	ITEM 9
GND	3		P7, P8, P9							5V	ITEM 9	RED
5V	4		P1							RSVD	NOTE 4	
NC	P5 TARGET		P2	sPCIeRsI	NOTE 4							
NC												

CONNECTOR	SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR	SIGNAL	WIRE/CABLE	NOTES			
S0 HOST	GND	P6 TARGET	A31	S7	GND	ITEM 7			NOTE 2			
	Rx6+		A32							S6	D6_TX0+	ITEM 7
	Rx6-		A33							S5	D6_TX0-	ITEM 7
	GND		A34							S4	GND	ITEM 7
	GND	P16	B31	P13, P14, P15	I2V	ITEM 9	YELLOW					
	Tx6+		B32							S2	D6_RX0+	ITEM 7
	Tx6-		B33							S3	D6_RX0-	ITEM 7
	GND		B34							S4	GND	ITEM 7
	GND	P6 TARGET	1	P12	GND	ITEM 9	BLACK					
	12V		2							P5, P6	GND	ITEM 9
GND	3		P7, P8, P9							5V	ITEM 9	RED
5V	4		P1							RSVD	NOTE 4	
NC	P6 TARGET		P2	sPCIeRsI	NOTE 4							
NC												

CONNECTOR	PIN/PAD	CONNECTOR	SIGNAL	NOTES
P0-P7 TARGET	S9	P0-P7 TARGET	S11+	NO CONNECT PIN/PAD SHALL NOT BE CONNECTED VIA CONNECTOR INTERNAL NOR VIA WIRE
	S10		S11-	
	S12		S1R-	
	S13		S1R+	
	S17		S2T+	
	S18		S2T-	
	S20		S2R-	
	S21		S2R+	
	S23		S3T+	
	S24		S3T-	
	S26		S3R-	
	S27		S3R+	
	P3		PWRDIS	
	P4		IFDET#	
	P10		PRSENT#	
	P11		Activity/DisableStaggeredSpinup	
	E1		RefC1k+	
	E2		RefC1k1-	
	E3		3.3Vaux	
	E4		ePERSTI#	
	E5		ePERSTO#	
	E6		IFDET2#	
	E7		RefC1k0+	
	E8		RefC1k0-	
	E9		GND	
E10	PETp0			
E11	PETn0			
E12	GND			
E13	PERn0			
E14	PERp0			
E15	GND			
E16	HPT1			
E17	PETp3			
E18	PETn3			
E19	GND			
E20	PERn3			
E21	PERp3			
E22	GND			
E23	SMC1k			
E24	SMDa1			
E25	DualPortEn#			
P0-P7 TARGET	S8	P0-P7 TARGET	GND	GROUND ALL PIN/PAD SHALL BE CONNECTED TO COMMON INDIVIDUAL CONNECTOR GROUND
	S11		GND	
	S14		GND	
	S15		GND (HPT0)	
	S16		GND	
	S19		GND	
	S22		GND	
	S25		GND	
S28	GND			

CONNECTOR	SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR	SIGNAL	WIRE/CABLE	NOTES			
S0 HOST	GND	P7 TARGET	A34	S7	GND	ITEM 7			NOTE 2			
	Rx7+		A35							S6	D7_TX0+	ITEM 7
	Rx7-		A36							S5	D7_TX0-	ITEM 7
	GND		A37							S4	GND	ITEM 7
	GND	P17	B34	P13, P14, P15	I2V	ITEM 9	YELLOW					
	Tx7+		B35							S2	D7_RX0+	ITEM 7
	Tx7-		B36							S3	D7_RX0-	ITEM 7
	GND		B37							S4	GND	ITEM 7
	GND	P7 TARGET	1	P12	GND	ITEM 9	BLACK					
	12V		2							P5, P6	GND	ITEM 9
GND	3		P7, P8, P9							5V	ITEM 9	RED
5V	4		P1							RSVD	NOTE 4	
NC	P7 TARGET		P2	sPCIeRsI	NOTE 4							
NC												

CONNECTOR	SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR	SIGNAL	WIRE/CABLE	NOTES				
S0 HOST	SB7A	P8	A8	P8	8	BP.TYPEA	ITEM 8	NOTE 1, BLUE					
	SB4A		A9							4	SDOA	ITEM 8	NOTE 1, YELLOW
	GND/SB3A		A10							6	GND	ITEM 8	NOTE 1, BROWN
	SBA+		A11								NC		
	SBA-	A12		NC									
	S80A	B8	P8	7	SCLKA	ITEM 8	NOTE 1, ORANGE						
	SB1A	B9		5						SLDA	ITEM 8	NOTE 1, PINK	
	GND/SB2A	B10		3						GND	ITEM 8	NOTE 1, BLACK	
	SB5A	B11		2						SDIA	ITEM 8	NOTE 1, GREEN	
	S86A	B12	P8	1	CTRL.TYPEA	ITEM 8	NOTE 1, WHITE						
	SB7B	A26		8						BP.TYPEB	ITEM 8	NOTE 1, BLUE	
	SB4B	A27		4						SDOB	ITEM 8	NOTE 1, YELLOW	
	GND/SB3B	A28		6						GND	ITEM 8	NOTE 1, BROWN	
	SBB+	A29		NC									
	SBB-	A30		NC									
	S80B	B26	P9	7	SCLKB	ITEM 8	NOTE 1, ORANGE						
	SB1B	B27		5						SLDB	ITEM 8	NOTE 1, PINK	
	GND/SB2B	B28		3						GND	ITEM 8	NOTE 1, BLACK	
	SB5B	B29		2						SDIB	ITEM 8	NOTE 1, GREEN	
	S86B	B30	P9	1	CTRL.TYPEB	ITEM 8	NOTE 1, WHITE						


- NOTES:**
1. END TO END RESISTANCE OF INDICATED CONNECTION SHALL BE 750 MILLIOHM MAX.
  2. SHARED PIN/PAD ON HOST (S0) CONNECTOR.
  3. SHARED PIN/PAD ON INDICATED TARGET (P0-P7) CONNECTOR.
  4. SHORT PIN/PAD P1 TO P2 OF INDICATED TARGET (P0-P7) CONNECTOR. NO CONNECT TO OTHER CONNECTORS.

# Cable 05-60007-00

The following figure shows the drawing and pinout for Broadcom cable 05-60007-00, a x8 SFF-8654 to x8 SFF-8654 connection.

Figure 22: Cable 05-60007-00 Drawing and Pinout

REVISIONS				
REV	ECO	DESCRIPTION	DATE	APPROVED
001		PRELIMINARY RELEASE	01MAY18	
002	175141	ADD WIRE GAUGE AND IMPEDANCE TOLERANCE. ITEM 2. REVISE MARKING REQUIREMENTS NOTE 3.	21NOV19	



- NOTES:**
- DRAWING NOT TO SCALE.
  - ELECTRICAL AND MECHANICAL PERFORMANCE SHALL MEET SAS 4.0 AND PCIe GEN 4 INDUSTRIAL SPECIFICATIONS.
  - MARK LABEL (ITEM 6) WITH:  
SFF-9402 SAS4/PCIe 4  
BROADCOM PART NUMBER  
BROADCOM REVISION XXX  
DATE CODE DD/MM/YY  
SECONDARY MARKING WITH MANUFACTURER PART NUMBER AND REVISION ACCEPTABLE.
  - SEE CABLE WIRING TABLE AND RELATED NOTES.

6	LABEL	LABEL, 70x26MM, WHITE, R2, HF	A/R	SEE NOTE 3
5	TAPE	ACETATE TAPE: W=1 INCH	A/R	
4	SLEEVING	EXPANDO TUBE: OD=1.0MM, GREEN, VW-1, HF	A/R	
3	WIRE	UL1061, STRANDED	A/R	
2	CABLE	SAS CABLE: UL20744, 28-32AWG, 92.5C2 ±10% DIFF, SAS4, PCIe GEN 4, VW-1, NATURAL, HF	A/R	SEE NOTE 4
1	CONNECTOR	SFF-8654, 74P, STRAIGHT, X8, STANDARD, SAS 4.0, PCIe GEN 4	2	SEE NOTE 4
ITEM	CALLOUT	DESCRIPTION	QUANTITY	NOTES

APPROVALS	DATE	UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN MILLIMETERS. TOLERANCES:	
DRAWN BY: ISFEB18	01MAY18	1.3 ± 0.2 MM 1.38 ± 0.15 MM 1.38 ± 0.050 MM ANGLES ± 1°	
APPROVED BY: 01MAY18		SCALE: 2.000	TITLE: CABLE, SFF-8654 TO SFF-8654, X8, STRAIGHT, 1M SHEET: 002 DWG NO: 5067-6869 REV: 002

CONNECTOR SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR SIGNAL	WIRE/CABLE	NOTES
GND	S0	A1	P0	B1	GND	ITEM 3	
Rx0+		A2		B2	Tx0+	ITEM 3	
Rx0-		A3		B3	Tx0-	ITEM 3	
GND		A4		B4	GND	ITEM 3	
Rx1+		A5		B5	Tx1+	ITEM 3	
Rx1-		A6		B6	Tx1-	ITEM 3	
GND		A7		B7	GND	ITEM 3	
SB7A		A8		B8	SB7A	ITEM 4	NOTE 1
SB4A		A9		B9	SB4A	ITEM 4	NOTE 1
GND/SB3A		A10		B10	GND/SB3A	ITEM 3	
SB4+		A11		B11	SB4+	ITEM 3	
SB4-		A12		B12	SB4-	ITEM 3	
GND		A13		B13	GND	ITEM 3	
Rx2+		A14		B14	Tx2+	ITEM 3	
Rx2-		A15		B15	Tx2-	ITEM 3	
GND		A16		B16	GND	ITEM 3	
Rx3+		A17		B17	Tx3+	ITEM 3	
Rx3-		A18		B18	Tx3-	ITEM 3	
GND		A19		B19	GND	ITEM 3	
Rx4+		A20		B20	Tx4+	ITEM 3	
Rx4-		A21		B21	Tx4-	ITEM 3	
GND		A22		B22	GND	ITEM 3	
Rx5+		A23		B23	Tx5+	ITEM 3	
Rx5-		A24		B24	Tx5-	ITEM 3	
GND		A25		B25	GND	ITEM 3	
SB7B		A26		B26	SB7B	ITEM 4	NOTE 1
SB4B		A27		B27	SB4B	ITEM 4	NOTE 1
GND/SB3B		A28		B28	GND/SB3B	ITEM 3	
SB8+		A29		B29	SB8+	ITEM 3	
SB8-		A30		B30	SB8-	ITEM 3	
GND		A31		B31	GND	ITEM 3	
Rx6+		A32		B32	Tx6+	ITEM 3	
Rx6-		A33		B33	Tx6-	ITEM 3	
GND		A34		B34	GND	ITEM 3	
Rx7+		A35		B35	Tx7+	ITEM 3	
Rx7-		A36		B36	Tx7-	ITEM 3	
GND		A37		B37	GND	ITEM 3	

- NOTES:**
- END TO END RESISTANCE OF INDICATED CONNECTION SHALL BE 750 MILLIOHM MAX.

CONNECTOR SIGNAL	CONNECTOR	PIN/PAD	CONNECTOR	PIN/PAD	CONNECTOR SIGNAL	WIRE/CABLE	NOTES
GND	S0	B1	P0	A1	GND	ITEM 3	
Tx0+		B2		A2	Rx0+	ITEM 3	
Tx0-		B3		A3	Rx0-	ITEM 3	
GND		B4		A4	GND	ITEM 3	
Tx1+		B5		A5	Rx1+	ITEM 3	
Tx1-		B6		A6	Rx1-	ITEM 3	
GND		B7		A7	GND	ITEM 3	
SB0A		B8		A8	SB0A	ITEM 4	NOTE 1
SB1A		B9		A9	SB1A	ITEM 4	NOTE 1
GND/SB2A		B10		A10	GND/SB2A	ITEM 3	
SB5A		B11		A11	SB5A	ITEM 3	
SB6A		B12		A12	SB6A	ITEM 3	
GND		B13		A13	GND	ITEM 3	
Tx2+		B14		A14	Rx2+	ITEM 3	
Tx2-		B15		A15	Rx2-	ITEM 3	
GND		B16		A16	GND	ITEM 3	
Tx3+		B17		A17	Rx3+	ITEM 3	
Tx3-		B18		A18	Rx3-	ITEM 3	
GND		B19		A19	GND	ITEM 3	
Tx4+		B20		A20	Rx4+	ITEM 3	
Tx4-		B21		A21	Rx4-	ITEM 3	
GND		B22		A22	GND	ITEM 3	
Tx5+		B23		A23	Rx5+	ITEM 3	
Tx5-		B24		A24	Rx5-	ITEM 3	
GND		B25		A25	GND	ITEM 3	
SB0B		B26		A26	SB0B	ITEM 4	NOTE 1
SB1B		B27		A27	SB1B	ITEM 4	NOTE 1
GND/SB2B		B28		A28	GND/SB2B	ITEM 3	
SB5B		B29		A29	SB5B	ITEM 3	
SB6B		B30		A30	SB6B	ITEM 3	
GND		B31		A31	GND	ITEM 3	
Tx6+		B32		A32	Rx6+	ITEM 3	
Tx6-		B33		A33	Rx6-	ITEM 3	
GND		B34		A34	GND	ITEM 3	
Tx7+		B35		A35	Rx7+	ITEM 3	
Tx7-		B36		A36	Rx7-	ITEM 3	
GND		B37		A37	GND	ITEM 3	







# Revision History

---

## **Version 2.6, December 12, 2024**

- Restructured [Board Storage Conditions](#).
- Added [Board Operating Conditions](#).
- Added the eHBA 9602W-16e adapter.
- Removed 3Gb/s SAS and SATA support references.

## **Version 2.5, May 21, 2024**

- Updated [Board Storage Conditions](#).
- Added [Cable 05-60009-00](#).

## **Version 2.4, January 17, 2024**

Added [FCC Compliance](#).

## **Version 2.3, October 31, 2023**

- Updated the address to 0x4C in [Virtual Pin Port Management](#).
- Removed reference to LED4.

## **Version 2.2, September 27, 2023**

Updated the 9670-24i adapter connector-to-CSW port associations in [Tri-Mode Storage Interface](#) and [PCIe \(NVMe\) Support](#).

## **Version 2.1, August 1, 2023**

- Updated the adapter dimensions in [Broadcom MegaRAID and HBA Tri-Mode Storage Adapter Characteristics](#).
- Updated [External Adapter Connector Pinout](#).

## **Version 2.0, August 30, 2022**

- Updated the resistor values in [Sideband Signals](#).
- Revised Typical Power values in [MegaRAID Tri-Mode Storage Adapter Power Supply Requirements](#) and [eHBA Tri-Mode Storage Adapter Power Supply Requirements](#).
- Changed SFF-8644 instances to SFF-8674.

## **Preliminary, Version 1.1, June 13, 2022**

- Revised the NVMe SSD count in [MegaRAID 9670W-16i, 9670-24i, and 9660-16i Adapter RAID Features](#).
- Updated the 05-60006-00 description in [Storage Interface Cabling](#).
- Added [Overtemperature Behavior](#).
- Updated the Adapter Marks and Certifications table in [Marks, Certifications, and Compliance](#).
- Added the eHBA 9600-8i8e adapter.
- Renamed HBA to eHBA.

**Preliminary, Version 1.0, March 8, 2022**

- Updated the 9670-24i and 9600-24i adapters in the NVMe Device or PCIe Switch Direct-Attach Options Supported for Each Adapter table in [PCIe \(NVMe\) Support](#).
- Updated the following tables in [PCIe \(NVMe\) Support](#):
  - 9670-24i Adapter PCIe Topology Configuration Combinations
  - 9600-24i Adapter PCIe Topology Configuration Combinations
- Updated [External Adapter Connector Pinout](#).
- Added board layout images.
- Updated [Power Supply Requirements](#).
- Updated the values regarding the CacheVault power module in [MegaRAID Tri-Mode Storage Adapter Power Supply Requirements](#).

**Advance, Version 0.2, March 19, 2021**

- Changed the 9660-16i cache memory description in the MegaRAID Tri-Mode Storage Adapter Features table in [Overview](#).
- Updated the drive descriptions in the HBA Tri-Mode Storage Adapter Features table in [Overview](#).
- Revised [eHBA 9600 Adapter Features](#).
- Added a note to [PCIe \(NVMe\) Support](#).
- Added [Adapter Security](#).
- Added the MegaRAID 9670-24i adapter.

**Advance, Version 0.1, April 27, 2020**

Initial document release.

