

CSM-MTD

Current-Sensor-Module Demonstration Kit for Automotive Motor Drive Applications

Overview

The Current-Sensor-Module Demonstration Kit (CSM-MTD) is designed to evaluate digital filters and isolated Sigma-Delta Modulators with input voltage from an external shunt resistor and then output ADC data to a user's controller MCU, DSP, or microprocessor. The kit can demonstrate sensing for an electric motor 3-phase current.

The Demonstration Kit mainly consists of the following items:

- 3-channel isolated Sigma-Delta Modulator Board with ACPL-C799T
- Digital Filter Board with ASIC ACPL-0873T for 3-channel SDM input
- Broadcom Bridge Board to Arduino Due Evaluation Board


The key features of the Demonstration Kit are as follows:

- Three Individual Digital Filters in the ACPL-0873T
- Sampling Time Synchronization
- Fast Over-range Detection
- Offset Calibration
- Programmable Input Configuration
- SPI Interface ADC Data Output
- Sensing range up to 500A current together with a 0.1 mΩ shunt, or a sensing range of up to 1000A current together with a 0.05 mΩ shunt

Broadcom Bridge Board to
Arduino DUE Evaluation Board

Digital Filter Board inclusive
ACPL-0873T

SDM board inclusive ACPL-C799T and
isolated DC-DC power supply.



Ordering Information

The ordering code is W1202-475318 (CSM-MTD). Contact Broadcom sales or an authorized distributor for prices.

NOTE: Broadcom does not provide shunt products, but may offer shunt samples to customers by request until the limited stock is finished

Demonstration Kit Connections


Refer to [Evaluation Board Circuit Schematic](#) for a detailed schematic.

Connection Map between the Digital Filter Board and the SDM Board Using an FPC Cable

Signal	SDM Board	Digital Filter
	H5	H1/H2/H3
VDD	4	1
MCLK	3	2
MDAT	2	3
GND	1	4

FPC Connector

Same-side-contacts and 1-mm pitch Flexible-Printed-Circuit (FPC) cables are used to connect the Digital Filter Board and the Sigma-Delta Modulator Board. Lift the connector's actuator up before inserting or removing the cable. Press down on the actuator after inserting the cable into the connector.



Connection Map between the Digital Filter Board and the CSM-DUE Bridge Board

Signal	Digital Filter Board	CSM-DUE Bridge Board		
	P2	P1	Pin Name	Connector
/CS	1	1	D24	JP8
/INT	2	2	D26	JP8
SCLK	3	3	SCLK	P1
/RST	4	4	D28	JP8
MISO	5	5	MISO	JP1
OC	6	6	D27	JP8
MOSI	7	7	MOSI	JP1
DR	8	8	D25	JP8
GND	11	11	GND	JP10, JP1
VDD	12	12	3.3V	JP10

When other MCU evaluation boards are used to replace the Arduino Due, connect the respective MCU board I/O port to Digital Filter Board connector P2. A 3.3V power supply is required. See the following section for more information.

Power Supply VDD Requirements


- Voltage: 3.3 VDC +/- 5%
- Current Minimum: 10 mA for the Digital Filter Board and 40 mA for each channel SDM Board.

Software Installation and Operation

Installing the Arduino Due Board USB Driver

To install the Arduino Due Board USB driver, complete the following steps:

1. Install the Arduino Due board USB driver located in the Arduino IDE from <https://www.arduino.cc/en/Main/Software>. More technical information about the Arduino Due board is available at <https://www.arduino.cc/en/Main/ArduinoBoardDue>.
2. During Arduino IDE installation, connect the Micro-USB cable from the computer to the Arduino Due board Programming Port.
3. After Arduino IDE installation, connect the Micro-USB cable from the computer to the Arduino Due board Native Port.
4. Verify that the driver was successfully installed on the computer by navigating to **Control Panel > Device Manager > Ports (COM & LPT)**.



Broadcom GUI Software Requirements

To run the Broadcom GUI, the user's computer must meet the following requirements:

- Windows OS 7.0 or later.
- A display resolution of 1920 X 1080 pixels or greater.

The user must also copy the demonstration software, `DigitalFilter v1.5.exe`, from a CD-ROM to the computer local drive.


NOTE: Contact Broadcom local sales for the demonstration software.

Bench Verification of the GUI Software and Demonstration Kit Functions

Bench Verification

To perform bench verification, complete the following steps:

1. Connect a 1Ω-resistor as a shunt at each channel ACPL-C799T input.
2. Send a General Waveform Generator output signal to the 1Ω-resistor. The current through the three shunts will be the same if three 1Ω-resistors are connected to the serial port.
3. Connect the computer's USB port to the Arduino Due Board's Native Port.




Example of Saved Log Data

3-Channel ADC Data in unsigned 16-bit decimal counts	Digital Filter Data Log SW 1.3						3-Channel ADC Fast-Fourier-Transformation (FFT) Data using one-sided power spectrum.
	ts = 86.7 μs	Sinc3 M=256	Sync off	Page 4/4	1020 Samples		
	fs = 11.54 kHz	F_CLK = 10 MHz					
Chan 1 - Offset = 77	Chan 2 - Offset = 73	Chan 3 - Offset = 26	PS Chan 1 - peak 89	PS Chan 2 - peak 89	PS Chan 3 - peak 89	Frequency(Hz)	
44968	44951	45050	-38.74537	-38.711319	-38.35733	0	
37327	37351	37396	-37.67979	-37.647015	-37.29035	11.3	
28324	28376	28353	-43.63582	-43.611361	-43.24372	22.5	
20569	20641	20549	-53.99354	-54.024927	-53.61993	33.8	
16319	16372	16245	-69.34268	-69.926137	-69.28329	45.1	
16770	16809	16678	-87.54132	-97.800114	-91.3222	56.3	
21821	21822	21716	-96.00454	-96.422403	-102.8476	67.6	

GUI Software Operation

To open the GUI, double click on `DigitalFilter v1.5.exe`. The following image shows the GUI.



To configure the GUI, complete the following steps:

1. Select the Sigma-Delta Modulator C799T mounted on the SDM Board.
2. Select the applied input channel
3. Select the Digital Filter Mode.
4. Enter the Input Offset calibration. Before clicking on **CAL** to capture input offset value, short the Sigma-Delta Modulator C799T input (that is, remove the Waveform Generator source cable and use a wire to short the 1Ω resistor). The offset value is stored in the MCU Evaluation Board's flash memory.
5. Enable or disable the Input Offset Calibration as necessary. When Offset Calibration is enabled, the GUI software subtracts the offset value stored in the MCU Board's flash memory from the raw ADC value of the digital filter.
6. Enable or Disable sampling synchronization for the filters.
7. Start or stop capturing data continuously. The GUI software reconstructs the ADC data as an input voltage signal graphic in the GUI window.
8. Save the last captured ADC data batch to the local drive. See [Example of Saved Log Data](#) for an example of the generated data.
9. Set the Over-Range value and channel.
10. Turn the FFT display On or Off, then select the display channel.
11. Set the Zoom level for the waveforms displayed.
12. Read the single ADC output data for each channel.
13. Close the software.

NOTE:

- The ADC data shown in the GUI is bipolar 16 bit.
- If a channel ADC output is -32768 or 32767 continuously, there may be an input open.

SPI Communication Software Implementation and Practice with the Arduino Due Board

The Arduino Due is configured in SPI Master Mode (SPI Mode 0 MSB first). The CS Pin is used for filter conversion start. The CS Pin is also used by SPI Chip Select to read and write registers. When CS is low, the registers on the digital filter can be read and written without having to toggle CS. This allows the Data Ready (DR) status on the ACPL-0873T Interrupt Status Register (0x02) to be read without restarting the filter conversion.

Sampling Methods

There are three main methods for reading data from the digital filter.

Method 1: Poll DR Status (Using a Timer)

Since the filter conversion time is known, a timer can be set to poll the DR status in Register 0x02 so that tasks can be done in between reads. Polling of the DR status is started just before the data is ready.

Method 2: Interrupt on DR Status on INT Pin

The ACPL-0873T Interrupt Enable Register (0x03) can be configured to output the DR status to the INT Pin, and the Arduino Due can be configured to interrupt on the INT pin H→L. The DR status is cleared when the Interrupt Status Register (0x02) is read, so the Interrupt Status Register needs to be read after the data has been read out from the filter in order to manually clear the DR status.


Method 3: Interrupt on DR Pin Signal

The DR pin signal is cleared automatically when CS is L→H, so the Arduino Due can be configured to interrupt on the DR pin signal L→H instead of using the DR status through the INT pin. The data can then be read out before the filter conversion is restarted by toggling CS, which clears the DR pin signal.


To achieve a constant sample rate, the CS pin can be toggled using either a timer or a PWM signal, but sufficient time must be allowed so the data can be sampled before the CS pin is toggled.

Flow Charts

Method 1: Polling Flow Chart



Methods 2 and 3: Interrupt Flow Chart



Sample Code

Timer Setup

```
// Delay = rc / (MCLK / 128)
void startTimer (Tc *tc, uint32_t channel, IRQn_Type irq, uint32_t rc) {
    pmc_set_writeprotect (false);
    pmc_enable_periph_clk ((uint32_t) irq);
    TC_Configure (tc, channel, TC_CMR_WAVE | TC_CMR_WAVSEL_UP_RC | TC_CMR_TCCLKS_TIMER_CLOCK4);
    TC_SetRA (tc, channel, rc >> 1);
    TC_SetRC (tc, channel, rc);
    TC_Start (tc, channel);
    tc->TC_CHANNEL[channel].TC_IER=TC_IER_CPCS;
    tc->TC_CHANNEL[channel].TC_IDR=~TC_IER_CPCS;
    NVIC_EnableIRQ(irq);
}

void stopTimer(Tc *tc, uint32_t channel, IRQn_Type irq) {
    TC_Stop (tc, channel);
    NVIC_DisableIRQ (irq);
}
```

Method 1: Poll DR Status

```
void setup_polling() {
    // Set flags
    flag = false; obuffer = buffer = 0; counter = 0;
    // Start transfer
    setCS(); clearCS();
    // Start Poll timer
    startTimer (TC1, 1, TC4_IRQn, delay_poll [filter_type]);
    // Start CS Pin timer
    startTimer (TC1, 0, TC3_IRQn, delay_cs [filter_type]);
    // Read interrupt status register to clear DR
    spiTransfer (0x92);
    spiTransfer (0x00);
}

// Main Loop
if (flag)
{
    // Read interrupt status register to check DR
    spiTransfer (0x92);
    if ((spiTransfer (0x00)) & 0x01)
    {
        // Read 2/2/4/6 bytes to buffer
        spiRead ((uint8_t*) &spi_data [buffer] [counter], num_bytes [chan_select]);
        // Increment counter and wrap when buffer full
        counter = (counter + num_bytes [chan_select]) * ((counter + num_bytes [chan_select]) < buffer_size);
        buffer = (buffer + (counter==0)) & 0x01;
        // Clear flag
        flag = false;
    }
}
```

```
// CS Pin Timer Handler
void TC3_Handler() {
    TC_GetStatus (TC1, 0);
    // Start next transfer
    setCS(); clearCS();
    // Restart poll timer
    startTimer (TC1, 1, TC4_IRQn, delay_poll [filter_type]);
}

// Poll Timer Handler
void TC4_Handler()
{
    TC_GetStatus (TC1, 1);
    // Set flag
    flag = true;
    // Stop poll timer
    stopTimer (TC1, 1, TC4_IRQn);
}
```

Method 2: Interrupt Using DR Status on INT Pin

```
void setup_int_pin() {
    // Set flags
    obuffer = buffer = 0; counter = 0;
    // Start transfer
    setCS(); clearCS();
    // Set interrupt enable register DR_E
    spiTransfer (0xA3);
    spiTransfer (0x01);
    // Read interrupt status register to clear DR
    spiTransfer (0x92);
    spiTransfer (0x00);
    // Enable INT pin interrupt
    attachInterrupt (INT_PIN, data_ready_isr, FALLING);
    // Start CS Pin timer
    startTimer (TC1, 0, TC3_IRQn, delay_cs [filter_type]);
}

// Data Ready ISR
void data_ready_isr() {
    // Read 2/2/4/6 bytes to buffer
    spiRead ((uint8_t*) &spi_data [buffer] [counter], num_bytes [chan_select]);
    // Increment counter and wrap when buffer full
    counter = (counter + num_bytes [chan_select]) * ((counter + num_bytes [chan_select]) < buffer_size);
    buffer = (buffer + (counter==0)) & 0x01;
}

// CS Pin Timer Handler
void TC3_Handler() {
    TC_GetStatus (TC1, 0);
    // Start next transfer
    setCS(); clearCS();
    // Read interrupt status register to clear DR
    spiTransfer (0x92);
    spiTransfer (0x00);
}
```

Method 3: Interrupt Using DR Pin Signal

```
void setup_dr_pin() {
    // Set flags
    obuffer = buffer = 0; counter = 0;
    // Start transfer
    setCS(); clearCS();
    // Enable DR pin interrupt
    attachInterrupt (DR_PIN, data_ready_isr, RISING);
    // Start CS Pin timer
    startTimer (TC1, 0, TC3_IRQn, delay_cs [filter_type]);
}


// Data Ready ISR
void data_ready_isr() {
    // Read 2/2/4/6 bytes to buffer
    spiRead ((uint8_t*) &spi_data [buffer] [counter], num_bytes [chan_select]);
    // Increment counter and wrap when buffer full
    counter = (counter + num_bytes [chan_select]) * ((counter + num_bytes [chan_select]) < buffer_size);
    buffer = (buffer + (counter==0)) & 0x01;
}

// CS Pin Timer Handler
void TC3_Handler() {
    TC_GetStatus (TC1, 0);
    // Start next transfer
    setCS(); clearCS();
}
```


Evaluation Board PCB Design

Evaluation Board Circuit Schematic

Sigma-Delta Modulator Board



Digital Filter Board



Evaluation Board Component List

Sigma-Delta Modulator Board

Land Pattern	Value	Designator	Description
C0402	220 nF	C1	C0402 220 nF / 16V 10% X7R
C1206	1 μ F	C2	C1206, 1 μ F, 50 V, \pm 0%, X7R
C0402	0.1 μ F	C3	C0402, 0.1 μ F, 16V, X7R, +/-20%
C0402	1 μ F	C4, C5, C6	C0402, 1 μ F, 16 V, \pm 10%, X5R
C0603	4.7 μ F	C7	C0603, 4.7 μ F, 16V, \pm 10%, X5R
SOD-123	MBR0520L	D1, D2	Rectifier Diode
L0402	Ferrite Bead	FB	HZ0402A601R-10, 100 mA
—	TE 1734248	H5	FPC Connector, 1 mm pitch
R0402	1R	R1, R2	R0402, 1R, 50 V, 100 mW, \pm 1%
—	WE 7466203R	S1, S2	SMD Spacer, Blind hole M3
SO6	Viso 5kVac	T1	Transformer WE 750313626, or TTe HA00-17007LF
SSO8	ACPL-C799T	U1	Broadcom Iso Sigma-Delta Modulator
DBV	SN6501-Q1	U2	Transformer Driver
DBV	TPS76350-Q1	U3	5V LDO

Digital Filter Board

Land Pattern	Value	Designator	Description
C0402	1 μ F	C10, C11	C0402, 1 μ F, 25 V, \pm 10%, X5R
C0402	10 nF	C12	C0402, 10 nF, 25V, \pm 10%, X7R
C0402	0.1 μ F	C13	C0402, 0.1 μ F, 16V, X7R, +/-20%
—	TE 1734248	H1, H2, H3	FPC Connector, 1 mm pitch
—	AMP 1241050-6	P2	Header 2X6P = 12P 2.54 mm
R0402	3.3 k Ω	R11	R0402, 3.3 k Ω , 50V, 125 mW, \pm 1%
R0402	33 Ω	R12	R0402, 33 Ω , 50V, 125 mW, \pm 1%
L0402	Ferrite Bead	X1	HZ0402A601R-10, 100 mA
QFN-20	ACPL-0873T	U4	Broadcom Digital Filter

Insulation Information between the Primary Side and the Secondary Side

- 5kVAC / 1-minute isolation voltage
- Clearance and Creepage distance: > 8 mm

Appendix

Digital Filter Typical Conversion Time

Filter Mode (K)	Decimation Ratio (D)	Filter Conversion Time t_C at 10 MHz MCLK (1 / t_C)
SINC2	1024	205 μ s (4.88 kHz)
SINC2	512	102 μ s (9.76 kHz)
SINC2	256	51 μ s (19.52 kHz)
SINC2	128	25 μ s (39.04 kHz)
SINC3	256	77 μ s (13.02 kHz)
SINC3	128	38 μ s (26.04 kHz)
SINC3	64	19 μ s (52.08 kHz)

NOTE: t_C is calculated as $t_C = 1 / f_{MCLK} * D * K$.

SPI Typical Timing

SPI Clock (MHz)	Time for 8-bit Write (μ s)	Time for 8-bit Write and 8-bit Read (μ s)	Time for 48-Bit Read (μ s)
5	1.60	3.20	9.6
10	0.80	1.60	4.8
15	0.53	1.06	3.18
20	0.40	0.80	2.40

Associated Information: Shunt

Manufacturer	TT Electronics	KOA	Isabellenhutte	Vishay
0.1 m Ω Part Number	EBW-387-38-061 	2017-c-818 	BAS-M-R0001 	WSBS8518L1000JTM4 
0.05 m Ω Part Number	Available on request.	Available on request.	BAS-M-00005 	WSBS8518L0500JTM4 
Worldwide Contact	www.ttelectronicsresistors.com	www.koaglobal.com	www.isabellenhuetten.de	www.vishay.com

Revision History

CSM-MTD-UG100; May 16

Initial release.

Important Notice

The Broadcom Current-Sensor-Module Demonstration Kit's circuit schematic and PCB layout are reference designs made by Broadcom for evaluation purpose *only*. The verification was done at room temperature. Users may use the Demonstration Kit's circuit schematic and PCB design as a reference to evaluate Broadcom Current-Sensor-Module Demonstration Kit functions *only* at room temperature on the condition that Broadcom holds neither liability on user's system performance with the Demonstration Kit applied nor on reliability.

The testing was done using a small sample size. The testing results presented in this document are *only* applicable to the circuit and component values, as well as other operating conditions only designated in this document. However, users may implement component value changes or circuitry modifications to achieve customized performance at their own discretion.

Broadcom, the pulse logo, Connecting everything, Avago Technologies, Avago, and the A logo are among the trademarks of Broadcom and/or its affiliates in the United States, certain other countries, and/or the EU.

Copyright © 2019 Broadcom. All Rights Reserved.

The term "Broadcom" refers to Broadcom Inc. and/or its subsidiaries. For more information, please visit www.broadcom.com.

Broadcom reserves the right to make changes without further notice to any products or data herein to improve reliability, function, or design. Information furnished by Broadcom is believed to be accurate and reliable. However, Broadcom does not assume any liability arising out of the application or use of this information, nor the application or use of any product or circuit described herein, neither does it convey any license under its patent rights nor the rights of others.